#### Manuals+

Q & A | Deep Search | Upload

#### SMRGBCD001

# Wireless Mouse for Laptop PC Bluetooth RGB Rechargeable Mouses

# USER MANUAL

Brand: Generic | Model: SMRGBCD001

#### 1. Introduction

Thank you for purchasing the Generic Wireless Mouse. This manual provides detailed instructions for setting up, operating, and maintaining your new mouse to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and keep it for future reference.

This sleek and stylish wireless mouse is designed to elevate your computing experience. Its ergonomic design ensures comfortable use for extended periods, while the smooth gliding surface allows for precise cursor control. Featuring a striking RGB lighting system that cycles through a vibrant spectrum of colors, this mouse adds a touch of flair to your desktop setup. With its plug-and-play functionality and reliable wireless connectivity, you can bid farewell to tangled cords and enjoy seamless operation. Crafted with durability in mind, this mouse is built to withstand the demands of daily use.

#### 2. Product Overview

The Generic Wireless Mouse combines ergonomic comfort with advanced features for an enhanced user experience. Key features include:

- Seamless RGB Lighting: A vibrant RGB lighting strip that cycles through a spectrum of colors.
- Ergonomic Design: Contoured shape and textured grips for comfortable and secure handling.
- Precise Tracking: High-precision optical sensor for smooth and accurate cursor control.
- Dual Connectivity: Supports 2.4GHz wireless connection and Bluetooth (3.0 and 5.2) for versatile pairing.
- Rechargeable Battery: Built-in 500mAh lithium polymer battery for extended use.
- Silent Buttons: Mute buttons for a quiet clicking experience.
- Plug and Play: No software installation required for 2.4GHz mode.



Figure 2.1: Front view of the Generic Wireless Mouse, showcasing its sleek black design and vibrant RGB lighting strip along the sides.



Figure 2.2: The slim profile of the wireless mouse, highlighting its rechargeable light feature and indicating support for both Bluetooth and USB receiver connectivity.



Figure 2.3: Illustration of the mouse's versatile connectivity options, supporting Bluetooth 3.0, Bluetooth 5.2, and 2.4G wireless modes, allowing connection to multiple devices.

# 3. Setup

#### 3.1 Initial Charging

Before first use, it is recommended to fully charge the mouse. Connect the included USB charging cable to the mouse's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter).



Figure 3.1: The mouse connected to a charging cable, illustrating its 500mAh battery and long endurance after a single charge. The RGB lighting may indicate charging status. A full charge typically provides up to 60 days of use, depending on usage patterns and RGB lighting settings.

# 3.2 Connecting the Mouse

Your mouse supports two primary connection modes: 2.4GHz Wireless and Bluetooth.

# 3.2.1 2.4GHz Wireless Connection

- 1. Locate the USB nano receiver, usually stored in a compartment on the bottom of the mouse.
- 2. Plug the USB nano receiver into an available USB port on your computer.
- 3. Turn on the mouse using the power switch located on the bottom.
- 4. Switch the mouse to 2.4G mode (refer to the mode switch on the bottom of the mouse).
- 5. The computer should automatically detect and install the necessary drivers. The mouse is ready for use.

#### 3.2.2 Bluetooth Connection

The mouse supports Bluetooth 3.0 and Bluetooth 5.2. You can easily pair one mouse to connect to two computers and switch freely between them.

1. Turn on the mouse using the power switch on the bottom.

- 2. Switch the mouse to Bluetooth mode (BT1 or BT2, refer to the mode switch on the bottom of the mouse).
- 3. On your computer or device, open Bluetooth settings.
- 4. Search for new devices. The mouse should appear as "Wireless Mouse" or similar.
- 5. Select the mouse to pair. Follow any on-screen prompts.
- 6. Once paired, the mouse is ready for use.

# 4. Operating Instructions

#### 4.1 Power On/Off

Use the power switch located on the bottom of the mouse to turn it ON or OFF.

# 4.2 Switching Connection Modes

The mouse features a mode switch on its underside, allowing you to toggle between 2.4G wireless mode and two Bluetooth modes (BT1, BT2). This enables seamless switching between up to three connected devices.

# 4.3 DPI Adjustment

The mouse typically features a DPI (Dots Per Inch) button, often located near the scroll wheel, to adjust cursor sensitivity. Press this button to cycle through different DPI settings (e.g., 800, 1200, 1600 DPI) to match your preference and task requirements.

# 4.4 RGB Lighting Control

The mouse features dynamic RGB lighting. The lighting typically activates automatically when the mouse is in use. Some models may allow cycling through different lighting modes or turning the lighting off by pressing a specific button (often the DPI button or a dedicated light button) or a combination of buttons. Refer to the product's specific button functions for detailed control.



Figure 4.1: The mouse's colorful and cool RGB lights, designed to enhance the aesthetic of your desktop setup.

# 4.5 Silent Click Feature

This mouse is designed with mute buttons, providing a quiet clicking experience. This feature is particularly beneficial in quiet environments, ensuring you do not disturb others.



Figure 4.2: Demonstrating the silent button feature, allowing for comfortable and undisturbed use, even in quiet environments.

#### 5. Maintenance

# 5.1 Cleaning

To clean your mouse, gently wipe its surface with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the mouse's finish or internal components.

# 5.2 Battery Care

- · Avoid exposing the mouse to extreme temperatures (hot or cold) as this can affect battery life.
- If the mouse will not be used for an extended period, it is advisable to turn it off to conserve battery life.
- Charge the mouse using only the provided cable or a compatible USB charging cable.

# 6. Troubleshooting

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Mouse not responding (2.4GHz)	Ensure the mouse is turned ON.  Check if the USB receiver is securely plugged into a working USB port.  Ensure the mouse is switched to 2.4G mode.  Try plugging the receiver into a different USB port.  Recharge the mouse if the battery is low.
Mouse not responding (Bluetooth)	Ensure the mouse is turned ON.  Ensure the mouse is switched to the correct Bluetooth mode (BT1/BT2).  Make sure Bluetooth is enabled on your device.  Unpair and re-pair the mouse in your device's Bluetooth settings.  Recharge the mouse if the battery is low.
Cursor erratic or jumpy	Clean the optical sensor on the bottom of the mouse.  Use the mouse on a clean, non-reflective surface or a mouse pad.  Check for interference from other wireless devices.
RGB lights not working	Ensure the mouse is turned ON.  Check if the battery is charged.  Some models may have a button to toggle RGB lights; try pressing it.
Mouse not charging	Ensure the charging cable is properly connected to both the mouse and the power source.  Try a different USB port or power adapter.  Ensure the charging cable is not damaged.

# 7. Specifications

Feature	Detail
Model Number	SMRGBCD001
Brand	Generic
Connectivity Technology	Bluetooth (3.0, 5.2), 2.4GHz USB Wireless
Movement Detection Technology	Optical
Color	Black
Special Feature	Ergonomic Design, RGB Lighting, Silent Click Buttons
Battery Type	1 Lithium Polymer battery (500mAh)
Manufacturer	Ch
Date First Available	August 26, 2024

# 8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the manufacturer's official website. Keep your proof of purchase for any warranty claims.

If you encounter any issues not covered in this manual, please contact the retailer or manufacturer's customer service for assistance.

© 2024 Generic. All rights reserved.

This manual is subject to change without notice.