

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Eueiriup](#) /

> [Eueiriup HKWH002-800W Electric Wall Heater User Manual](#)

Eueiriup HKWH002-800W

Eueiriup HKWH002-800W Electric Wall Heater User Manual

Model: HKWH002-800W



Image: The Eueiriup HKWH002-800W Electric Wall Heater, a compact white panel heater with wheels, emitting warm air.

IMPORTANT SAFETY INSTRUCTIONS

Please read this entire instruction manual carefully before installing or using your Eueiriup Electric Wall Heater. Failure to follow these instructions may result in fire, electric shock, serious injury, or death. Keep this manual for future reference.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock

or fire, or damage the heater.

- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- This heater is equipped with overheat protection. If the heater overheats, it will automatically shut off. To reset, unplug the heater from the electrical outlet, wait 10 minutes for the unit to cool, then plug it back in.
- The heater is IPX4 waterproof rated, suitable for bathroom use, but avoid direct water spray.
- Features anti-tip protection. If the heater is accidentally knocked over, it will automatically shut off.

PACKAGE CONTENTS

Verify that all components are present before beginning installation.

- Eueiriup HKWH002-800W Electric Wall Heater Unit
- Wall Mounting Bracket and Hardware
- Caster Wheels (for freestanding use)
- User Manual

SETUP AND INSTALLATION

Your Eueiriup heater offers both freestanding and wall-mounted installation options.

Option 1: Freestanding Installation (with wheels)

1. Carefully unpack the heater and all components.
2. Attach the caster wheels to the base of the heater using the provided screws. Ensure they are securely fastened.
3. Place the heater on a stable, level surface, away from flammable materials.



Image: The heater shown in both freestanding mode with wheels and wall-mounted mode, illustrating its dimensions (22.25" H x 15.83" W x 3.54" D).



Image: Detailed view of the heater's design features, including universal wheels for easy movement, a hidden handle for portability, and a dedicated power cord storage area for convenience.

Option 2: Wall-Mounted Installation

1. Choose a suitable wall location, ensuring it is a safe distance from curtains, furniture, and other flammable materials.
2. Using the provided wall mounting bracket as a template, mark the drilling points on the wall.
3. Drill holes and insert wall anchors if necessary.
4. Secure the mounting bracket to the wall using the provided screws.
5. Carefully hang the heater onto the mounting bracket, ensuring it is securely seated.
6. Ensure the heater is plugged into a grounded electrical outlet.

OPERATING INSTRUCTIONS

The Eueiriup Electric Wall Heater is designed for simple and efficient operation.

Powering On/Off

- Plug the heater into a standard 120V AC electrical outlet.
- Locate the power knob on the side of the unit. Turn the knob clockwise to select a heating mode.
- To turn off the heater, turn the power knob counter-clockwise to the "OFF" position.

Adjusting Heat Settings and Temperature



Image: The heater's control panel showing two rotary knobs. The top knob controls temperature regulation (indicated by '+' and '-' symbols), and the bottom knob selects between 'Full power' and 'Half-power' heating modes.

- **Power Setting Knob:** This knob allows you to select between two heating power levels:
 - **Half-power:** For lower heat output and energy saving.
 - **Full power:** For maximum heat output (800W) to quickly warm the room.
- **Temperature Regulation Knob:** This knob controls the thermostat. Turn it clockwise to increase the desired temperature and counter-clockwise to decrease it. The heater will cycle on and off to maintain the set temperature.

The heater utilizes aluminum convection technology for efficient warming. You may feel warmth within 2 seconds, and the room temperature will adjust within minutes.



Image: An illustration of the heater effectively warming a bedroom through convection, showing warm air rising and circulating throughout the space.

Energy Efficient Heater



Image: The heater mounted on a bathroom wall, highlighting its features: low noise operation, energy saving, and fast heating (60-second warm-up indicated).

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Always unplug the heater before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents. Ensure no water enters the internal components.
- **Storage:** If storing the heater for an extended period, ensure it is clean and dry. Store it in a cool, dry place, preferably in its original packaging. Utilize the power cord storage area for neatness.
- **Inspection:** Periodically inspect the power cord and plug for any signs of damage. If damage is found, discontinue use and contact customer support.

TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Heater does not turn on.	<p>Not plugged in.</p> <p>Power outlet not functioning.</p> <p>Overheat protection activated.</p> <p>Anti-tip protection activated.</p>	<p>Ensure the heater is securely plugged into a working 120V AC outlet.</p> <p>Check the circuit breaker or try a different outlet.</p> <p>Unplug the heater, wait 10 minutes for it to cool down, then plug it back in.</p> <p>Ensure the heater is upright and on a stable surface.</p>
Heater produces insufficient heat.	<p>Low power setting selected.</p> <p>Thermostat set too low.</p> <p>Room size exceeds heating capacity.</p>	<p>Select "Full power" mode.</p> <p>Increase the temperature setting using the thermostat knob.</p> <p>This heater is designed for spaces up to 150 sq ft. For larger rooms, supplemental heating may be required.</p>
Heater makes unusual noises.	<p>Normal expansion/contraction sounds.</p> <p>Foreign object inside.</p>	<p>Minor clicking or crackling sounds are normal as the metal heats and cools.</p> <p>Unplug the heater and inspect for any obstructions. Do not attempt to disassemble.</p>

SPECIFICATIONS

Feature	Detail
Brand	Eueiriup
Model Number	HKWH002-800W
Power Output	800W
Voltage	120V
Heating Technology	Aluminum Convection
Coverage Area	Up to 150 Sq Ft
Dimensions (D x W x H)	3.54" x 15.83" x 22.24"
Item Weight	20.6 pounds
Safety Features	Overheat Protection, Anti-tip Protection, V0 Flame Retardant Materials, IPX4 Waterproof Rating
Installation Options	Wall Mount, Freestanding (with wheels)

Our



All Aluminum



Non-Liquid



Non-Air Blower

Other



Non Aluminum



Containing Liquid



Contains Fan

Image: A comparison chart highlighting the Eueirup heater's construction: "All Aluminum," "Non-Liquid," and "Non-Air Blower," contrasting it with typical "Other" heaters that may be "Non Aluminum," "Containing Liquid," or "Contains Fan."



Image: An illustration of the heater's safety mechanisms, including tip-over protection, overheat protection, and a child lock feature, ensuring safe operation even while sleeping.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Eueiriup customer service. Refer to your purchase documentation for specific warranty terms.

Contact Information: Please refer to the contact details provided with your product packaging or visit the official Eueiriup website.



