

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PHOINIKAS](#) /

› [PHOINIKAS H3 Wired Gaming Headset User Manual](#)

PHOINIKAS H3

PHOINIKAS H3 Wired Gaming Headset User Manual

Model: H3





Image 1.0: PHOENIKAS H3 Wired Gaming Headset. This image displays the PHOENIKAS H3 headset, featuring its black and red design, over-ear cups, adjustable microphone, and the inline control unit with its 3.5mm and USB connectors.

1. INTRODUCTION

The PHOENIKAS H3 Gaming Headset is a wired over-ear headset designed for an immersive gaming experience across multiple platforms. It features a noise-cancelling microphone, 50mm drivers for 3D stereo surround sound, and an ergonomic design for extended comfort. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your headset.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing. If any items are missing or damaged, contact customer support.

- PHOINIKAS H3 Gaming Headset
- Product Manual (this document)
- 3.5mm Y-Splitter Cable

3. SETUP AND CONNECTIVITY

The PHOINIKAS H3 headset is compatible with various devices. Ensure your device has a 3.5mm audio jack. For devices with separate audio and microphone ports, use the included 3.5mm Y-splitter. The USB plug is solely for powering the LED lights.



Image 3.1: Multi-Platform Compatibility. This diagram illustrates how to connect the PHOINIKAS H3 headset to various gaming platforms and devices. It shows direct 3.5mm jack connection for PC/Laptop, PS5/PS4/PS4 Slim/PS4 Pro/Switch, and Cell Phone/Tablet. For Xbox One/Xbox One S, a Microsoft adapter (not included) may be required for full functionality.

3.1 Connecting to PC/Laptop

1. Connect the 3.5mm audio jack (green plug) to your computer's audio output port.

2. Connect the 3.5mm microphone jack (pink plug) to your computer's microphone input port. If your PC has a single 3.5mm combo jack, use the included Y-splitter.
3. Plug the USB connector into an available USB port on your PC for the LED lighting.
4. Adjust sound settings in your operating system to select the headset as the default audio input and output device.

3.2 Connecting to PlayStation (PS4/PS5)

1. Insert the 3.5mm jack into the controller's headset port.
2. Go to System Settings > Devices > Audio Devices.
3. Select "Headset Connected to Controller" for "Input Device" and "Output Device".
4. Set "Output to Headphones" to "All Audio".

3.3 Connecting to Xbox One/Xbox Series X|S

1. For Xbox One controllers with a 3.5mm jack, directly plug the headset's 3.5mm jack into the controller.
2. For older Xbox One controllers without a 3.5mm jack, a Microsoft Stereo Headset Adapter (not included) is required.
3. Adjust audio settings via the Xbox Guide: Press the Xbox button, navigate to System > Audio.

3.4 Connecting to Nintendo Switch

1. Plug the 3.5mm jack directly into the Nintendo Switch console's audio port.
2. Ensure the volume is adjusted on both the headset's inline control and the Switch console.

3.5 Connecting to Mobile Devices/Tablets

1. Insert the 3.5mm jack into your mobile device's audio port.
2. If your device lacks a 3.5mm port, an appropriate adapter (e.g., USB-C to 3.5mm) may be required (not included).

4. OPERATING INSTRUCTIONS

Familiarize yourself with the headset's controls for optimal use.



Image 4.1: Headset Components and Controls. This image details the various parts of the PHONIKAS H3 headset, including the adjustable headband (Telescopic regulation), the flexible microphone, and the inline control unit with volume wheel and microphone mute switch. It also shows the USB plug for LED power and the 3.5mm audio jack.

4.1 Volume Control

- The headset features an inline volume control wheel located on the cable.
- Rotate the wheel upwards to increase volume and downwards to decrease volume.

4.2 Microphone Usage

- The headset is equipped with a 120° adjustable, noise-cancelling boom microphone.
- To activate or deactivate the microphone, use the mute switch on the inline control. Slide it to the appropriate position.
- Position the microphone approximately 1-2 inches from your mouth for optimal voice clarity.

NOISE CANCELLATION MICROPHONE

Better pick up your voice and communicate it to your partner



Before

After

120°

Adjustable Mic



Image 4.2: Noise Cancellation Microphone. This image demonstrates the noise-cancelling capabilities of the headset's microphone, showing a clearer sound wave after processing. The microphone is also shown to be adjustable by 120 degrees for user comfort and optimal positioning.

4.3 LED Lighting

- The headset features LED lights on the earcups, powered by the USB connection.
- There is a dedicated LED on/off switch on the inline control. Use this switch to toggle the lights according to your preference.

4.4 Ergonomic Design and Comfort

- The adjustable headband allows for a customized fit for various head sizes.
- Soft, breathable protein earmuffs and a comfortable head beam are designed for extended wear without discomfort.

ERGONOMIC DESIGN

FULLY COMFORTABLE & LONG-TIME WEARING



Image 4.3: Ergonomic Design. This image showcases the ergonomic features of the PHOENIKAS H3 headset, including the adjustable headband for a custom fit, breathable earmuffs for comfort during long gaming sessions, and a padded head beam to reduce pressure.

5. MAINTENANCE

Proper care and maintenance will extend the lifespan of your PHOENIKAS H3 headset.

- **Cleaning:** Use a soft, dry cloth to wipe down the headset. For earcups, a slightly damp cloth with mild soap can be used, but ensure no moisture enters the speaker grilles.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the headset.
- **Cable Care:** Avoid sharp bends or excessive pulling on the cables. Coil them loosely when not in use.
- **Microphone:** Handle the adjustable microphone gently. Avoid forcing it beyond its intended range of motion.

6. TROUBLESHOOTING

If you encounter issues with your PHOINIKAS H3 headset, refer to the following common solutions.

6.1 No Sound from Headset

- Ensure the 3.5mm audio jack is fully inserted into the device.
- Check the inline volume control on the headset cable and ensure it is turned up.
- Verify that the headset is selected as the default audio output device in your device's sound settings.
- Test the headset with another device to rule out a device-specific issue.

6.2 Microphone Not Working

- Ensure the microphone mute switch on the inline control is in the "unmuted" position.
- Verify the 3.5mm microphone jack (pink plug) is correctly inserted into the microphone input port on your PC, or that the Y-splitter is correctly used for combo jacks.
- Check your device's sound settings to ensure the headset microphone is selected as the default input device and that its input volume is not set to zero.
- For Xbox One, ensure a Microsoft Stereo Headset Adapter is used if your controller lacks a 3.5mm jack, and check audio settings in the Xbox Guide.
- Test the microphone with another application or device to confirm functionality.

6.3 LED Lights Not Working

- Ensure the USB plug is securely connected to a powered USB port.
- Check the LED on/off switch on the inline control to ensure it is in the "on" position.
- Try plugging the USB into a different USB port.

7. SPECIFICATIONS

Feature	Detail
Brand	PHOINIKAS
Model Name	H3
Connectivity Technology	Wired (3.5mm Jack, USB for LED)
Driver Diameter	50mm
Impedance	32 Ohms
Microphone Type	Noise-Cancelling, 120° Adjustable Boom Mic
Ear Placement	Over-Ear (Circum-Aural)
Material	Plastic, Protein Leather Earmuffs
Weight	350 Grams
Special Features	Adjustable Headband, LED Light (USB powered), Inline Volume Control, Microphone Mute

Feature	Detail
Compatible Devices	Nintendo Switch, PC, PS4, Xbox One, Laptop, Mobile Devices



Image 7.1: 3D Stereo Surround Sound. This image provides an internal view of the 50mm audio driver, emphasizing its role in delivering 3D stereo surround sound for an enhanced gaming audio experience.

8. WARRANTY AND SUPPORT

Warranty Information: Specific warranty details for the PHOENIKAS H3 Gaming Headset are not provided in this manual. Please refer to the retailer's return policy or the manufacturer's official website for warranty terms and conditions.

Customer Support: For further assistance, technical support, or inquiries regarding your PHOENIKAS H3 headset, please contact the retailer where the product was purchased or visit the official PHOENIKAS website for contact information.

