

HDLXAEPEA-WHITE

2500W Handheld High-Temperature Pressurized Steam Cleaner User Manual

Model: HDLXAEPEA-WHITE | Brand: Generic

1. INTRODUCTION

Thank you for choosing the Generic 2500W Handheld High-Temperature Pressurized Steam Cleaner. This powerful and versatile appliance is designed for deep cleaning various surfaces using high-temperature, high-pressure steam, effectively removing dirt, grease, and grime without the need for harsh chemicals. Please read this manual thoroughly before operation to ensure safe and efficient use of your steam cleaner.



Image 1.1: The 2500W Handheld High-Temperature Pressurized Steam Cleaner, showcasing the main unit, steam gun, and various brush heads.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the steam cleaner is unplugged from the power outlet before filling with water, cleaning, or performing any maintenance.
- Do not direct steam at people, pets, or electrical appliances. Steam is extremely hot and can cause severe burns.
- Use only clean tap water in the water tank. Do not add any cleaning solutions, detergents, or chemicals to the water tank, as this can damage the unit and void the warranty.
- Keep children and pets away from the appliance during operation.
- Do not immerse the steam cleaner in water or any other liquid.
- Ensure the power cord is not damaged. Do not operate the appliance with a damaged cord or plug.
- The appliance features anti-dry protection and automatic temperature control reset for safety. However, always monitor the water level during use.

- Allow the unit to cool down completely before storing.

3. PRODUCT COMPONENTS

Your steam cleaner comes with several components designed for various cleaning tasks:

- **Main Unit:** Contains the heating element, water tank, and controls.
- **Steam Gun:** Handheld nozzle for directing steam.
- **Steam Hose:** Connects the main unit to the steam gun, designed to be double-layered and anti-tangling for high-pressure use.
- **Nozzle:** A long, angled nozzle for reaching tight spaces.
- **Brush Heads:** Includes various brush heads (e.g., stiff brush, soft brush) for different surfaces and cleaning needs.

SIZE



Image 3.1: Overview of the steam cleaner and its included accessories, including the main unit, steam gun, hose, and multiple brush heads.



Non-slip handle

Ergonomic design
Small and flexible
Easy to control

Double-layer steam hose

High-pressure hose
Anti-tangling




Image 3.2: Detailed view of the interchangeable gun heads and the independent spray gun, highlighting the non-slip handle and double-layer steam hose.

4. SETUP

Follow these steps to set up your steam cleaner for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Place:** Position the main unit on a stable, flat, and heat-resistant surface.
3. **Fill Water Tank:** Ensure the unit is unplugged. Open the water tank cap and fill the tank with clean tap water. The large capacity glass water tank allows for sustainable operation. Do not overfill. The water tank capacity is 1L (33.82 OZ).



Equipped with a variety of gun heads

Flexibly select gun head installation according to the cleaning scenario



Independent spray gun

Spray gun + adjustable nozzle

Image 4.1: Demonstrates filling the large capacity glass water tank, which supports up to 1 hour of continuous operation.

4. **Attach Hose and Gun:** Securely connect the steam hose to the main unit and the steam gun. Ensure all connections are tight to prevent steam leaks.
5. **Select Accessory:** Choose the appropriate nozzle or brush head for your cleaning task and attach it firmly to the steam gun.

5. OPERATING INSTRUCTIONS

Once set up, follow these steps to operate your steam cleaner:

1. **Power On:** Plug the power cord into a grounded electrical outlet. Turn on the main power switch. The indicator light will illuminate.
2. **Heating:** The unit will begin to heat the water. The 2500W motor ensures quick heating, reaching high-temperature steam in a short time.
3. **Steam Generation:** Once the desired temperature is reached (approximately 100°C), the unit is ready to produce steam.
4. **Cleaning:** Direct the steam gun towards the surface you wish to clean. Press the steam trigger on

the gun to release steam. Move the nozzle slowly over the surface, allowing the high-pressure steam to penetrate and loosen dirt and grime.




Image 5.1: The steam cleaner in action, effectively cleaning a kitchen range hood with high-temperature steam.

5. **Versatile Cleaning:** This steam cleaner is suitable for various surfaces including kitchen range hoods, air conditioners, sofas, carpets, floors, and bathrooms.
6. **Wipe Clean:** After steaming, wipe the treated surface with a clean cloth to remove loosened dirt and moisture.

Large capacity glass water tank
Sustainable operation for 1 hour



Image 5.2: Before and after images demonstrating the effective cleaning power of the steam cleaner on a range hood and a stovetop.

7. **Refilling:** If the water level becomes low, turn off and unplug the unit, allow it to cool slightly, and then refill the water tank.
8. **Shut Down:** When finished, turn off the main power switch and unplug the unit from the outlet.

6. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your steam cleaner:

- **Draining Water:** After each use, allow the unit to cool completely. Carefully drain any remaining water from the tank.
- **Cleaning Accessories:** Clean the nozzles and brush heads after each use. Remove any debris or residue.
- **Exterior Cleaning:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or solvents.
- **Descaling (if necessary):** If you notice reduced steam output or mineral buildup, descaling may be

required. Consult the manufacturer for specific descaling instructions, as improper methods can damage the unit.

- **Storage:** Store the steam cleaner and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the hose is not kinked during storage.

7. TROUBLESHOOTING

If you encounter issues with your steam cleaner, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|--------------------------------|--|--|
| No steam output | Unit not plugged in; Power switch off; No water in tank; Unit not heated sufficiently; Blocked nozzle. | Check power connection; Turn on power switch; Fill water tank; Allow unit to heat up; Clean or unblock nozzle. |
| Low steam pressure | Low water level; Mineral buildup; Nozzle partially blocked. | Refill water tank; Perform descaling (if applicable); Clean nozzle. |
| Water leaking from connections | Connections not tight; Damaged O-rings. | Ensure all hose and accessory connections are securely tightened; Inspect O-rings for damage and replace if necessary. |
| Unit not turning on | No power; Faulty power cord/plug. | Check power outlet; Inspect power cord for damage. Do not use if damaged. |

If the problem persists after trying these solutions, please contact customer support.

8. TECHNICAL SPECIFICATIONS

| Feature | Specification |
|--------------------------------|--|
| Model Name | HDLXAEPEA-WHITE |
| Rated Power | 2500W |
| Steam Pressure | 3 BAR |
| Water Tank Capacity | 1L (33.82 OZ) |
| Steam Hose Length | 2.2m |
| Housing Material | Plastic (Flame retardant, heat-insulating, non-conductive) |
| Color | White |
| Product Dimensions (L x W x H) | 19cm x 15cm x 13cm (7.48 x 5.91 x 5.51 inches) |

| Feature | Specification |
|-------------|--------------------------|
| Item Weight | 1602 Grams (3.53 pounds) |



Image 8.1: Dimensional diagram of the steam cleaner, illustrating its compact size.

9. WARRANTY AND SUPPORT

This product is manufactured by Generic. Specific warranty information is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product packaging or contact the seller directly through your purchase platform.

For general inquiries or assistance, you may also visit the manufacturer's official website or contact their customer service department if contact information is available on the product or packaging.

