

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [OLEVS](#) /

› [OLEVS Men's Stainless Steel Chronograph Quartz Watch Instruction Manual](#)

OLEVS OUW-S-G2856GH-HH

OLEVS Men's Stainless Steel Chronograph Quartz Watch Instruction Manual

Model: OUW-S-G2856GH-HH

INTRODUCTION

Thank you for choosing the OLEVS Men's Stainless Steel Chronograph Quartz Watch. This manual provides essential information for setting up, operating, and maintaining your watch to ensure optimal performance and longevity. Please read these instructions carefully before using your watch.



Image: OLEVS Men's Stainless Steel Chronograph Watch, featuring a black dial with gold accents and a stainless steel band.

SETUP

Time and Date Adjustment

1. **Pull out the stem to position "2"** (the outermost position).
2. **Turn the stem clockwise** to set the correct time.
3. **Push the stem back to position "1"** (the middle position) to set the date. Turn the stem to adjust the date.
4. **Push the stem completely back in** to position "0" (normal operating position).
5. **Note:** The moon phase display will automatically adjust with the 24-hour cycle.

Chronograph Function

Your watch is equipped with a chronograph for measuring elapsed time.

1. **Press pusher "A"** (top button) to start timing.
2. **Press pusher "A" again** to stop timing.
3. **Press pusher "B"** (bottom button) to reset the chronograph to zero.



Image: Detailed diagram illustrating the stem positions for time setting and the functions of pushers A and B for chronograph operation.

Bracelet Adjustment

The stainless steel bracelet can be adjusted for a comfortable fit. It is recommended to have a professional jeweler adjust the links to prevent damage to the watch or bracelet.

OPERATING YOUR WATCH

Timekeeping

This watch utilizes a precision quartz movement, ensuring accurate and reliable timekeeping. Once set, the watch will maintain time without further adjustment unless the battery needs replacement or time zone changes occur.

Water Resistance

The watch is water resistant to 30 meters (3 ATM). This rating means it is suitable for daily use, such as splashes, rain, or accidental short immersion in water. It is **not suitable** for bathing, swimming, diving, or any water-related work where prolonged immersion or high water pressure is involved. Ensure the crown is fully pushed in before any contact with water.



Image: Visual representation of the watch's 30M water resistance, high hardness coated mirror, stainless steel material, and luminous hands/markers.

Luminous Display

The watch hands and markers feature a luminous coating, allowing for readability in low-light conditions after exposure to light.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and dirt. For the stainless steel band, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Chemicals:** Do not expose the watch to harsh chemicals, solvents, or detergents, as these can damage the case, band, or seals.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect the movement and water resistance.
- **Shocks:** Protect the watch from strong impacts or shocks, which can damage internal components.
- **Battery Replacement:** The quartz movement is powered by a battery. When the watch stops or the second hand skips, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.
- **Storage:** When not in use, store your watch in a dry, cool place, preferably in its original box or a watch case to protect it from dust and scratches.

TROUBLESHOOTING

- **Watch Not Running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect Time:** Ensure the crown is fully pushed in after setting the time. If the time is consistently incorrect, the watch may require servicing.
- **Water Condensation:** If condensation appears inside the watch, it indicates a breach in the water resistance. Seek professional servicing immediately to prevent further damage.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	OLEVS
Model	OUW-S-G2856GH-HH
Movement	Quartz Movement
Case Material	Stainless Steel
Strap Material	Stainless Steel
Water Resistance	30M (3 ATM)
Case Diameter	42 mm (1.65 inches)
Case Thickness	11.5 mm (0.45 inches)
Strap Length	22 cm (8.67 inches)
Weight	129g (4.55 oz)



Image: Detailed parameter table outlining the watch's dimensions, materials, and other technical specifications.

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: This video showcases the OLEVS Men's Stainless Steel Chronograph Watch, highlighting its design, features, and wearability.

WARRANTY AND CUSTOMER SUPPORT

OLEVS provides the following:

- **30-Day Money-Back Guarantee:** If you are not satisfied with your purchase, you may return it within 30 days for a full refund.
- **12-Month Warranty:** Your watch is covered by a 12-month warranty against manufacturing defects from the date of purchase. This warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.
- **Customer Service:** For any questions, concerns, or warranty claims, please contact the seller directly through your purchase platform.