

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TALOYA](#) /

› [TALOYA 52-inch Ceiling Fan with Lights and Remote Control: User Manual](#)

TALOYA 9013

TALOYA 52-inch Ceiling Fan with Lights and Remote Control: User Manual

Model: 9013

Brand: TALOYA

1. SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to do so could lead to electric shock, fire, or serious injury.

- Always disconnect power at the main circuit breaker before installation or maintenance.
- All electrical connections must be in accordance with local codes, ordinances, or national electrical codes. If you are unfamiliar with electrical wiring, consult a qualified electrician.
- The mounting structure must be capable of supporting the weight of the fan (approximately 14.1 lbs).
- Ensure the fan blades are at least 7 feet (2.1 meters) from the floor and at least 18 inches (0.45 meters) from any wall or obstruction.
- Do not operate the fan with damaged blades. Replace all blades if any are damaged.
- Do not insert objects into the path of the fan blades.

2. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not attempt to install the product. Contact customer service for assistance.

- Ceiling Fan Motor Assembly
- Fan Blades (3x)
- Integrated LED Light Kit
- Remote Control (requires 2 AAA batteries, not included)
- Mounting Bracket
- Hardware Pack (screws, wire nuts, etc.)
- Instruction Manual

TALOYA Quiet Ceiling Fan

- Reversible DC Motor
- Adjustable 3-Color Temperature
- 6-Speed Adjustable
- 1/2/4-Hour Timer Settings
- Ultra Quiet(Buzzer Switch)
- Ultra-Low Profile(8.67 inches)



Image: Unboxing the TALOYA Ceiling Fan, showing the protective packaging and main components.

3. SPECIFICATIONS

Brand	TALOYA
Model Number	9013
Dimensions	52"L x 52"W x 8.67"H
Material	Plastic (Blades), Metal (Motor Housing)
Color	Black Walnut Wood Grain
Power Source	Corded Electric
Voltage	120 Volts (AC)
Wattage	50 Watt-hours
Fan Speeds	6 (Adjustable via Remote)
Light Color Temperatures	3 (3000K Warm, 4000K Neutral, 5000K Cool)
Timer Settings	1H, 2H, 4H
Noise Level	Less than 30dB
Motor Type	Reversible DC Motor
Usage Environment	Indoor or Covered Outdoor Use

DIMENSIONS



Image: Detailed dimensions of the TALOYA 52-inch Ceiling Fan.

4. SETUP AND INSTALLATION

4.1 Pre-Installation

- Ensure power is OFF at the circuit breaker.
- Gather necessary tools: screwdriver, wire strippers, ladder, safety glasses.

4.2 Fan Assembly

1. Attach the fan blades to the motor housing using the provided screws. Ensure they are securely fastened.
2. Connect the internal wiring as per the wiring diagram in the detailed manual.

6-Speed Adjustable

1-2 Speed
Low Wind
Ideal for Sleep



3-4 Speed
Medium Wind
Suitable for Family Enjoyment



5-6 Speed
High Wind
Perfect for Cooling in the Summer



Image: Assembly of fan blades to the motor unit.

4.3 Mounting to Ceiling

1. Secure the mounting bracket to the ceiling junction box. Ensure it is firmly attached and can support the fan's weight.
2. Carefully lift the fan assembly and connect the electrical wires from the ceiling to the fan's wiring. Use wire nuts to secure connections (Live, Neutral, Ground).
3. Tuck all wires neatly into the junction box and attach the canopy to the mounting bracket.

Ultra Quiet with Buzzer Switch (<30dB)



Image: Electrical wiring connections during installation.

4.4 Light Kit Installation

1. Connect the light kit wires to the corresponding wires from the fan motor.
2. Attach the LED light panel and light cover to the bottom of the fan assembly.

4.5 Remote Control Setup

- Insert 2 AAA batteries (not included) into the remote control.
- Pairing instructions may vary; refer to the specific remote control manual for pairing procedures if needed.



Image: Remote control for the TALOYA Ceiling Fan.

4.6 Installation Video

For a visual guide on the installation process, please refer to the official installation video provided by the seller:

Your browser does not support the video tag.

Video: Installation guide for the TALOYA Ceiling Fan, demonstrating assembly and mounting steps.

5. OPERATING INSTRUCTIONS

The TALOYA Ceiling Fan is operated using the included remote control. Ensure the remote has fresh AAA batteries for optimal performance.

5.1 Fan Control

- **Power On/Off:** Press the power button on the remote to turn the fan on or off.
- **Fan Speed:** Use the '1' through '6' buttons to select desired fan speed. '1' is the lowest, '6' is the highest.
- **Reversible Motor (Summer/Winter Mode):** Press the forward/reverse button (often indicated by circular arrows) to change the direction of blade rotation.
 - **Summer Mode (Downdraft):** Blades rotate counter-clockwise, pushing air down to create a cooling breeze.

- **Winter Mode (Updraft):** Blades rotate clockwise, drawing air up to circulate warm air evenly.
- **Timer Function:** Press the '1H', '2H', or '4H' buttons to set the fan to automatically turn off after 1, 2, or 4 hours, respectively.
- **Beep Silence:** The remote includes a button to silence the operational beeps for a quieter experience.



Image: Reversible DC Motor functionality for year-round comfort.

5.2 Light Control

- **Light On/Off:** Press the light bulb icon button to turn the integrated LED light on or off.
- **Color Temperature Adjustment:** Use the dedicated buttons (often sun icons or temperature symbols) to cycle through the three available color temperatures: 3000K (Warm Light), 4000K (Neutral Light), and 5000K (Cool Light).
- **Brightness Adjustment:** Use the dimmer buttons (often '+' and '-' symbols) to increase or decrease the light brightness.
- **Memory Function:** The light features a color temperature memory function, which recalls your last selected setting when turned back on.

3 Color Temperature



Warm Light



Neutral Light



Cool Light

Light Power: 15W

Brightness: 1500LM

Light Size: 6.7inch

Image: Adjustable 3-Color Temperature options for the integrated LED light.

6. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- Light Cover:** The light cover can be removed for cleaning if necessary. Ensure the fan is off and cool before handling.
- Tighten Fasteners:** Periodically check all screws and fasteners on the fan and mounting bracket to ensure they are secure.
- Motor:** The DC motor is designed for maintenance-free operation and does not require lubrication.

7. TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

- Fan does not start:**
 - Check that the power is supplied to the fan.
 - Ensure all electrical connections are secure.
 - Verify remote control batteries are correctly installed and not depleted.

- **Light does not work:**

- Check the light switch on the remote.
- Ensure the light kit wiring is properly connected.

- **Fan wobbles:**

- Ensure all blade screws are tightened.
- Check that the mounting bracket is securely fastened to the ceiling.
- Verify that the fan is balanced. (Balancing kits are often available separately if needed).

- **Excessive noise:**

- Ensure all screws are tight.
- Check for any loose parts or obstructions.
- The DC motor is designed for quiet operation (under 30dB); unusual noise may indicate an issue.

- **Remote control not responding:**

- Replace remote control batteries.
- Ensure there are no obstructions between the remote and the fan receiver.
- Re-pair the remote control if necessary (refer to specific remote instructions).

8. WARRANTY AND SUPPORT

For warranty information or technical support, please contact TALOYA customer service. Keep your purchase receipt as proof of purchase.

Visit the [TALOYA Store](#) for more products and information.