

[Manuals.plus](#) /

› [Panana](#) /

› Panana 850W Personal Blender and Grinder Combo (Model PB-2110) Instruction Manual

Panana PB-2110

Panana 850W Personal Blender and Grinder Combo

Model: PB-2110

INTRODUCTION

Thank you for choosing the Panana 850W Personal Blender and Grinder Combo. This versatile appliance is designed for efficient blending of fruits, vegetables, and ice, as well as grinding coffee beans and spices. Please read this manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not immerse the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always operate the blender with the cup and blade assembly securely in place.
- Do not blend hot liquids, as this may create pressure and cause the cup to burst.
- Do not overfill the blending cups.

PRODUCT OVERVIEW

The Panana 850W Personal Blender and Grinder Combo includes a powerful motor base, blending cups, and blade assemblies for various tasks.

Multifunctional mixer

MILKSHAKES, SMOOTHIES, FRUIT CRUSHES,
FROZEN DRINKS AND ICE CREAM GRINDING

 **Pure copper motor**

 **850W power**

 **Press control**

 **Easy to clean**



Image: Main components of the Panana Personal Blender. This includes the motor base, two portable blending cups with lids, and two types of blade assemblies: a six-edge blade for blending and a flat blade for grinding.

Package Contents

- 1 x Motor Base (850W)
- 2 x Portable 20oz (600ml) Smoothie Cups with To-Go Lids
- 1 x 7.5oz (220ml) Coffee Grinder Cup
- 1 x Six-Edge Blade Assembly (for blending)
- 1 x Flat Blade Assembly (for grinding)

SETUP

Before first use, wash all parts that will come into contact with food (cups, lids, blade assemblies) in warm, soapy water. Rinse thoroughly and dry. Ensure the motor base is unplugged from the power outlet.

Assembly Steps:

1. Place the motor base on a clean, dry, and stable surface.
2. Fill your chosen blending cup with ingredients. Do not exceed the MAX fill line.
3. Select the appropriate blade assembly (six-edge for blending, flat for grinding).
4. Screw the blade assembly firmly onto the open end of the cup until it is tightly sealed.
5. Invert the cup and blade assembly, then align the tabs on the blade assembly with the slots on the motor base.
6. Press the cup down onto the motor base and twist clockwise to lock it into place.

OPERATING INSTRUCTIONS

The Panana Personal Blender features simple press control for operation.

Blending (for Smoothies, Juices, etc.):

1. Prepare your ingredients. For best results, cut solid ingredients into small pieces (approx. 1 inch).
2. Add liquids first, then soft ingredients, followed by harder ingredients and ice. Do not exceed the MAX fill line.
3. Attach the six-edge blade assembly to the blending cup and secure it onto the motor base as described in the Setup section.
4. Plug the blender into a power outlet.
5. Press down on the cup to start blending. For continuous blending, press down and twist clockwise to lock. For pulse blending, press down and release repeatedly.
6. Blend until desired consistency is reached. Do not operate continuously for more than 1 minute to prevent overheating. Allow the motor to cool for 10-15 minutes between cycles if blending for longer periods.
7. Once blending is complete, release pressure or twist counter-clockwise to unlock and stop the motor. Unplug the appliance.
8. Remove the cup from the motor base, unscrew the blade assembly, and attach a to-go lid if desired.

Very simple operation

Press the cup down to start the work
Mix food and grind



Image: Demonstrates the simple operation of pressing the cup down onto the motor base to activate blending. The cup is filled with fruits and ice, ready for smoothie preparation.

Full release

Fruit and vegetable nutrition

Juices/smoothies/smoothies and other watery ingredients



Six pages
Phillips screwdriver

Image: A blending cup filled with various fruits and vegetables, highlighting the six-edge blade assembly used for processing these ingredients into juices or smoothies.

Grinding (for Coffee Beans, Spices, Nuts):

1. Use the smaller 7.5oz coffee grinder cup for grinding tasks.
2. Fill the grinder cup with dry ingredients such as coffee beans, spices, or nuts. Do not overfill.
3. Attach the flat blade assembly to the grinder cup and secure it onto the motor base.
4. Plug the blender into a power outlet.
5. Press down on the cup to start grinding. Use short pulses for better control over the consistency.
6. Grind until desired consistency is reached. Do not operate continuously for more than 30 seconds.
7. Once grinding is complete, release pressure and unplug the appliance.
8. Remove the cup from the motor base and carefully unscrew the blade assembly.



Safty Pulse Technology

Press the cup to start blending or grinding.



coffee beans



spices



nuts

Flat blade knife

Dry Grinding, for coffee beans,



Image: The blender base with a cup attached, grinding coffee beans. The image also shows examples of ingredients suitable for grinding, such as coffee beans, spices, and nuts, along with the flat blade assembly.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your Panana Personal Blender.

Cleaning Steps:

1. Always unplug the motor base before cleaning.
2. **Self-Cleaning (for cups and blades):** Add warm water and a drop of dish soap to the blending cup. Attach the blade assembly and secure it to the motor base. Run the blender for a few seconds. Rinse thoroughly.
3. **Manual Cleaning:** Detach the blade assembly from the cup. Wash the cups, lids, and blade assemblies with warm, soapy water. Use a brush to clean around the blades carefully. All detachable parts are dishwasher safe.
4. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
5. Dry all parts thoroughly before storing.

Easy to Clean & Disassemble



flushable



Clean with Brush



Self Cleaning



Removable Blade

Image: Visual guide for cleaning the blender components. It shows flushing the blade assembly under water, using a brush for detailed cleaning, the concept of self-cleaning by blending water, and the removable nature of the blade for thorough washing.

TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; cup not assembled correctly.	Ensure power cord is securely plugged in. Verify cup and blade assembly are locked onto the motor base.
Ingredients are not blending smoothly.	Too little liquid; ingredients too large; overfilled cup.	Add more liquid. Cut ingredients into smaller pieces. Do not exceed the MAX fill line. Use pulse function to break up larger pieces.
Leakage from the cup.	Blade assembly not tightened; damaged seal.	Ensure the blade assembly is screwed on tightly to the cup. Check the rubber gasket/seal for damage and ensure it is properly seated.

Problem	Possible Cause	Solution
Motor stops during operation.	Overheating protection activated.	Unplug the blender and allow the motor to cool down for at least 10-15 minutes before resuming use. Reduce load for next use.

SPECIFICATIONS

Feature	Detail
Brand	Panana
Model Number	PB-2110
Power	850 Watts
Capacity (Smoothie Cups)	2 x 20 oz (600 ml)
Capacity (Grinder Cup)	1 x 7.5 oz (220 ml)
Material	Stainless Steel, Acrylonitrile Butadiene Styrene (BPA-Free)
Blade Material	Stainless Steel
Controls Type	Push Button
Product Dimensions	11D x 11W x 30H Centimetres
Dishwasher Safe Parts	Yes (cups, lids, blade assemblies)
UPC	710917409208

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Panana customer service directly. Keep your proof of purchase for any warranty claims.