

[Manuals.plus](#) /

> [Xiaomi](#) /

> [Xiaomi Redmi 14C 4G LTE Smartphone User Manual](#)

Xiaomi

Xiaomi Redmi 14C 4G LTE User Manual

Model: 14C

INTRODUCTION

Welcome to the user manual for your new Xiaomi Redmi 14C 4G LTE smartphone. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. The Redmi 14C features a rounded design aesthetic, a 6.88-inch cinema-view display, a 50MP ultra-clear AI dual camera system, and a powerful 5160mAh battery, designed to enhance your mobile experience.



Figure 1: Xiaomi Redmi 14C in Sage Green, showcasing its front display and rear camera module.

SETUP

1. What's in the Box

- Xiaomi Redmi 14C Smartphone
- 18W Wall Charger
- USB Type-C Cable
- SIM Eject Tool
- Phone Case

2. Inserting SIM Cards and MicroSD Card

The Redmi 14C supports Dual Nano SIM cards and one MicroSD card. Locate the SIM tray on the side of the device. Use the provided SIM eject tool to open the tray. Carefully place your Nano SIM cards and MicroSD card into their respective slots, ensuring correct orientation. Gently push the tray back into the device until it clicks into place.

3. Initial Charging and Power On

Before first use, it is recommended to fully charge your device. Connect the 18W wall charger to the USB Type-C port on the phone. The device features a 5160mAh (typical) battery. Once sufficiently charged, press and hold the power button on the side of the phone until the Xiaomi logo appears. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

OPERATING YOUR DEVICE

1. Display Features

The Redmi 14C boasts an immersive 6.88-inch Dot Drop Display with a resolution of 1640x720 pixels (260 ppi). It offers a contrast ratio of 1500:1 and 8-bit color depth (16.7 million colors). The display supports a refresh rate of up to 120Hz and a touch sampling rate of up to 240Hz for smooth interactions. For eye comfort, it includes Reading mode, TÜV Rheinland Low Blue Light (Software Solution), TÜV Rheinland Flicker Free, and DC dimming.

2. Camera System

Capture stunning photos and videos with the 50MP ultra-clear AI dual camera system. The main camera features a 5P lens and f/1.8 aperture. Supported modes include filmCamera, HDR mode, Night mode, Portrait mode, 50MP mode, and Time-lapse. Rear camera video recording supports 1080P at 30fps and 720P at 30fps.

3. Performance and Storage

Powered by the MediaTek Helio G81-Ultra processor with a CPU frequency of up to 2.0GHz and Mali-G52 MC2 GPU, the device ensures smooth performance for daily tasks. It comes with 4GB of RAM and 128GB of internal storage, providing ample space for your applications and media.

4. Connectivity and Sensors

The Redmi 14C supports 4G LTE connectivity across various global bands (FDD: 1/3/5/7/8/20/28; TDD: 38/40/41) and Wi-Fi. It includes comprehensive navigation support with GPS, AGPS, GLONASS, Beidou, and Galileo. Essential sensors such as a proximity sensor, ambient light sensor, and accelerometer are integrated. A 3.5mm headphone jack is also available.

5. Security Features

For enhanced security, the device is equipped with a rear-mounted fingerprint sensor and AI face unlock

capabilities, allowing for quick and secure access to your phone.






Figure 2: Certification details for the Xiaomi Redmi 14C, including model number and FCC ID.

MAINTENANCE

1. Software Updates

Ensure your device's software is always up to date to benefit from the latest features, security patches, and performance improvements. You can check for updates in the 'Settings' menu under 'About phone' or 'System update'.

2. Battery Care

To prolong battery life, avoid exposing your phone to extreme temperatures. Use only the original charger and cable provided with your device. Avoid completely draining the battery frequently.

3. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials that could damage the finish or screen coating.

TROUBLESHOOTING

1. Device Not Responding

If your phone becomes unresponsive, press and hold the power button for approximately 10-15 seconds to force a restart.

2. Connectivity Issues

If you experience issues with Wi-Fi or cellular data, try toggling Airplane Mode on and off. For persistent cellular issues, ensure your SIM card is properly inserted and contact your network provider.

3. App Performance

If an application is not functioning correctly, try clearing its cache and data via 'Settings' > 'Apps' > [App Name] > 'Storage'. If the issue persists, consider uninstalling and reinstalling the app.

4. Factory Reset

As a last resort for severe software issues, you may perform a factory reset. **Warning: This will erase all data on your device.** Back up important data before proceeding. Navigate to 'Settings' > 'About phone' > 'Factory reset' and follow the instructions.

SPECIFICATIONS

Feature	Specification
Model Name	Redmi 14C
Operating System	Xiaomi HyperOS based on Android 14
Display Size	6.88 Inches
Display Resolution	1640 x 720
Processor	MediaTek Helio G81-Ultra (2 GHz CPU Speed)
RAM	4 GB
Storage Capacity	128 GB
Main Camera	50 MP AI Dual Camera
Battery Capacity	5160 Milliamp Hours (typical)
Charging	18W Fast Charging
Connectivity	Wi-Fi, Cellular (4G LTE)
Audio Jack	3.5 mm
Security	Rear Fingerprint Sensor, AI Face Unlock
Dimensions (Package)	7 x 4 x 2 inches
Item Weight	6 ounces

WARRANTY AND SUPPORT

Your Xiaomi Redmi 14C is covered by a manufacturer's warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Xiaomi website. For technical support, service, or further assistance, please contact Xiaomi customer service through their official channels. Keep your proof of purchase for warranty claims.