

[manuals.plus](#) /› [VECYS](#) /› [VECYS Bottom Loading Water Dispenser User Manual](#)

VECYS BY607WP

VECYS Bottom Loading Water Dispenser User Manual

Model: BY607WP

1. INTRODUCTION

Thank you for choosing the VECYS Bottom Loading Water Dispenser. This manual provides important information regarding the installation, operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and retain it for future reference.

This water dispenser is designed to provide hot, cold, and room temperature water from 3 or 5-gallon water bottles, featuring a convenient bottom-loading design, child safety lock, and a self-cleaning function.

2. SAFETY INFORMATION

WARNING: To reduce the risk of injury and property damage, you must read this entire guide before assembling, installing, and operating the dispenser.

- Always place the dispenser on a level surface.
- Do not operate the dispenser with a damaged power cord or plug.
- Ensure the dispenser is properly grounded.
- Keep the dispenser away from direct sunlight and heat sources.
- Do not immerse the dispenser, cord, or plug in water or other liquids.
- Unplug the dispenser before cleaning or performing any maintenance.
- The hot water faucet is equipped with a child safety lock. Always engage the lock when not in use to prevent accidental hot water dispensing.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PRODUCT OVERVIEW



Figure 3.1: Front view of the VECYS Bottom Loading Water Dispenser.




Figure 3.2: Side view of the VECYS Water Dispenser showing key features and dimensions (40.8in H x 14.2in W x 12.2in D).

Key Components:

- **Control Panel:** Features LED indicators for power, heating, and cooling status.
- **Dispensing Faucets:** Separate faucets for hot, room temperature, and cold water.
- **Child Safety Lock:** Located on the hot water faucet.
- **Drip Tray:** Removable for easy cleaning.
- **Bottom Loading Compartment:** Houses the 3 or 5-gallon water bottle.
- **Power Cord:** For electrical connection.

4. SETUP

4.1 Unpacking

- Carefully remove the dispenser from its packaging.
- Inspect the unit for any shipping damage. If damaged, do not operate and contact customer support.
- Remove all packaging materials, including any protective films or tapes.

4.2 Placement



Figure 4.1: The water dispenser can be placed in various indoor environments such as offices or homes.

- Place the dispenser on a hard, level surface that can support its weight when full.
- Ensure there is at least 4 inches of clearance from the back and sides of the dispenser to a wall to allow for proper ventilation.
- Avoid placing the dispenser in direct sunlight or near heat-generating appliances.
- Do not place the dispenser in an enclosed area or cabinet.

4.3 Water Bottle Installation (Bottom Loading)

1. Open the lower cabinet door of the dispenser.
2. Remove the cap from a new 3 or 5-gallon water bottle.
3. Insert the water intake tube (probe) into the opening of the water bottle. Ensure the tube reaches the bottom of the bottle.
4. Slide the water bottle into the lower cabinet.
5. Close the cabinet door securely.

4.4 Initial Priming and First Use

1. After installing the water bottle, plug the dispenser into a grounded electrical outlet.
2. Allow the dispenser to sit for at least 5 minutes before turning on the heating or cooling functions. This allows water to fill the internal reservoirs.
3. Dispense water from all three faucets (hot, room temperature, cold) until water flows steadily. This purges any air from the lines.
4. Turn on the hot and cold water switches located on the back of the unit (if applicable). The corresponding LED indicators on the front panel will illuminate.
5. Allow approximately 15-20 minutes for the water to reach optimal hot and cold temperatures before first use.

5. OPERATING INSTRUCTIONS

5.1 Dispensing Water




Figure 5.1: The dispenser offers hot, normal (room temperature), and cold water options.



Figure 5.2: Visual representation of hot water for beverages, fresh (room temperature) water, and cold water for refreshment.

- **Hot Water:** Push the child safety lock button inward, then press the hot water lever. Release the lever to stop dispensing.
- **Room Temperature Water:** Press the room temperature water lever. Release the lever to stop dispensing.
- **Cold Water:** Press the cold water lever. Release the lever to stop dispensing.

5.2 Child Safety Lock



Figure 5.3: The child safety lock (red button) and LED indicators for heating and chilling.

The hot water faucet is equipped with a two-step child safety lock. To dispense hot water, you must first push the red safety button inward and then press the hot water lever. This mechanism helps prevent accidental burns.

5.3 LED Indicators

The control panel features LED lights that indicate the status of the dispenser:

- **Power Indicator:** Illuminates when the unit is powered on.
- **Heating Indicator:** Illuminates when the hot water heating element is active.
- **Cooling Indicator:** Illuminates when the cold water cooling system is active.
- **Water Bottle Empty Indicator:** Illuminates when the water bottle in the bottom compartment is empty and needs replacement.

6. MAINTENANCE

6.1 Self-Clean Function

This dispenser features an interior UV light for a self-clean function. Refer to the specific instructions provided with your unit for activating this cycle. Regular use of the self-clean function helps maintain water quality and prevent bacterial growth.

6.2 External Cleaning

- Unplug the dispenser from the power outlet before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Remove and empty the drip tray regularly. Wash it with mild soap and water, then rinse thoroughly and dry before reinserting.

6.3 Draining the Unit

If the dispenser will not be used for an extended period or needs to be moved, it should be drained:

1. Unplug the dispenser and remove the water bottle.
2. Place a bucket under the drain plug located at the back of the unit.
3. Remove the drain plug to allow all water to empty from the reservoirs.
4. Once drained, replace the drain plug securely.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No water dispensing	Water bottle empty or not properly installed. Air lock in system.	Replace water bottle. Ensure intake tube is fully inserted. Dispense from all faucets to clear air.
No hot water	Hot water switch off. Heating element malfunction.	Ensure hot water switch on back is ON. Allow time for heating. If problem persists, contact support.
No cold water	Cold water switch off. Cooling system malfunction.	Ensure cold water switch on back is ON. Allow time for cooling. If problem persists, contact support.
Water leaking	Water bottle cracked. Drain plug loose.	Check water bottle for cracks. Tighten drain plug.
Unusual noise	Compressor cycling (normal). Unit not level.	Ensure unit is on a level surface. If noise is excessive or continuous, contact support.

8. SPECIFICATIONS

Feature	Specification
Model Number	BY607WP
Brand	VECYS
Color	White
Material	Plastic, Stainless Steel
Capacity	3-5 Gallons (water bottle)

Feature	Specification
Product Dimensions	17.1"D x 14"W x 46.6"H
Wattage	500 watts
Installation Type	Freestanding
Access Location	Bottom
Number of Settings	3 (Hot, Room Temp, Cold)
Upper Temperature Rating	212 Degrees Fahrenheit (Hot)
Lower Temperature Rating	42 Degrees Fahrenheit (Cold)
Power Source	Corded Electric
Item Weight	38.9 pounds
Certifications	ETL Approved


9. WARRANTY AND SUPPORT

The VECYS Bottom Loading Water Dispenser (Model BY607WP) is backed by a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product's reliability under normal use.

For warranty claims, technical assistance, or any questions regarding your product, please contact VECYS customer support. Please have your model number (BY607WP) and proof of purchase available when contacting support.

© 2024 VECYS. All rights reserved.

Related Documents - BY607WP

	<p><u>VECYS BYCZ623 Water Dispenser Operation Manual</u></p> <p>Comprehensive operation manual for the VECYS BYCZ623 Water Dispenser, covering safety precautions, product introduction, operating instructions, troubleshooting, and technical specifications.</p>
---	---