



Manuals.plus /

› WELLFOR /

› WELLFOR 8-Inch Dual Head Shower System (Model 88044B) Instruction Manual

WELLFOR 88044B

WELLFOR 8-Inch Dual Head Shower System

Model: 88044B | Brand: WELLFOR

INTRODUCTION

This instruction manual provides detailed guidance for the installation, operation, and maintenance of your WELLFOR 8-Inch Dual Head Shower System. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your product. Keep this manual for future reference.



The WELLFOR 8-Inch Dual Head Shower System in Matte Black, featuring a rainfall shower head and a handheld shower.

SAFETY INFORMATION

- Always turn off the main water supply before beginning any installation or maintenance.
- If you are unsure about plumbing procedures, it is recommended to consult a qualified professional plumber.
- Wear appropriate safety gear, such as safety glasses, during installation.
- Ensure all connections are secure and watertight to prevent leaks.
- Do not use harsh chemicals or abrasive cleaners on the product finish, as this may cause damage.

PACKAGE CONTENTS

Verify that all components listed below are present and undamaged before proceeding with installation.



An overview of all components included in the WELLFOR 8-Inch Dual Head Shower System.

1. 8-Inch Shower Head
2. Decorate Cover (for shower head arm)
3. Shower Arm
4. Shower Valve and Trim Kit
5. Handheld Shower
6. Shower Hose
7. Shower Holder
8. Decorate Cover (for shower holder)
9. Accessories (screws, anchors, etc.)

SPECIFICATIONS

Feature	Detail
Brand	WELLFOR
Model Number	88044B
Color	Matte Black
Finish Type	Matte
Number of Handles	1
Handle Material	Stainless Steel
Mounting Type	Wall Mount
Rainfall Shower Head Size	8 inches
Hand Shower Size	5 inches
Shower Hose Length	59 inches (Stainless Steel)
Valve Type	Pressure-balanced Brass Valve with cUPC certification
Flow Rate	2.5 GPM

ALL THE PARTS IN THE BOX

1. 8" Shower Head
2. Decorate Cover
3. Shower Arm

4. Shower Valve and Trim Kit
5. Handheld Shower
6. Shower Hose

7. Shower Holder
8. Decorate Cover
9. Accessories



Dimensional drawing illustrating the sizes of the shower head, hand shower, valve, and hose.

SETUP AND INSTALLATION

Installation of this shower system requires plumbing knowledge. It is highly recommended to hire a certified plumber for installation to ensure compliance with local codes and proper functionality.

Valve Installation

The system includes a premium solid brass shower valve with a cUPC pressure balance cartridge. This valve is designed to maintain consistent water temperature, preventing sudden changes due to water pressure fluctuations.



Detailed view of the solid brass shower valve, showing connections and internal components.

- **Brass Diverter:** Controls water flow between the shower head and hand shower.
- **cUPC Pressure Balance Cartridge:** Ensures stable water temperature.
- **Solid Brass Shower Valve Body:** Durable construction for longevity.
- **Water Flow Adjustable Screw:** Allows for adjustment of maximum water flow.
- **Connectors:** Hot Water Connector (1/2" NPT), Cold Water Connector (1/2" NPT), Shower Head Connector (1/2" NPT), Hand Shower Connector (1/2" NPT). Ensure all connections are properly sealed.

Component Assembly

Once the valve is securely installed within the wall, attach the shower arm, rainfall shower head, shower holder, and hand shower hose according to standard plumbing practices. Ensure all decorative covers are placed correctly for a finished appearance.


OPERATING INSTRUCTIONS

Water Temperature and Flow Control

The single handle on the shower valve controls both water temperature and flow. Rotate the handle to adjust temperature (typically counter-clockwise for hot, clockwise for cold) and lift/push to control water volume.

Switching Water Diverter

The 2-way diverter knob allows you to switch water flow between the rainfall shower head and the handheld shower. Rotate the knob to select your desired output.



**Premium Solid Brass Shower Valve
Comes with High Quality cUPC Pressure
Balance Cartridge, No Extra Pay for valve**

The diverter knob allows easy switching between the rainfall shower and the handheld shower.

Rainfall Shower Head Spray Patterns

The 8-inch rainfall shower head offers 6 distinct spray patterns. To change the spray pattern, rotate the 5-zone click lever dial located on the shower head. The shower head also features a 360° rotation for adjustable angle.



The 6 available spray patterns for the rainfall shower head include Waterfall, Stay-Warm Mist, Rainfall+Mist, Rainfall, Pellet, and Pause.

Handheld Shower Spray Patterns

The 5-inch handheld shower provides 9 versatile spray patterns. Adjust the spray by rotating the 7-zone click lever dial. A dedicated Power Jet Lever is also included for a concentrated stream.



360° Rotation

**5-zone Click
Lever Dial**

**8" HIGH QUALITY ABS PLASTIC
RAINFALL SHOWER HEAD**

Waterfall

Stay-Warm Mist

Rainfall+Mist

6 Spray Patterns

Rainfall

Pellet


Pause

The 9 available spray patterns for the handheld shower include Pellet, Pellet+Mist, Mist, Rainfall+Mist, Rainfall, Waterfall, Massage, Pause, and Power Jet.

Adjusting Hand Shower Angle

The solid brass shower holder allows for angle adjustment of the handheld shower, providing flexibility for various user preferences.

ADJUSTABLE ANGLE SOLID BRASS SHOWER HOLDER



Hand Shower



Shower Holder



59"High Quality
Shower Hose



The shower holder can be adjusted to direct the handheld shower spray as needed.

MAINTENANCE

Regular cleaning and maintenance will help preserve the finish and functionality of your WELLFOR shower system.

- **Cleaning the Finish:** Use a soft cloth and mild soap or a non-abrasive cleaner specifically designed for matte black finishes. Rinse thoroughly and dry with a soft cloth to prevent water spots. Avoid cleaners containing abrasives, ammonia, bleach, or acid.
- **Cleaning Nozzles:** The shower heads feature easy-to-clean silicone nozzles. Periodically rub the nozzles with your finger or a soft brush to dislodge any mineral buildup. This helps maintain optimal spray performance.
- **Hose Maintenance:** Inspect the 59-inch stainless steel hose periodically for any signs of wear or damage. Clean the hose with a soft cloth and mild soap.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low water pressure	Clogged nozzles or aerator; partially closed shut-off valve; low household water pressure.	Clean silicone nozzles by rubbing them. Check if shut-off valves are fully open. Consult a plumber if household pressure is consistently low.
Water leaks from connections	Loose connections; worn O-rings or gaskets; improper thread sealant.	Ensure all connections are tightened properly. Replace any damaged O-rings or gaskets. Reapply plumber's tape or sealant if necessary.
Water temperature fluctuates	Pressure balance cartridge issue; inconsistent hot/cold water supply.	Verify consistent hot and cold water supply to the valve. If the issue persists, the pressure balance cartridge may need inspection or replacement by a professional.
Diverter not switching properly	Mineral buildup in diverter; faulty diverter mechanism.	Flush the system to remove debris. If the problem continues, the diverter may require professional servicing or replacement.

WARRANTY AND SUPPORT

WELLFOR products are manufactured to high-quality standards. For specific warranty information regarding your WELLFOR 8-Inch Dual Head Shower System, please refer to the warranty card included with your purchase or visit the official WELLFOR website.

If you encounter any issues or require technical assistance, please contact WELLFOR customer support. Have your model number (88044B) and purchase information ready when contacting support.

WELLFOR Customer Support:

- Refer to your product packaging or the WELLFOR official website for the most current contact information.