

[Manuals.plus](#) /

› [Electrolux](#) /

› Electrolux Comfort 600 Portable AC 9000 BTU User Manual

Electrolux EXP26U339CW

Electrolux Comfort 600 Portable Air Conditioner User Manual

Model: EXP26U339CW (Reference: 950011600)

Brand: Electrolux

INTRODUCTION

This user manual provides comprehensive instructions for the safe and efficient operation, installation, and maintenance of your Electrolux Comfort 600 Portable Air Conditioner, model EXP26U339CW. Please read this manual thoroughly before using the appliance and keep it for future reference.



Figure 1: Electrolux Comfort 600 Portable Air Conditioner.

SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury

to persons. This appliance is for indoor use only. Do not operate the unit with a damaged cord or plug. Ensure proper grounding. Keep children and pets away from the unit.

PACKAGE CONTENTS

Before installation, check that all components are present and in good condition:

- Electrolux Comfort 600 Portable Air Conditioner Unit
- Remote Control
- User Manual
- Hot Air Exhaust Hose
- Adapters (for hose connection)

SETUP AND INSTALLATION

1. Placement

Place the air conditioner on a flat, stable surface, ensuring there is at least 30 cm (12 inches) of clear space around the unit for proper airflow. Avoid placing it near heat sources or in direct sunlight.

2. Window Kit Installation

The unit comes with a window kit for exhausting hot air. This is crucial for efficient cooling.

1. Attach the exhaust hose to the air conditioner's exhaust outlet.
2. Extend the window kit to fit your window opening.
3. Connect the other end of the exhaust hose to the window kit adapter.
4. Secure the window kit in the window to prevent hot air from re-entering the room.



Figure 2: Easy window kit installation for exhaust.

3. Power Connection

Plug the power cord into a grounded electrical outlet (240 Volts). Do not use extension cords or adapters.

OPERATING INSTRUCTIONS

1. Control Panel and LED Display

The unit features an intuitive LED display and control panel on top for direct operation.

2. Remote Control

The included remote control allows for convenient adjustment of settings from a distance.

3. Operating Modes (3-in-1 Function)

- **Cooling Mode:** For powerful air conditioning. Adjust the target temperature using the +/- buttons.

- **Dehumidifier Mode:** Reduces humidity in the room.
- **Fan Mode:** Circulates air without cooling. Adjust fan speed as desired.

4. Silent Mode

Activate Silent Mode for reduced noise levels (64 dB), ideal for quiet environments or nighttime use.



Un confort frais et silencieux
Fournit un flux constant d'air frais dans un confort silencieux (niveau de bruit faible de 64dB*)

*Conformément au test de bruit standard: EN 12102-2013

Figure 3: The unit's silent operation ensures a comfortable environment.

5. Wi-Fi Connectivity and App Control

The unit supports Wi-Fi connectivity, allowing you to control and monitor your air conditioner remotely via a smartphone application. Refer to the app's instructions for pairing and usage.



Figure 4: Remote control via smartphone app.

MAINTENANCE

1. Air Filter Cleaning

The antibacterial filter should be cleaned regularly (every two weeks or as needed) to maintain optimal performance and air quality.

1. Unplug the unit from the power outlet.
2. Locate and remove the air filter (usually at the back or side).
3. Clean the filter with a vacuum cleaner or wash it gently with warm water and mild detergent.
4. Allow the filter to dry completely before reinserting it.

2. Water Drainage

During dehumidification or in high humidity conditions, water will collect inside the unit. The unit has an internal water tank

that may require manual drainage. Refer to the specific instructions in the full manual for continuous drainage options if available.

3. Storage

When storing the unit for an extended period, ensure it is completely drained of water, clean the filters, and cover it to protect from dust. Store in a dry, cool place.

ENVIRONMENTAL CONSIDERATIONS

This appliance uses R290 natural gas as a refrigerant, which has a significantly lower climate impact (99.8% less) compared to R410a. Electrolux is committed to sustainable solutions.



99,8% d'impact climatique en moins
Tranquillité d'esprit: Le gaz naturel R290 a 99,8% d'impact climatique en moins par rapport au R410a

Figure 5: Reduced environmental impact with R290 refrigerant.

Problem	Possible Cause	Solution
Unit does not turn on	No power, power cord unplugged, circuit breaker tripped.	Check power connection, ensure plug is fully inserted, reset circuit breaker.
Insufficient cooling	Dirty air filter, exhaust hose not properly installed, room too large, windows/doors open.	Clean air filter, ensure hose is sealed and not kinked, close windows/doors, verify room size suitability for unit's capacity.
Unit is noisy	Unit not on a flat surface, fan obstruction, dirty filter.	Place on a flat, stable surface, check for obstructions in air inlets/outlets, clean filter.
Water leakage	Water tank full, drainage hose blocked or improperly connected.	Drain water tank, check drainage hose for kinks or blockages and ensure secure connection.

SPECIFICATIONS

Feature	Value
Brand	Electrolux
Model Name	Comfort 600
Model Number	EXP26U339CW (950011600)
Cooling Capacity	9000 BTU (2.6 kW)
Dimensions (L x W x H)	38.3 x 47.2 x 70.5 cm
Weight	31.5 kg
Energy Efficiency Rating	A
Annual Energy Consumption	500 kWh per year
Noise Level	64 dB
Voltage	240 Volts
Filter Type	Antibacterial filter
Refrigerant	R290 (Natural Gas)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Electrolux website. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, you may contact Electrolux customer service through their official channels. Details are typically provided in the product packaging or on the brand's website.

