

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Yaheetech](#) /

› [Yaheetech Rolling Kitchen Island User Manual](#)

## Yaheetech B0DHXD1MRP

# Yaheetech Rolling Kitchen Island User Manual

Model: B0DHXD1MRP

## INTRODUCTION

---

Thank you for choosing the Yaheetech Rolling Kitchen Island. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new kitchen island. Please read it thoroughly before use and retain it for future reference.



Figure 1: Yaheetech Rolling Kitchen Island, showcasing its rustic brown finish and overall structure.

## IMPORTANT SAFETY INFORMATION

---

To ensure safe operation and prevent damage, please adhere to the following safety guidelines:

- **Weight Capacity:** Do not exceed the maximum weight capacity of 88 lbs (40 kg) for the countertop and shelves. Each hook has a maximum capacity of 11 lbs (5 kg). Overloading can cause structural failure and injury.
- **Stability:** Use caution when moving the island, especially on uneven surfaces, to prevent tipping. Ensure casters are locked when the island is stationary to maintain stability.
- **Electrical Safety:** Keep electrical appliances and the power outlets away from water or excessive liquids. Always turn off the OCP (Over Current Protection) switch after using appliances connected to the integrated power outlets.
- **Assembly:** Follow all assembly instructions carefully. Ensure all parts are securely fastened before use. Do not modify the product structure.
- **Cleaning:** Disconnect any electrical appliances before cleaning. Use a damp cloth for cleaning and avoid harsh chemicals that may damage the finish.

## SETUP AND ASSEMBLY

---

The Yaheetech Rolling Kitchen Island requires assembly. Please ensure all components are present before beginning. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

## Package Contents:

- MDF Panels (Countertop, Shelves)
- Metal Frame Components
- Casters (Wheels)
- Power Outlet Unit with Cord
- Mug Holders
- Wine Glass Holders
- S-shaped Hooks
- Assembly Hardware (Screws, Allen Wrench, etc.)
- Instruction Manual (this document)

## Assembly Steps:

1. **Unpack and Verify:** Carefully unpack all components and compare them against the parts list provided in the original packaging.
2. **Assemble Frame:** Begin by connecting the metal frame components using the provided hardware. Ensure all connections are finger-tight before fully tightening.
3. **Attach Casters:** Securely attach the four casters to the bottom of the metal frame. Two of the casters are lockable; position them on the same side for easier access.
4. **Install Shelves:** Place the MDF shelves onto the designated frame supports. Secure them with the appropriate hardware.
5. **Mount Power Outlet:** Attach the power outlet unit to the side panel as indicated in the assembly diagram. Ensure the power cord is routed safely and not pinched.
6. **Add Accessories:** Install the mug holders, wine glass holders, and S-shaped hooks as desired on the designated rails.
7. **Final Tightening:** Once all components are in place, systematically tighten all screws and bolts to ensure the structure is rigid and stable. Do not overtighten.



Figure 2: Detailed dimensions of the kitchen island, useful for planning placement and assembly.



Figure 3: Close-up view of the 360-degree rotatable caster wheel with its locking mechanism (ON/OFF).

## OPERATING INSTRUCTIONS

---

### Using the Rolling Function:

To move the kitchen island, unlock the two lockable casters by pushing the lever to the "OFF" position. Gently push the island to its desired location. Once positioned, push the levers to the "ON" position to lock the casters and prevent unintended movement.

### Utilizing Storage Space:

The island features a spacious countertop, two open shelves, three wine glass holders, three mug holders, and eight S-shaped hooks. Distribute weight evenly across the shelves and countertop to maintain stability. The bottom shelf is designed with slats for stable multi-layer stacking of wine bottles.



# Sufficient Storage Space

Improve Kitchen Space Utilization, Keep it Neat and Tidy



Figure 4: Illustration of the kitchen island's ample storage capacity, showing various kitchen items organized on its shelves and hooks.



## Stable Multi-layer Stacking of Wine Bottles

Figure 5: Detailed view of the slatted bottom shelf, designed for stable multi-layer stacking of wine bottles.

### Using the Power Outlets:

The kitchen island is equipped with two AC power outlets and an OCP (Over Current Protection) switch. These outlets are suitable for small kitchen appliances such as microwave ovens, coffee makers, and air fryers. To use, plug your appliance into one of the outlets. After use, always turn off the OCP switch to ensure safety and conserve energy.



# Charging Station Does matter!



2 AC Outlets



1 Switch



6.5- Foot  
[Power Cord Length]



Figure 6: Detailed view of the integrated charging station, featuring two AC outlets and an OCP switch.

## MAINTENANCE AND CARE

Regular maintenance will help prolong the life and appearance of your kitchen island.

- **Cleaning:** Wipe the surfaces with a damp cloth. For stubborn stains, a mild soap solution can be used, followed by wiping with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the rustic brown finish or metal frame.
- **Spills:** Promptly wipe up any spills, especially liquids, to prevent water damage to the MDF panels.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Caster Maintenance:** Keep the caster wheels free of debris (hair, dust, etc.) to ensure smooth rolling.

## TROUBLESHOOTING

If you encounter issues with your Yaheetech Rolling Kitchen Island, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Island is wobbly after assembly.	Loose hardware.	Check and tighten all screws and bolts. Ensure the island is on a level surface.



Problem	Possible Cause	Solution
Casters do not roll smoothly.	Debris caught in wheels; casters locked.	Clear any debris from the wheels. Ensure the caster lock levers are in the "OFF" position.
Power outlets are not working.	OCP switch is off; appliance issue; power cord not plugged in.	Ensure the OCP switch is in the "ON" position. Check if the appliance is working correctly in another outlet. Verify the island's power cord is securely plugged into a wall outlet.
Scratches on surface.	Sharp objects; abrasive cleaning.	Use coasters or protective mats for hot or sharp items. Avoid dragging objects across the surface. Use only soft cloths for cleaning.

If the problem persists or is not listed here, please contact Yaheetech customer support for assistance.

## SPECIFICATIONS

Feature	Detail
Model	B0DHXD1MRP
Color	Rustic Brown
Materials	CARB P2 Compliant MDF, Powder-coated Metal Frame
Assembled Dimensions (L x W x H)	47.5" x 24" x 36.5" (120.65 cm x 60.96 cm x 92.71 cm)
Countertop Dimensions (L x W)	47.5" x 24" (120.65 cm x 60.96 cm)
Maximum Weight Capacity (Countertop)	88 lb (40 kg)
Maximum Weight Capacity (Each Shelf)	88 lb (40 kg)
Maximum Weight Capacity (Each Hook)	11 lb (5 kg)
Power Outlets	2 AC Outlets with OCP Switch
Power Cord Length	6.5 ft (1.98 m)
Casters	4 (2 lockable, 2 non-lockable)
Assembly Required	Yes
Product Weight	68 lbs (30.8 kg)

## WARRANTY AND SUPPORT

## Customer Support:

For any questions, concerns, or assistance with your Yaheetech Rolling Kitchen Island, please contact Yaheetech customer support. You can typically find contact information on the Yaheetech official website or through the retailer where you purchased the product.

Please have your model number (B0DHXD1MRP) and purchase date ready when contacting support.

## Warranty Information:

Specific warranty details may vary by region and retailer. Please refer to the warranty card included with your product or visit the official Yaheetech website for the most up-to-date warranty policy. Generally, Yaheetech products are covered against manufacturing defects for a specified period from the date of purchase.

