

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LUDOMIDE](#) /

› [LUDOMIDE Ceiling Fans with Lights, Low Noise Reversible Airflow DC Motor 52 Inch Ceiling Fan with Remote Control, Flush Mount Ceiling Fan for Indoor Outdoor](#)

LUDOMIDE 1164

LUDOMIDE Ceiling Fan User Manual

Model: 1164

Brand: LUDOMIDE

1. INTRODUCTION

Thank you for choosing the LUDOMIDE 52-inch Ceiling Fan with Light. This modern and aesthetically pleasing fan is designed to provide both cooling comfort and enhanced ambiance for your indoor and outdoor spaces (covered patios, breezeways, gazebos, and pergolas). Featuring a low-noise DC motor, reversible airflow, and versatile lighting options, this fan ensures year-round comfort and convenience. Please read this manual thoroughly before installation and operation to ensure safe and optimal performance.



Image 1.1: The LUDOMIDE 52-inch Ceiling Fan with Light, showcasing its sleek black design and integrated lighting. The image also displays the remote control and a smartphone screen illustrating the app control interface.

2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- **Read all instructions:** Before beginning installation, read all instructions and safety information.
- **Electrical Safety:** All electrical wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- **Disconnect Power:** Before installing, cleaning, or servicing the fan, disconnect power by turning off the circuit breaker at the main fuse box.
- **Mounting Structure:** Ensure the mounting structure can support the weight of the fan (approximately 4.54 kg).

- **Blade Clearance:** Ensure there is adequate clearance from the fan blades to any obstacles.
- **Do not bend blades:** Do not bend the fan blades during installation or cleaning.
- **Use only supplied parts:** Use only replacement parts supplied by the manufacturer.
- **Outdoor Use:** For outdoor use, ensure the fan is installed in a covered area, protected from direct rain.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Assembly
- Fan Blades (3)
- Light Kit Assembly
- Remote Control
- Mounting Bracket
- Hardware Pack (screws, wire nuts, washers)
- User Manual

4. SETUP AND INSTALLATION

The LUDOMIDE ceiling fan is designed for easy installation. For detailed visual guidance, please refer to the official installation video provided by LUDOMIDE.


4.1 Pre-Installation Checklist

- Ensure power is OFF at the circuit breaker.
- Gather necessary tools: screwdriver, wire strippers, ladder, electrical tape.
- Confirm the mounting location is suitable and can support the fan's weight.

4.2 Installation Steps (General Overview)

1. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box. Ensure it is firmly attached to a structural support.
2. **Wiring Connections:** Connect the fan's electrical wires to the household wiring according to local electrical codes. Use the provided wire nuts.
3. **Fan Assembly:** Attach the fan motor assembly to the mounting bracket.
4. **Blade Attachment:** Securely attach the fan blades to the motor housing.
5. **Light Kit Installation:** Connect and install the light kit to the bottom of the fan motor assembly.
6. **Final Checks:** Ensure all connections are secure and the fan is properly balanced.

CEILING FAN DIMENSIONS



SUITABLE FOR 144 - 324 ft²




Image 4.1: Ceiling Fan Dimensions. This diagram illustrates the overall dimensions of the 52-inch LUDOMIDE ceiling fan, including its width, height, and individual component measurements, along with a guide for suitable room sizes (144-324 sq ft).

5. OPERATING INSTRUCTIONS

Your LUDOMIDE ceiling fan can be controlled via the included remote control or a dedicated smartphone application.

5.1 Remote Control Operation

Insert two AAA batteries (not included) into the remote control. The remote allows full control over fan speed, light settings, and timer functions.

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed Adjustment:** Select from six adjustable fan speeds.
 - **1-2 Gear:** Low Wind - Soft Wind

- **3-4 Gear:** Medium Wind - Natural Wind
- **5-6 Gear:** High Wind - Cool Wind
- **Light Control:**
 - **Brightness Adjustment:** Adjust light brightness from 10% to 100%.
 - **Color Temperature:** Cycle through three color temperatures: 3000K (Warm Light), 4500K (Natural Light), and 6000K (White Light).
 - **Night Light Mode:** Activate a softer light setting for nighttime use.
- **Timer Function:** Set a sleep-off timer for up to 2 hours.
- **Reverse Airflow:** Change the direction of the fan blades for seasonal comfort.




Image 5.1: Two Control Modes. The fan can be operated using either the dedicated remote control or a smartphone application, offering flexible control options.

6 WIND SPEED



1-2 Gear

Low Wind-Soft Wind



3-4 Gear

Medium Wind-Natural Wind



5-6 Gear

High Wind-Cool Wind



Image 5.2: 6 Wind Speed. This graphic details the six available wind speed settings, grouped into low (1-2 gear), medium (3-4 gear), and high (5-6 gear) for varied comfort levels.

ADJUST COLOR TEMPERATURE



3000K
Warm Light

4500K
Natural Light

6000K
White Light

ADJUST BRIGHTNESS

10%

25%

50%

75%

100%

Dim

Bright

Image 5.3: Adjust Color Temperature and Brightness. This image demonstrates the fan's ability to adjust light color temperature (3000K, 4500K, 6000K) and brightness from 10% to 100%.



Image 5.4: Night Light Mode. The fan features a night light mode, providing a soft illumination ideal for creating a soothing atmosphere, particularly beneficial for families with infants.

5.2 Reversible Airflow Function

The fan's reversible DC motor allows for year-round use:

- **Summer Mode:** Blades rotate counter-clockwise to create a downward airflow, producing a cooling effect.
- **Winter Mode:** Blades rotate clockwise to create an upward airflow, circulating warm air trapped near the ceiling.

REVERSIBLE DC MOTOR

Warm in winter and cool in summer



Image 5.5: Reversible DC Motor. This visual demonstrates the fan's reversible airflow function, allowing it to provide a cooling breeze in summer and improve warm air circulation in winter.

5.3 Ultra-Quiet Operation

The LUDOMIDE ceiling fan operates at a low noise level of just 35 dB, ensuring a peaceful environment, ideal for bedrooms or quiet spaces.

ULTRA-QUIET DESIGN

ONLY WIND, NO SOUND



≤35dB



2H Timer



6 Wind Speeds

Ours



Others



Image 5.6: Ultra-Quiet Design. This image emphasizes the fan's quiet operation (less than 35dB), making it suitable for environments where minimal noise is desired, such as bedrooms.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing regularly with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Periodically check that all blade screws are tight. Loose blades can cause wobbling and noise.
- **Light Cover:** Clean the light cover with a soft, dry cloth.
- **No Lubrication Needed:** The fan's motor is permanently lubricated and does not require oiling.
- **Power Off:** Always turn off the power at the circuit breaker before cleaning or performing any maintenance.

7. TROUBLESHOOTING

If you encounter issues with your LUDOMIDE ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start.	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Ensure all wire connections are secure; Replace remote control batteries.
Fan wobbles.	Loose blade screws; Unbalanced blades; Improper mounting.	Tighten all blade screws; Check blade balance (use balancing kit if necessary); Re-check mounting bracket installation.
Light does not work.	Loose wire connection in light kit; LED driver issue.	Check light kit wiring; Contact customer support if LED driver is suspected.
Remote control not working.	Low batteries; Remote not paired with fan.	Replace batteries; Refer to pairing instructions in the full manual (if applicable).
Fan is noisy.	Loose screws; Fan not level; Obstruction.	Check and tighten all screws; Ensure fan is level; Remove any obstructions.

If the problem persists after attempting these solutions, please contact LUDOMIDE customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	LUDOMIDE
Model Number	1164
Color	Black
Product Dimensions	27.94 x 22.86 x 68.58 cm (52-inch diameter)
Item Weight	4.54 kg
Material	Acrylonitrile Butadiene Styrene (ABS)
Motor Type	DC Motor (Reversible)
Number of Speeds	6

Feature	Detail
Noise Level	< 35 dB
Light Source	Integrated LED
Light Brightness	Adjustable (10% to 100%), up to 2000 LM
Color Temperatures	3000K (Warm), 4500K (Natural), 6000K (White)
Control Type	Remote Controlled, App Controlled (Android)
Timer Function	2-hour sleep off timer
Recommended Room Size	144-324 square feet

9. WARRANTY AND SUPPORT

LUDOMIDE is committed to customer satisfaction. Your LUDOMIDE Ceiling Fan comes with a **24-month worry-free warranty** from the date of purchase.

If you have any questions, require technical assistance during installation or use, or need to claim warranty service, please do not hesitate to contact our technical support team. Our team is available 24/7 to assist you.

Contact Information: Please refer to the contact details provided on your purchase receipt or the LUDOMIDE official website for the most up-to-date support channels.

© 2025 LUDOMIDE. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.