

ATTACK SHARK L80

ATTACK SHARK L80 Wireless Gaming Headset User Manual

Model: L80

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your ATTACK SHARK L80 Wireless Gaming Headset. Please read this manual thoroughly before using the product to ensure proper function and longevity.



Image: The ATTACK SHARK L80 Wireless Gaming Headset, featuring over-ear cups, a flexible microphone, and a USB dongle.

PACKAGE CONTENTS

Verify that all items are present in your product package:

- ATTACK SHARK L80 Wireless Gaming Headset
- Detachable Omni-directional Microphone
- 2.4GHz USB Wireless Dongle (USB-A)
- USB-C to USB-A Charging Cable
- 3.5mm Audio Cable
- User Manual (this document)



Image: All components included in the ATTACK SHARK L80 headset package: headset, detachable microphone, 2.4GHz USB dongle, USB-C charging cable, and 3.5mm audio cable.

PRODUCT OVERVIEW

Headset Controls and Ports

Familiarize yourself with the headset's controls and connection points:



Press and hold for 3 seconds:
ON/OFF

Short press when power on:
answer the call
(phone priority)/paly/pause

Short press 3 times in succession:
Bluetooth/2.4G mode switvhing

Short press: **Volume+**
Long press: **Previous song**

Short press: **Volume-**
Long press: **Next song**

Short press: **microphone on/off**



Image: Close-up of the ATTACK SHARK L80 headset's left earcup, showing the power button, mode switch button, volume up/previous track button, volume down/next track button, and microphone mute button.

- **Power Button:** Press and hold for 3 seconds to power ON/OFF. Short press to answer/end calls or play/pause media.
- **Mode Switch Button:** Short press 3 times in succession to switch between Bluetooth and 2.4G wireless modes.
- **Volume Up / Previous Song:** Short press for Volume+, Long press for Previous Song.
- **Volume Down / Next Song:** Short press for Volume-, Long press for Next Song.
- **Microphone Mute Button:** Short press to toggle microphone ON/OFF.
- **Microphone Port:** For connecting the detachable microphone.
- **3.5mm Audio Jack:** For wired connection.
- **USB-C Charging Port:** For charging the headset.
- **Indicator Light:** Displays connection status and battery level.

Detachable Microphone

The L80 headset features a detachable, omni-directional microphone with noise reduction capabilities. It can be adjusted 360 degrees for optimal positioning.

NOISE CANCELLING MICROPHONE

360° Adjustable Microphone to Pick up Your Voice



360°
Adjustable



Detachable
Microphone



Image: The ATTACK SHARK L80 headset with its detachable, 360-degree adjustable, noise-cancelling microphone attached.

SETUP

The ATTACK SHARK L80 headset offers three connection modes: 2.4GHz wireless, Bluetooth 5.2, and 3.5mm wired. Choose the appropriate method for your device.

1. 2.4GHz Wireless Connection (for PC, PS5, PS4, Nintendo Switch Docked)

1. Insert the 2.4GHz USB wireless dongle into an available USB port on your PC, PS5, PS4, or Nintendo Switch dock.
2. Power on the L80 headset by pressing and holding the Power Button for 3 seconds.
3. The headset will automatically attempt to connect to the dongle. The indicator light will show a stable color once connected.
4. On your device, ensure the audio output is set to "ATTACK SHARK L80" or similar.

2.4GHz & Dual Mode Online

Dual device, gaming/calling at the same time



Image: Diagram illustrating 2.4GHz USB dongle connection to a PS4 and a USB-C dongle connection to a portable device, alongside Bluetooth connectivity for phones.

2. Bluetooth 5.2 Connection (for Phones, Tablets, Laptops)

1. Power on the L80 headset by pressing and holding the Power Button for 3 seconds.
2. If not already in Bluetooth mode, short press the Mode Switch Button three times in quick succession to enter Bluetooth pairing mode. The indicator light will flash, indicating it is discoverable.
3. On your device (phone, tablet, laptop), go to Bluetooth settings and search for available devices.
4. Select "ATTACK SHARK L80" from the list to pair. The indicator light will become stable once connected.

3. 3.5mm Wired Connection (for various devices)

1. Connect one end of the 3.5mm audio cable to the 3.5mm audio jack on the L80 headset.
2. Connect the other end of the 3.5mm audio cable to the audio output port of your device.
3. The headset will function in wired mode. Note that volume control via the headset buttons may not be available in wired mode, depending on the connected device.

COMPATIBLE WITH MULTIPLE PLATFORMS

Option 1: Connet with PS4 via 2.4G/USB plug

Option 2: Connet with Xbox via USB plug



Note: Volume cannot be adjusted via the headphone button in wired mode

Image: The ATTACK SHARK L80 headset displayed among various compatible platforms including PlayStation consoles, Nintendo Switch, Xbox, PC, tablets, and smartphones.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the Power Button for approximately 3 seconds until the indicator light illuminates.
- **Power Off:** Press and hold the Power Button for approximately 3 seconds until the indicator light turns off.

Volume Control

- **Increase Volume:** Short press the Volume Up button.
- **Decrease Volume:** Short press the Volume Down button.

Media Playback Control

- **Play/Pause:** Short press the Power Button.

- **Previous Song:** Long press the Volume Up button.
- **Next Song:** Long press the Volume Down button.

Call Management

- **Answer/End Call:** Short press the Power Button.

Microphone Usage

- Attach the detachable microphone to the designated port on the headset.
- Adjust the microphone's position for optimal voice pickup.
- **Mute/Unmute Microphone:** Short press the Microphone Mute Button.

Mode Switching

- To switch between 2.4GHz wireless mode and Bluetooth mode, short press the Mode Switch Button three times in quick succession.

Charging the Headset

The headset provides up to 50 hours of playtime at 50% volume and takes approximately 3 hours for a full charge.

- Connect the USB-C end of the charging cable to the headset's USB-C port.
- Connect the USB-A end of the charging cable to a USB power source (e.g., computer USB port, wall adapter).
- The indicator light will show charging status. A red light alert indicates battery level below 10%.

Long-Lasting Battery Life



Image: Visual representation of the ATTACK SHARK L80 headset's battery features, including 45-50 hours gaming time, red light alert for low battery, 3 hours charging time, and electricity saving standby.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the headset frequently. Charge it regularly, even if not in use for extended periods.
- **Cable Management:** Avoid sharp bends or kinks in the cables to prevent damage.




Image: Close-up of the headset's ultra-soft mesh earmuffs, highlighting their breathable and comfortable design for extended wear.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from headset.	Headset not powered on, not connected, or volume too low.	<ul style="list-style-type: none">◦ Ensure headset is powered on.◦ Verify correct connection mode (2.4GHz, Bluetooth, or wired).◦ Check device's audio output settings.◦ Increase headset and device volume.
Microphone not working.	Microphone muted, not properly attached, or incorrect input device selected.	<ul style="list-style-type: none">◦ Ensure microphone is securely attached.◦ Press the Microphone Mute Button to unmute.◦ Check device's audio input settings and select "ATTACK SHARK L80" or similar.
Cannot connect via 2.4GHz wireless.	Dongle not inserted, headset not in 2.4GHz mode, or interference.	<ul style="list-style-type: none">◦ Ensure 2.4GHz dongle is fully inserted into a working USB port.◦ Triple-press the Mode Switch Button to ensure headset is in 2.4GHz mode.◦ Try a different USB port.◦ Move closer to the dongle to reduce interference.

Problem	Possible Cause	Solution
Cannot connect via Bluetooth.	Headset not in pairing mode, Bluetooth off on device, or previously paired device interfering.	<ul style="list-style-type: none">◦ Triple-press the Mode Switch Button to enter Bluetooth pairing mode (flashing indicator light).◦ Ensure Bluetooth is enabled on your device.◦ Forget "ATTACK SHARK L80" from your device's Bluetooth list and re-pair.◦ Ensure no other devices are actively connected to the headset via Bluetooth.
Headset not charging.	Charging cable faulty, power source issue, or charging port obstruction.	<ul style="list-style-type: none">◦ Ensure charging cable is securely connected to both headset and power source.◦ Try a different USB-C charging cable.◦ Try a different USB power source.◦ Check the charging port for any debris.

SPECIFICATIONS

Feature	Detail
Model Name	L80 headset
Connectivity Technology	2.4Ghz Wireless, Bluetooth 5.2, 3.5mm Wired
Audio Driver Size	40 mm
Frequency Range	20 Hz - 20,000 Hz
Impedance	30 Ohm
Noise Control	Sound Isolation
Microphone	Detachable, Omni-directional, Noise-reduction
Battery Life	Up to 50 hours (at 50% volume)
Charging Time	Approximately 3 hours
Weight	12 ounces (approx. 340 grams)
Material	Plastic
Compatible Devices	PC, PS5, PS4, Nintendo Switch, Laptops, Tablets, Phones

High Fidelity Sound



Powerful 40mm Audio Drivers







Image: Cutaway view of the ATTACK SHARK L80 headset's earcup, highlighting the powerful 40mm audio drivers responsible for high-fidelity sound.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official ATTACK SHARK website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: ATTACK SHARK

Contact: Please visit the [ATTACK SHARK Store on Amazon](#) for further assistance or to find contact information.

	<p>Attack Shark Three-Mode Wireless Lightweight Gaming Headset Guide</p> <p>Explore the ATTACK SHARK Three-Mode Wireless Lightweight Gaming Headset. This guide covers button functions, indicator lights, connection methods (Bluetooth, 2.4G, Wired), troubleshooting, and care instructions for an optimal gaming experience.</p>
	<p>Attack Shark Three-Mode Wireless Lightweight Gaming Headset User Manual</p> <p>User manual for the Attack Shark Three-Mode Wireless Lightweight Gaming Headset, detailing its features, setup, connection methods, usage tips, precautions, and maintenance.</p>
	<p>Attack Shark G300 Foldable ANC Dual Mode Headphones User Manual</p> <p>Official user manual for the Attack Shark G300 headphones, detailing features like Active Noise Cancellation (ANC), dual-mode connectivity, foldable design, specifications, usage instructions, and safety guidelines.</p>
	<p>Attack Shark X68 HE Gaming Keyboard User Manual</p> <p>Comprehensive user manual for the Attack Shark X68 HE gaming keyboard, detailing its features, setup, and customization options including rapid trigger, magnetic switches, and RGB lighting.</p>
	<p>Attack Shark R5 Wireless Gaming Mouse User Manual</p> <p>Comprehensive user manual for the Attack Shark R5 Wireless Gaming Mouse, detailing its features, connectivity options (USB, 2.4G, Bluetooth), and operation. Includes instructions for pairing and driver downloads.</p>
	<p>Attack Shark X3 Superlight Gaming Mouse User Manual</p> <p>Comprehensive user manual for the Attack Shark X3 Superlight Gaming Mouse, detailing features, setup, and operation for wireless and wired gaming.</p>

Documents - ATTACK SHARK – L80

no relevant documents