

## Uten SL-A01-1

# Uten 800 Watt High Speed Countertop Blender Instruction Manual

Model: SL-A01-1

## 1. INTRODUCTION

---

Thank you for choosing the Uten 800 Watt High Speed Countertop Blender. This appliance is designed to provide efficient and versatile blending for a variety of ingredients, from smoothies and shakes to grinding coffee beans. Please read this manual thoroughly before first use to ensure safe and optimal operation.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the blender.
- To protect against risk of electrical shock, do not immerse the motor base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Keep hands and utensils out of container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate blender with lid in place.
- Do not blend hot liquids as this may cause pressure buildup and scalding.
- Do not use the appliance for other than intended use.
- Ensure the glass jar is properly seated and locked onto the motor base before operating.
- The blender features overheating protection. If the motor stops due to overheating, unplug the unit and allow it to cool down for at least 30 minutes before resuming use.

### 3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Uten Countertop Blender:

- Measuring Cup (removable from lid)
- Lid
- Sealing Ring (for lid)
- Glass Jug (68 Oz. capacity, 60 Oz. usable)
- Blades (6-leaf stainless steel)
- Glass Jug Base
- Fixing Ring
- Retaining Ring Wrench
- Speed Knob (with Pulse 'P' and speeds '0-5')
- Motor Base (with non-slip feet and heat dissipation vents)

## 5 Speeds & Pulse

Various speeds to suit your needs

**"P" Pulse Speed**  
For crushing ice and making smoothies

**"1-2" Low Speeds**  
For soft foods and vegetables

**"3-5" Fast Speeds**  
For hard fruits and nuts

Figure 3.1: Key components of the Uten Countertop Blender.



Figure 3.2: Detailed breakdown of blender parts for assembly and cleaning.

## 4. SETUP AND ASSEMBLY

1. **Unpack:** Carefully remove all parts from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the glass jug, lid, measuring cup, and blade assembly in warm, soapy water. Rinse thoroughly and dry. Do not immerse the motor base in water.
3. **Assemble Blade and Jug:** Ensure the sealing ring is correctly installed on the blade assembly. Attach the blade assembly to the bottom of the glass jug. Use the provided retaining ring wrench to properly install and tighten the fixing ring and the base of the glass jug. This ensures a secure, leak-free connection.
4. **Place on Base:** Place the assembled glass jug onto the motor base. Turn the jug until it is securely seated and aligned. The blender has a safety interlock; it will not operate unless the jug is correctly positioned.
5. **Secure Lid:** Place the lid onto the glass jug and insert the measuring cup into the lid opening.



Figure 4.1: Fully assembled Uten Countertop Blender ready for use.

## Tips

- 1 Use a wrench to properly install and tighten the fixing ring and the base of the glass bottle.
- 2 If there is a leak at the bottom of the container, please check whether the sealing ring is correctly installed.
- 3 Control the working capacity at 75% to avoid overload.
- 4 If the food is attached to the glass wall and cannot be stirred, please add a little water and stir again.



Figure 4.2: Proper installation and tightening of the glass jug base using the retaining ring wrench.

## 5. OPERATING INSTRUCTIONS

---

The Uten blender features an 800W motor and a 6-leaf stainless steel blade system for efficient blending.

- Add Ingredients:** Place your desired ingredients into the glass jug. Do not exceed the 60 Oz. usable capacity. For optimal performance and to prevent overloading, control the working capacity to approximately 75% of the jug's volume.
- Secure Lid:** Ensure the lid is securely placed on the jug and the measuring cup is inserted.
- Select Speed:** Turn the speed knob to your desired setting:
  - **'P' (Pulse):** For crushing ice, making smoothies, or short bursts of power. The blender operates only while the knob is held in this position.
  - **'0' (Off):** Turns the blender off.
  - **'1-2' (Low Speeds):** Ideal for soft foods and vegetables.
  - **'3-5' (Fast Speeds):** Suitable for hard fruits, nuts, and more intensive blending.
- Blend:** The blue LED light around the knob will illuminate when the blender is powered on and ready for operation. Turn the knob to the desired speed setting to begin blending.
- Adjusting During Blending:** If food sticks to the glass wall and cannot be stirred, please add a little water or liquid and stir again. You can also use the pulse function for quick bursts to dislodge ingredients.
- Finish:** Once blending is complete, turn the knob back to '0' and unplug the blender from the power outlet.

# 800W

High Power Motor

# 42000

RPM/min

# 6 Blades

High Efficiency Mixing



Retaining Ring Wrench



Figure 5.1: Understanding the speed settings and pulse function.



Figure 5.2: Examples of food preparations possible with your blender.

## 6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your blender.

1. **Pulse Clean:** For quick cleaning, add clean water (and a drop of dish soap, if desired) to the jug and select the 'P' (Pulse) mode. This can clean approximately 80% of the residue.
2. **Hand Washing:** For thorough cleaning, it is recommended to combine automatic (pulse) and manual cleaning. Disassemble the glass jug, blade assembly, lid, and measuring cup. Wash these parts in warm, soapy water. The bottom grinder parts can be easily removed for cleaning. Rinse thoroughly and dry.
3. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
4. **Important Cleaning Notes:**
  - Since the blender has ABS parts and rubber seals, it is **not suitable for dishwasher cleaning**. Plastic parts and seals will deform and fail under high temperature cleaning.
  - Glass jug is **not suitable for use and cleaning in alternating hot and cold conditions** which can easily

cause the jug to break. Avoid sudden temperature changes.

## Easy to Clean



### Pulse clean

Add clean water and select pulse mode to clean 80% of the residue



### Hand Washing

It is recommended to combine automatic and manual cleaning



Figure 6.1: Cleaning methods for your Uten Blender.

## 7. TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	<ol style="list-style-type: none"><li>1. Power cord not plugged in.</li><li>2. Glass jug not correctly seated or locked.</li><li>3. Overheating protection activated.</li></ol>	<ol style="list-style-type: none"><li>1. Ensure the power cord is securely plugged into a working outlet.</li><li>2. Remove the jug and re-seat it firmly on the motor base, turning until it clicks into place.</li><li>3. Unplug the blender and let it cool down for at least 30 minutes.</li></ol>

Problem	Possible Cause	Solution
Motor strains or smells burnt.	<ol style="list-style-type: none"> <li>Overloading the blender.</li> <li>Blending too thick or hard ingredients without sufficient liquid.</li> </ol>	<ol style="list-style-type: none"> <li>Reduce the amount of ingredients. Do not exceed 75% of the usable capacity.</li> <li>Add more liquid to the mixture. Use the pulse function for tough ingredients. If the motor stops, allow it to cool.</li> </ol>
Ingredients are not blending smoothly or are stuck.	<ol style="list-style-type: none"> <li>Insufficient liquid.</li> <li>Ingredients are too large or packed too tightly.</li> </ol>	<ol style="list-style-type: none"> <li>Add more liquid (water, milk, juice) to facilitate blending.</li> <li>Cut ingredients into smaller pieces. Use the pulse function to dislodge ingredients.</li> </ol>
Leakage from the bottom of the jug.	<ol style="list-style-type: none"> <li>Sealing ring not correctly installed.</li> <li>Fixing ring not tightened properly.</li> </ol>	<ol style="list-style-type: none"> <li>Disassemble the blade assembly and ensure the sealing ring is properly seated.</li> <li>Use the retaining ring wrench to tighten the fixing ring securely.</li> </ol>

## 8. SPECIFICATIONS

Feature	Detail
Brand	Uten
Model Number	SL-A01-1
Power	800 Watts
Capacity	68 Oz. (2 Liters) total, 60 Oz. usable
Material	Glass, Metal
Speed Settings	5 Speeds + Pulse Function
Blades	6-leaf Stainless Steel
Product Dimensions (D x W x H)	14.4" x 10.62" x 7.8"
Item Weight	10.08 pounds
Power Source	AC/DC

## 9. WARRANTY AND SUPPORT

Specific warranty information for the Uten 800 Watt High Speed Countertop Blender is not provided in this manual. For details regarding warranty coverage, technical support, or replacement parts, please contact Uten customer service directly or refer to the product packaging and purchase documentation.

You may also visit the official Uten store on Amazon for more information: [Uten Store](#)

