

PM860

TUNE PM860 RGB Wireless Bluetooth Headset User Manual

Model: PM860

1. INTRODUCTION

Thank you for purchasing the TUNE PM860 RGB Wireless Bluetooth Headset. This manual provides detailed instructions on how to set up, operate, and maintain your new headset. Please read this manual carefully before use to ensure optimal performance and longevity of your device.



The TUNE PM860 RGB Wireless Bluetooth Headset, showcasing its vibrant LED lighting and over-ear design.

2. KEY FEATURES

- **Advanced Bluetooth 5.2:** Ensures stable, faster transmission speeds and seamless audio-visual synchronization with low latency.
- **Long Battery Life:** Provides approximately 20 hours of music playback, minimizing battery concerns.
- **Powerful Audio:** Equipped with a large 40mm dynamic driver for rich, powerful bass and immersive sound.
- **Enhanced Communication:** Features intelligent noise reduction, high-definition calls, passive physical noise reduction, and a high-sensitivity microphone.
- **Foldable & Portable Design:** Convenient for travel and storage, maintaining sound quality and vibrant RGB lighting.
- **Dual Connectivity:** Supports both wireless Bluetooth and wired AUX audio connections.
- **Multi-Platform Compatibility:** Works with mainstream smart devices including Android and iOS.
- **Integrated FM Radio & SD Card Support:** Offers additional playback options.



Overview of the TUNE PM860's gaming features, including RGB light, wireless 5.3 (note: product description states 5.2), built-in mic, and lightweight design.

40 CUSTOMIZED MM DRIVE UNIT

The custom-tuned 40mm driver unit gives the sound greater clarity and depth of dive. Capture the subtle sound of footsteps and feel the powerful sound of gunfire, So you can enjoy more games and music fun!



High polymer composite diaphragm



7.1 Surround Stereo Game Sound

Detailed view of the 40mm customized drive unit, highlighting its high polymer composite diaphragm and 7.1 surround stereo game sound capabilities.

3. SETUP

3.1 Charging the Headset

Before first use, fully charge the headset. Connect the included USB charging cable to the headset's charging port and to a standard USB power source (e.g., computer USB port, wall adapter). The LED indicator will show charging status and turn off or change color when fully charged.

3.2 Powering On/Off

To power on, press and hold the Power button until the LED indicator lights up. To power off, press and hold the Power button until the LED indicator turns off.

3.3 Bluetooth Pairing

1. Ensure the headset is powered off.
2. Press and hold the Power button for approximately 5-7 seconds until the LED indicator flashes rapidly, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "TUNE PM860" (or similar name) from the list of found devices.
5. Once connected, the LED indicator on the headset will stop flashing and remain solid or flash slowly.

If prompted for a password, enter "0000" (four zeros).

4. OPERATING INSTRUCTIONS

4.1 Music Playback

- **Play/Pause:** Press the Multi-function button (often the Power button or a dedicated Play/Pause button).
- **Next Track:** Press and hold the Volume Up button or a dedicated Next button.
- **Previous Track:** Press and hold the Volume Down button or a dedicated Previous button.
- **Volume Up:** Short press the Volume Up button.
- **Volume Down:** Short press the Volume Down button.

4.2 Phone Calls

- **Answer/End Call:** Short press the Multi-function button.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

4.3 RGB LED Lighting

The headset features dynamic RGB LED lighting. The lighting effect can typically be controlled by a dedicated button (often labeled "RGB" or a light bulb icon) on the headset. Press this button to cycle through different lighting modes or to turn the lights on/off.

RGB DAZZLE COLOR LIGHT EFFECT

The headphone case is made of light-transparent, Opaque PC material, better lighting effect, cooler



The RGB Dazzle Color Light Effect on the ear cup, made from light-transparent PC material for enhanced illumination.

4.4 AUX Wired Mode

To use the headset in wired mode, connect the included 3.5mm AUX audio cable to the headset's AUX port and to your audio source. This mode allows you to continue using the headset even if the battery is depleted. Note that RGB lights may turn off in AUX mode.

4.5 FM Radio & SD Card Playback

The headset supports FM radio and playback from an SD card. Insert a formatted SD card into the designated slot. Use the mode button (if available) to switch between Bluetooth, FM, and SD card modes. In FM mode, use the volume buttons to scan for stations. Refer to specific button functions on your headset for detailed control.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headset in a cool, dry place, away from direct sunlight and extreme

temperatures. The foldable design allows for compact storage.

- **Ear Cushions:** The headset features skin-friendly foam earmuffs. Regularly inspect them for wear and tear. Avoid prolonged exposure to moisture.
- **Battery Care:** To preserve battery life, avoid fully discharging the headset frequently. Charge it regularly, even if not in use for extended periods.



Close-up of the skin-friendly foam earmuffs, designed for comfort and good sound insulation.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headset does not power on.	Battery is low or depleted.	Charge the headset fully.
Cannot pair with device.	Headset not in pairing mode; device Bluetooth off; too far from device.	Ensure headset is in pairing mode (flashing LED). Turn on Bluetooth on your device. Move headset closer to device (within 10 meters).
No sound.	Volume too low; headset not connected; incorrect audio source.	Increase volume on both headset and device. Reconnect Bluetooth. Check if AUX cable is properly inserted if using wired mode.
Poor sound quality.	Interference; low battery; distance from device.	Move away from sources of interference. Charge the headset. Reduce distance between headset and device.
Microphone not working.	Microphone muted; incorrect input device selected on computer.	Ensure microphone is not muted. Check audio settings on your device and select the headset as the input device.

7. SPECIFICATIONS

Feature	Detail
Model Name	PM860
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.2

Feature	Detail
Headphone Jack	3.5 mm Jack
Noise Control	Passive Noise Cancellation
Impedance	120 Ohm
Headphones Form Factor	Over-Ear
Color	Black
Manufacturer	Generic
Package Dimensions	21.6 x 14.2 x 8.4 cm
Item Weight	70 grams
Batteries	1 Lithium Polymer battery (Included)

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly. Specific warranty terms and support channels may vary by region and seller.