

## Fabater Fabater7cvpy2iarg

# Fabater Ferrofluid Speaker Music Mate User Manual

Model: Fabater7cvpy2iarg

## INTRODUCTION

---

The Fabater Ferrofluid Speaker Music Mate is a unique sound visualizer designed to display sound frequencies through the mesmerizing dance of magnetic fluid. This device enhances your audio experience by providing a dynamic visual representation of music or ambient sounds, making it an engaging desktop decoration.

## SAFETY INFORMATION

---

- Keep the device away from strong magnetic fields to prevent interference.
- Do not expose the device to extreme temperatures or direct sunlight.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to open or modify the device, as this may cause damage and void the warranty.
- Keep out of reach of children and pets.

## PACKAGE CONTENTS

---

Please check the package for the following items:

- 1 x Magnetic Fluid Pickup (Assembly parts x 2)
- 1 x Power Cable (Type-C)
- 1 x AUX Cable
- 1 x Handle Magnet



Image: The Fabater Ferrofluid Speaker Music Mate shown with its included accessories: a Type-C power cable, an AUX cable, and a handle magnet.

## SETUP

---

### Assembly

The Magnetic Fluid Pickup comes with two main assembly parts. To assemble, align the sealing protrusion of one part with the gap of the inner ring rubber ring on the other part. Gently press them together until they are securely connected.

# INSTRUCTIONS FOR USE




Image: A diagram illustrating the assembly process, showing how to align the two halves of the device and connect them.

## Charging

The device is powered by a built-in rechargeable battery. To charge, connect the provided Type-C cable to the charging port on the device and the other end to a 5V 1A power source (e.g., a USB wall adapter or computer USB port). The charging indicator light will illuminate during charging. A full charge provides approximately 6-8 hours of continuous operation.

## OPERATING MODES

The Fabater Ferrofluid Speaker Music Mate offers two operating modes: Sound-Pickup Mode and AUX Mode.

### 1. Sound-Pickup Mode

In this mode, the device's advanced built-in microphone captures ambient sound vibrations and translates them into dynamic movements of the ferrofluid. Simply place the device near your audio source (e.g., a speaker playing music) and power it on. The ferrofluid will dance in response to the sound. **Note: This device does not emit sound itself; it is a visualizer only.**

### 2. AUX Mode

For a direct and precise visual experience, use the AUX mode. Connect the provided AUX cable from your audio source (e.g., smartphone, computer, MP3 player) to the AUX in port on the device. The ferrofluid will then react directly to the audio signal received through the cable.

# INSTRUCTIONS FOR USE




Image: A diagram illustrating how to connect an audio source to the device using the AUX cable for AUX mode operation.

Video: Demonstration of the Ferrofluid Speaker Visualizer reacting to music, showcasing its dynamic magnetic fluid display.

Video: A closer look at the Ferrofluid Music Visualizer, highlighting the intricate movements of the magnetic liquid in response to sound.

## MAINTENANCE

- Clean the exterior of the device with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the charging port and AUX port are free from dust and debris.
- Store the device in a cool, dry place when not in use.

## TROUBLESHOOTING

- **Ferrofluid not moving:** Ensure the device is powered on and charged. Check if the audio source is playing and the volume is sufficient in Sound-Pickup mode, or if the AUX cable is securely connected in AUX mode.
- **Device not charging:** Verify that the Type-C cable is properly connected to both the device and a working 5V 1A power source. Try a different cable or power adapter.
- **Intermittent ferrofluid movement:** This could be due to low battery. Recharge the device. Also, ensure there are no strong electromagnetic interferences nearby.

## SPECIFICATIONS

Feature	Specification
Item Type	Magnetic Fluid Pickup
Size	Approx. 98 x 98 x 106mm / 3.86 x 3.86 x 4.17in
Battery Capacity	3000mAh (Built-in)
Input	5V 1A
Working Time (Full Charge)	6-8 hours
Operating Temperature	-10°C to 50°C
Product Dimensions	6.69 x 6.3 x 4.72 inches
Item Weight	1.98 pounds
Model Number	Fabater7cvpy2iarg



**Size: Approx. 98 x 98 x 106mm / 3.86 x 3.86x4.17in**

Image: The Fabater Ferrofluid Speaker Music Mate with its approximate dimensions indicated.

## **WARRANTY**

---

This product comes with a standard manufacturer's warranty. Please refer to the product packaging or contact customer support for specific warranty terms and conditions. The warranty typically covers defects in materials and workmanship under normal use.

## **SUPPORT**

---

For any questions, technical assistance, or support regarding your Fabater Ferrofluid Speaker Music Mate,

please contact our customer service team. You can find contact information on the product packaging or through the official Fabater website.

---

© 2024 Fabater. All rights reserved.