

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SIMATE](#) /

› [SIMATE Electric Scooter for Kids User Manual](#)

SIMATE Electric Scooter for Kids

SIMATE Electric Scooter for Kids User Manual

Model: Electric Scooter for Kids (ASIN: B0CRHNPY21)

1. PRODUCT OVERVIEW

The SIMATE Electric Scooter for Kids is designed for young riders aged 6-14 years, with a recommended height of 4.0 ft to 5.3 ft. This motorized e-scooter features a lightweight and foldable design, making it easy to store and transport. It includes a vibrant LED display, colorful front and pedal lights, and a robust dual braking system for enhanced safety.



Image: The SIMATE Electric Scooter in black, showcasing its sleek design and integrated colorful LED lights on the stem and footboard.

Key features include a powerful 130W motor, a top speed of 8.7 mph (14 km/h), and a maximum range of up to 5 miles (8 km) on a single charge. The scooter is equipped with solid anti-puncture rubber tires suitable for various terrains, ensuring a smooth and stable ride.

2. SETUP AND ASSEMBLY

Your SIMATE Electric Scooter comes partially assembled. Please follow these steps for initial setup:

1. Carefully remove all components from the packaging. The package includes the scooter, installation tools, a charger, and this instruction manual.
2. Unfold the scooter. Ensure the folding mechanism is securely locked into place before use.
3. Attach the handlebars if they are not already connected. Use the provided installation tools to tighten any necessary screws.
4. Before the first ride, fully charge the scooter's battery. Refer to the "Charging the Battery" subsection in the Operating section for detailed instructions.

FOLDABLE & LIGHTWEIGHT

Easy to Lift Up & Storage & Carry



Folded Size: 30.7*12.9*14.2 IN

Weight: 14LB = 14 Bottle Water

Image: The SIMATE Electric Scooter shown in its compact, folded state, demonstrating its portability and ease of storage.

The scooter features a start-up assist design for safety: the motor will not engage until the riding speed reaches approximately 2 mph (3.2 km/h). This design helps prevent accidental acceleration and provides a safer experience for young riders.

3. OPERATING INSTRUCTIONS

3.1. First Ride and Safety

Always wear appropriate safety gear, including a helmet, knee pads, and elbow pads, when riding the scooter. Ensure the rider's height is between 4.0 ft and 5.3 ft and they are within the age range of 6-14 years for optimal safety and control.

E-Scooter for Kids Ages 5-14



Range
5 Miles/40 mins

Charging
2-3 hour

Rider
4.0ft-5.3ft

Image: A young girl with a helmet standing next to the scooter, illustrating the recommended rider height and general usage.

3.2. Controls and Display

The scooter is equipped with an intuitive LED display and easy-to-use controls:

- **LED Display:** The large 2.8-inch LED digital dashboard accurately shows your current riding speed, selected speed gear, and remaining battery capacity.
- **Power Switch:** Located on the display unit, press to turn the scooter on or off.
- **Electronic Throttle:** Control your speed with the electronic throttle. The scooter can reach a top speed of 8.7 mph (14 km/h).
- **Electronic Brake:** Provides quick stopping power, especially at higher speeds.
- **Foot Brake:** Located on the rear wheel, this brake offers additional stopping control and helps prevent splashing in wet conditions.

Large-Sized LED Digital Dashboard

2.8-inch Effective Screen Size




Image: A detailed view of the scooter's LED digital dashboard, displaying speed and battery life indicators.

BEST GIFTS FOR KIDS

Rainbow LED Light



Birthday



Christmas



Halloween



Thanksgiving

Image: The scooter in use, highlighting the vibrant colorful front light and pedal lights that enhance visibility and style.

3.3. Riding Experience

The SIMATE Electric Scooter is designed for a smooth ride across various surfaces thanks to its solid anti-puncture rubber tires and dual suspension system. It is suitable for both off-road and commuting use.




Image: A visual representation of the scooter's durable rubber tires performing on various ground types, including paved roads and gravel.

For a visual demonstration of the scooter's features and operation, please watch the official product video below:

Your browser does not support the video tag.

Video: Official SIMATE Pro Electric Scooter overview, demonstrating its design and key functionalities. (Duration: 0:15)

4. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your SIMATE Electric Scooter.

4.1. Battery Charging

To charge the scooter, connect the provided charger to the charging port on the scooter and then to a standard power outlet. A full charge typically takes 2-3 hours. Do not overcharge the battery. Disconnect the charger once the battery indicator shows full.

4.2. Cleaning and Storage

- Wipe the scooter clean with a damp cloth after each use. Avoid using harsh chemicals or abrasive materials.
- Store the scooter in a cool, dry place, away from direct sunlight and extreme temperatures.
- When storing for extended periods, ensure the battery is partially charged (around 50%) to maintain battery health.

4.3. Tire and Brake Inspection

- Periodically inspect the solid anti-puncture rubber tires for any signs of wear or damage.
- Check the electronic and foot brakes regularly to ensure they are functioning correctly and provide adequate stopping power.

5. TROUBLESHOOTING

If you encounter any issues with your SIMATE Electric Scooter, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Scooter does not turn on.	Low battery or power switch off.	Ensure the battery is charged. Press and hold the power switch to turn on.
Scooter does not move when throttle is engaged.	Safety start-up assist not activated.	Push off with your foot to reach at least 2 mph (3.2 km/h) before engaging the throttle.
Battery not charging.	Charger not properly connected or faulty charger/battery.	Ensure charger is securely connected to both scooter and power outlet. Check if the charging indicator light is on. If the issue persists, contact customer support.
Lights are not working.	Loose connection or electrical issue.	Check for any visible loose connections. If problem persists, contact customer support.

For issues not listed here, or if the problem persists after attempting the solutions, please contact SIMATE customer support.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	SIMATE
Model Name	Electric Scooter for Kids
Color	black
Age Range (Description)	6-14 years
Rider Height	4.0 ft - 5.3 ft
Weight Limit	154 Pounds
Product Dimensions (LxWxH)	30.7" L x 12.9" W x 36.2" H
Number of Wheels	2
Wheel Material	Rubber
Wheel Type	Solid
Wheel Size	6.5 Inches
Frame Material	Aluminum
Handlebar Type	Fixed
Handle Height	36.2 Inches
Suspension Type	Dual Suspension
Brake Style	Dual Braking System (Electronic, Foot)
Motor Power	130W
Maximum Speed	8.7 mph (14 km/h)
Maximum Distance Range	5 Miles (8 km)
Charging Time	2-3 Hours
Recommended Uses	Off Road, Commuting
UPC	708436310617
Included Components	Scooter, Installation tools, Charger, Instruction Manual

7. WARRANTY INFORMATION

The SIMATE Electric Scooter comes with a **Lifetime Warranty**. This warranty covers manufacturing defects and ensures the product's quality and durability. For specific terms and conditions, please refer to the warranty documentation provided with your purchase or contact SIMATE customer support.

8. CUSTOMER SUPPORT




For further assistance, questions, or support regarding your SIMATE Electric Scooter, please utilize the following resources:

- **Official User Manual (PDF):** A comprehensive PDF version of this manual is available for download: [Download PDF Manual](#)
- **SIMATE Brand Store:** Visit the official SIMATE store for product information, FAQs, and contact options: [SIMATE Store on Amazon](#)
- **Contact Manufacturer:** For direct support, refer to the contact information provided in the product packaging or the official SIMATE website.

© 2024 SIMATE. All rights reserved.

Related Documents - Electric Scooter for Kids

 SIMATE Electric Scooter User Manual	<p>SIMATE Electric Scooter User Manual</p> <p>This user manual provides comprehensive instructions for the SIMATE Electric Scooter, covering package contents, installation, safety precautions, operation, charging, and maintenance. It is designed for children and includes multilingual content.</p>
 SIMATE Electric Scooter User Manual	<p>SIMATE Electric Scooter User Manual</p> <p>User manual for the SIMATE electric scooter, providing instructions on package contents, installation, safety precautions, operation, charging, and maintenance.</p>

 <p>SIMATE Electric Scooter User Manual</p>	<p>SIMATE Electric Scooter User Manual</p> <p>User manual for the SIMATE Electric Scooter, covering package contents, installation, safety precautions, operation, charging, and maintenance.</p>
 <p>SIMATE</p> <p>User Manual</p>	<p>SIMATE Self-Balancing Electric Scooter User Manual</p> <p>Comprehensive user manual for SIMATE self-balancing electric scooters, covering operation, safety, maintenance, and specifications for models like Apato, Tank, Mega, and Epic.</p>
 <p>SIMATE Hoverboard</p>	<p>SIMATE Hoverboard Electric Balance Scooter User Manual and Guide</p> <p>Comprehensive user manual for the SIMATE Hoverboard Electric Balance Scooter, covering setup, usage, safety, maintenance, troubleshooting, and disposal. Includes model specifications and app installation.</p>