

[manuals.plus](#) /

- › [SHIHOT](#) /
- › [SHIHOT 72-inch Large Ceiling Fan with Light and Remote User Manual](#)

SHIHOT 6667

SHIHOT 72-inch Large Ceiling Fan with Light and Remote (Model: 6667)

User Instruction Manual



1. PRODUCT OVERVIEW

The SHIHOT 72-inch Large Ceiling Fan is designed for both indoor and outdoor use, featuring a modern black finish and 8 reversible blades. It includes an integrated LED light with adjustable color temperature and dimming capabilities. The fan is equipped with a quiet DC motor offering 6 speed settings and a reversible function for year-round comfort. Control is convenient via the included remote or a dedicated mobile application.



Figure 1: SHIHOT 72-inch Large Ceiling Fan with remote and app interface.

2. SAFETY INFORMATION

Please read all instructions carefully before beginning installation. Improper installation or operation can lead to electric shock, fire, or personal injury. Retain this manual for future reference.

- Ensure power is disconnected at the circuit breaker before installation or maintenance.
- All electrical wiring must comply with national and local electrical codes. If unsure, consult a qualified electrician.
- Mount the fan to a ceiling outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the mounting screws provided with the outlet box.
- Do not bend the blade holders during installation, balancing, or cleaning.
- Avoid placing objects in the path of the rotating blades.
- This fan is suitable for damp locations, such as covered patios, but not for direct exposure to water.

3. PACKAGE CONTENTS

Verify all components are present and undamaged before beginning assembly. Refer to the installation video for visual identification of parts.

- Fan Motor Assembly
- Canopy
- Horn Hood
- Mounting Bracket
- Downrod (includes 8-inch and 16-inch options)
- Blades (8 pieces, reversible black/wood grain)
- LED Lampshade
- Blade Arms (4 pieces)
- Remote Control
- Instruction Manual
- Hardware Pack (screws, washers, wire nuts)




Figure 2: Fan dimensions and recommended room size (18FT*18FT to 25FT*25FT).

4. SETUP AND INSTALLATION

This section provides detailed steps for assembling and installing your SHIHOT ceiling fan. For a visual guide, please refer to the official installation video below.

Your browser does not support the video tag.

Video 1: SHIHOT Ceiling Fan Installation Guide. This video demonstrates the complete assembly and mounting process.

Assembly Steps:

1. **Assemble Blade Arms:** Attach the blade arms to the fan motor assembly using the provided screws. Ensure they are securely fastened.



Figure 3: Securely attach the blade arms to the motor housing.

2. **Attach Blades:** Select your preferred blade finish (wood grain or black). Align each blade with the pre-drilled holes on the blade arms and secure them with the designated screws.



Figure 4: Blades can be installed with either the wood grain or black side facing down.

3. **Install LED Light Kit:** Connect the LED light board to the fan motor's wiring. Carefully place the LED board into its designated slot and secure the lampshade.



Figure 5: The integrated LED light provides adjustable illumination.

4. **Prepare Downrod:** Insert the downrod through the canopy and horn hood. Feed the motor wires through the downrod. Secure the downrod to the fan motor assembly using the provided pin and screw.
5. **Mounting Bracket Installation:** Secure the mounting bracket to your ceiling outlet box. Ensure the bracket is firmly attached to a structural support capable of holding the fan's weight.
6. **Hang Fan Assembly:** Carefully lift the fan assembly and hang it on the mounting bracket. Ensure the ball joint of the downrod is properly seated in the bracket's opening.
7. **Electrical Connections:** Connect the fan's electrical wires to your household wiring according to the wiring diagram in the included manual. Typically, this involves connecting live, neutral, and ground wires. Ensure all connections are secure with wire nuts.
8. **Secure Canopy:** Slide the canopy up to the ceiling and secure it to the mounting bracket with the provided

screws, covering the electrical connections.

5. OPERATING INSTRUCTIONS

Your SHIHOT ceiling fan can be operated using the included remote control or a compatible mobile application. The fan features 6 speed settings, a reversible function, and a dimmable LED light with adjustable color temperature.

Your browser does not support the video tag.

Video 2: SHIHOT Ceiling Fan Features Overview. This video demonstrates the fan's various functions including speed, light, and reverse modes.

Remote Control Functions:

- **Fan Speed Control:** Adjust fan speed from 1 (lowest) to 6 (highest).
 - Speeds 1-2: Gentle air circulation, suitable for sleeping.
 - Speeds 3-4: Natural wind, ideal for daily use.
 - Speeds 5-6: Strong wind, effective for rapid cooling or exercise.




Figure 6: Six adjustable fan speeds for various comfort levels.

- **Light On/Off:** Toggle the LED light on or off.
- **Color Temperature Adjustment:** Cycle through warm light (3000K), natural light (4500K), and cool white light (6000K).



Figure 7: Choose from three light color temperatures to suit your ambience.

- **Dimming Function:** Adjust the brightness of the LED light from 0% to 100%.
- **Timer Setting:** Set the fan to automatically turn off after 1, 2, 4, or 8 hours.



Figure 8: The fan features a convenient timer function for up to 8 hours.

- **Reverse Function:** Press the 'R' key on the remote. The fan will stop completely and then automatically reverse direction.
 - Summer Mode (Forward Rotation): Creates a downward airflow, providing a cooling effect.
 - Winter Mode (Reverse Rotation): Creates an upward airflow, circulating warm air trapped near the ceiling.




Figure 9: Utilize the reversible function for optimal comfort in both summer and winter.

Mobile Application Control:

Download the compatible mobile application (refer to the included manual for QR code or app store details). The app allows for comprehensive control over all fan and light functions, similar to the remote control.

6. KEY FEATURES

- Quiet DC Motor:** The fan is equipped with a high-quality DC motor that ensures smooth, silent operation, providing a comfortable and peaceful environment. This motor is also energy-efficient, reducing electricity costs.




Figure 10: The efficient DC motor ensures quiet operation and energy savings.



Figure 11: Experience a quiet environment with the fan operating at approximately 30dB.

- Reversible Blades:** The 8 fan blades feature a dual-sided design, allowing you to choose between a classic black finish or a stylish wood grain finish to match your interior decor.



Figure 12: Customize your fan's appearance with reversible blades.

- Large Coverage:** With a 72-inch span, this fan is ideal for medium to large rooms, including living rooms, bedrooms, offices, studies, and kitchens, providing effective air circulation.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:**

- Always turn off the power at the circuit breaker before cleaning.
- Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- For the LED lampshade, wipe gently with a dry, lint-free cloth.

- **Blade Balance:** If the fan wobbles, check that all blade screws are tight. Minor wobbling can often be corrected using a fan blade balancing kit (not included).
- **Lubrication:** The DC motor is permanently lubricated and does not require additional oiling.

8. TROUBLESHOOTING

Before attempting any repairs, ensure power is disconnected at the circuit breaker.

Problem	Possible Cause	Solution
Fan does not start.	No power to the fan; loose wire connections; remote control battery low or not paired.	Check circuit breaker; verify all wire connections are secure; replace remote battery or re-pair remote.
Fan wobbles.	Loose blade screws; unbalanced blades; improper mounting.	Tighten all blade screws; use a balancing kit; ensure mounting bracket is securely installed.
Light does not work.	Loose wire connection to light kit; LED board failure; remote control issue.	Check light kit wiring; contact customer support if LED board is faulty; check remote battery/pairing.
Remote control not working.	Low battery; interference; not paired with fan.	Replace batteries (2 x 12V included); ensure no strong interference sources; follow pairing instructions in manual.
Fan makes noise.	Loose screws; internal motor issue; blades hitting an obstruction.	Check all screws; ensure no obstructions; if motor noise persists, contact support.

9. SPECIFICATIONS

- **Brand:** SHIHOT
- **Model Name:** 6667
- **Size:** 72 inches
- **Color:** Black
- **Material:** Plastic, Iron
- **Number of Blades:** 8 (Reversible)
- **Motor Type:** DC Motor
- **Speed Settings:** 6
- **Light Source:** Integrated LED
- **Color Temperature:** 3000K (Warm), 4500K (Natural), 6000K (Cool White)
- **Dimming:** Yes, 0-100%
- **Timer:** 1H, 2H, 4H, 8H
- **Control Method:** Remote Control, Mobile App

- **Voltage:** 120 Volts
- **Wattage:** 75 watts
- **Product Dimensions:** 72 x 72 x 15 inches
- **Item Weight:** 24.1 pounds
- **Recommended Room Size:** 18FT*18FT to 25FT*25FT
- **Included Components:** Light Kit, Remote Control, 2 x 12V Batteries (for remote)

10. WARRANTY AND SUPPORT

SHIHOT provides a limited warranty for this product. For detailed warranty information, including coverage period and terms, please refer to the warranty card included in your product packaging or visit the official SHIHOT website. For technical support, troubleshooting assistance, or replacement parts, please contact SHIHOT customer service through the contact information provided in your product manual or via the [SHIHOT Store on Amazon](#).

© 2025 SHIHOT. All rights reserved.