ZMISHIBO ZMCF008

ZMISHIBO 52 Inch Ceiling Fan with Light User Manual (Model ZMCF008)

Brand: ZMISHIBO

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your ZMISHIBO 52 Inch Ceiling Fan with Light. Please read this manual thoroughly before installation and use to ensure safe and efficient operation.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions.

- Read all instructions carefully before installing the fan.
- Ensure the installation site can support the fan's weight.
- All electrical connections must be made in accordance with local codes and ordinances.
- Turn off power at the circuit breaker before installation or servicing.
- Do not operate the fan with damaged blades.

PACKAGE CONTENTS

Verify that all parts are included in your package before beginning installation.

Image: All components of the ZMISHIBO 52 Inch Ceiling Fan, including blades, motor housing, light kit, remote control, and mounting hardware, laid out on a surface.

- Fan Motor Host
- Fan Blades (5)
- Blade Arms (5)
- LED Light Kit (20W, 2000LM)
- Remote Control (with 2 AAA batteries)
- Mounting Bracket
- Canopy
- Receiver
- Hardware Pack (screws, wire nuts, etc.)
- Instruction Manual

INSTALLATION GUIDE

Follow these steps for proper installation. It is recommended to have two people for certain steps.

Step 1: Prepare the Fan Assembly

6 Fan Speeds Adjustable

Image: Diagram illustrating the easy installation process of the ZMISHIBO 52 Inch Ceiling Fan, highlighting its 30-minute installation time and reduced electrical fees.

1. Remove the 10 arm screws from the host part of the fan motor.
2. Attach each blade arm to a fan blade using the provided screws. Ensure they are securely fastened.
3. Fix the assembled fan blades to the fan motor host using the previously removed screws.
4. Remove the three screws from the triangular plate on the fan motor.
5. Install the LED lamp panel onto the fan motor, securing it with the removed screws.
6. Connect the lamp wire to the LED panel.
7. Remove the pre-installed screws from the fan motor host.
8. Install the canopy onto the fan motor host and tighten the screws.
9. Attach the safety rope to a screw on the fan motor.

Step 2: Mount the Bracket and Wiring

Ensure power is OFF at the circuit breaker before proceeding.

10. Mount the bracket securely to the ceiling junction box using appropriate screws.
11. Hang the safety rope of the fan assembly onto the hook of the mounted bracket.
12. Connect the receiver and fan motor wires according to the wiring diagram in the manual.
13. Connect the "Neutral wire" (white) from the ceiling to the fan's neutral wire.
14. Connect the "Live wire" (black) from the ceiling to the fan's live wire.
15. Connect the "Ground wire" (green/copper) from the ceiling to the fan's ground wire.

Your browser does not support the video tag.

Video: Official ZMISHIBO 52 Inch Ceiling Fan Installation Guide. This video demonstrates the step-by-step process of assembling the fan and connecting it to the ceiling wiring, ensuring a secure and functional setup.

Step 3: Final Assembly

16. Secure the canopy to the ceiling bracket, ensuring all wires are tucked inside.
17. Screw the lampshade onto the light kit.

OPERATING INSTRUCTIONS

Remote Control Functions

Image: The ZMISHIBO 52 Inch Ceiling Fan highlighting its dual control options: a physical remote control and a smartphone application, showcasing various features like stepless color temperature, dimming, night light, and natural wind mode.

- **Fan ON/OFF:** Turns the fan on or off.
- **Fan Speed:** Select from 6 different fan speeds (1-2 for soft wind, 3-4 for natural wind, 5-6 for cool wind).
- **Light ON/OFF:** Turns the LED light on or off.

- **Dimming:** Adjusts the brightness of the LED light from 10% to 100%.
- **Color Temperature:** Changes the light color from warm white (3000K) to neutral white (4000K) to cool white (6500K).
- **Reversible Mode:** Changes the direction of the fan blades for summer (downward airflow) or winter (upward airflow).
- **Timer:** Set the fan to turn off automatically after 2 or 4 hours.
- **Memory Function:** The fan retains your last light settings (brightness and color temperature) when turned off and on again.

App Control Functions

The fan can also be controlled via a smartphone application. Ensure Bluetooth is enabled on your device.

Your browser does not support the video tag.

Video: Connection Tutorial for Smart Home Light APP. This video guides users through downloading the app, enabling Bluetooth access, and pairing the ZMISHIBO 52 Inch Ceiling Fan with the smartphone application for remote control.

1. Download the "Smart Home Light Pro" app from your device's app store (scan QR code in manual).
2. Enable Bluetooth on your smartphone.
3. Allow the app to access Bluetooth (for iPhone users, Android users can ignore this step).
4. Open the app, click the plus sign to add a group, then select "Fan" and click the plus sign again.
5. To pair, locate the "Pairing" button on the app, power on the fan with the wall switch (not the remote), and quickly click the pairing button once within 5 seconds. The light will blink twice to confirm pairing.
6. Once paired, you can control all fan and light functions directly from the app.

KEY FEATURES

- **Optimal Room Size:** Ideal for rooms with dimensions of 15FT x 15FT and ceiling heights between 8FT and 11FT.
- **Quiet Operation:** Equipped with a pure copper high-performance DC motor for strong airflow with minimal noise (around 30dB).
- **Reversible Air Circulation:** Switch between summer mode (downward airflow) and winter mode (upward airflow) for year-round comfort.
- **Durable Blades:** Features high-quality tough plywood blades for long-lasting performance and easy maintenance.
- **Integrated LED Light:** Dimmable 20W LED light with 2000LM brightness and stepless color temperature adjustment (3000K-6500K).

Image: Diagram illustrating the reversible air circulation feature of the ZMISHIBO 52 Inch Ceiling Fan, showing downward airflow for summer cooling and upward airflow for winter warmth distribution.

MAINTENANCE

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Balancing:** If the fan wobbles, use the included blade balancing kit to correct it.

- **Regular Checks:** Periodically check all connections and screws to ensure they are secure.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	Loose wiring, no power, remote not paired.	Check wiring connections, ensure power is on, re-pair remote/app.
Light does not work	Loose wire, LED panel issue.	Check light wire connection, contact support if LED panel is faulty.
Fan wobbles	Loose blades, unbalanced blades, improper mounting.	Tighten blade screws, use balancing kit, ensure mounting bracket is secure.
Remote not responding	Dead batteries, remote not paired.	Replace batteries, re-pair remote.

SPECIFICATIONS

- **Brand:** ZMISHIBO
- **Model Name:** BJ52 (ZMCF008)
- **Size:** 52 Inch
- **Color:** White
- **Power Source:** DC Motor
- **Wattage:** 20 watts (for LED light)
- **Luminous Flux:** 2000 lumen
- **Voltage:** 120 Volts (AC)
- **Air Flow Capacity:** 3057 Cubic Feet Per Minute
- **Number of Blades:** 5
- **Control Method:** App, Remote Control
- **Installation Type:** Flush Mount
- **Room Type:** Bedroom, Dining Room, Kitchen, Living Room
- **Item Weight:** 11.58 pounds

WARRANTY AND SUPPORT

ZMISHIBO Ceiling Fans with Light come with a **5-year motor support** and a **2-year support** on other parts. For any questions or support, please contact ZMISHIBO customer service.
We uphold the highest standards for all our products by testing each product for optimal performance.