

VIVOHOME VH1717-BK

VIVOHOME 42-inch Low Profile Ceiling Fan with Light and Remote

Model: VH1717-BK

1. SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to follow these instructions could result in electric shock, fire, or serious personal injury.

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All electrical connections must be in accordance with local codes, ordinances, or national electrical codes. If you are unfamiliar with electrical wiring, consult a qualified electrician.
- The fan must be mounted with a minimum of 7 feet (2.1 meters) clearance from the trailing edge of the blades to the floor.
- Do not bend the blade holders during installation, balancing, or cleaning the fan.
- Do not insert foreign objects between rotating fan blades.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Ceiling Fan Unit (Motor Housing, Downrod, Canopy)
- 3 Fan Blades (Dual-sided: Black and Wood Grain)
- LED Light Kit

- Remote Control
- Mounting Hardware (Mounting Bracket, Screws, Wire Nuts, etc.)



Image: Main components of the VIVOHOME 42-inch ceiling fan, including the fan unit, remote control, and reversible fan blades.

3. PRODUCT OVERVIEW

The VIVOHOME 42-inch Ceiling Fan is designed for optimal airflow and illumination, featuring advanced technology for energy efficiency and user comfort.

Key Features:

- **Energy-Efficient DC Motor:** Delivers powerful airflow while saving up to 80% on energy consumption compared to traditional fans.
- **Adjustable LED Lighting:** 18W LED light with three color temperature options (3000K Warm White, 4000K Natural Light, 6500K Cool Light) and stepless dimming from 10% to 100%.
- **Reversible Function:** Allows for downward airflow in summer for cooling and upward airflow in winter for improved warm air circulation.

- **6+1 Wind Speed Settings:** Includes 6 standard speeds and a Natural Breeze Mode for varied comfort levels.
- **Quiet Operation:** Operates at a low noise level of 35 dB, ideal for bedrooms and quiet environments.
- **Smart Sleep Timer:** Built-in timer for 1, 2, or 4 hours to automatically turn off the fan.
- **Memory Function:** The light will stay at its previous settings after being turned off for 10+ seconds and then back on.
- **Dual-Sided Blades:** Black and wood grain sides allow for customization to match your decor.

Energy-Efficient Ceiling Fan



Image: Illustration of the fan's energy efficiency, highlighting up to 80% energy savings.



3000K
Warm Light



4000K
Natural Light



6500K
Cool Light

Customizable Light for Every Mood

Image: Visual representation of the three color temperature options: warm white (3000K), natural light (4000K), and cool light (6500K).

All-Season Comfort

Reversible DC Motor



Image: Depiction of the reversible airflow function, showing downward airflow for summer cooling and upward airflow for winter heat circulation.

4. SETUP AND INSTALLATION

This section provides general guidelines for installing your VIVOHOME ceiling fan. Professional installation is recommended if you are not experienced with electrical wiring.

Installation Steps (Summary):

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Ensure the mounting location is structurally sound and can support the fan's weight.
2. **Install Mounting Bracket:** Secure the mounting bracket to the ceiling junction box using appropriate hardware.
3. **Assemble Fan Blades:** Attach the fan blades to the motor housing, ensuring the desired blade color (black or wood grain) is facing down.
4. **Wire the Fan:** Connect the fan's electrical wires to the household wiring according to the wiring diagram

provided in the detailed manual (not included here).

5. **Mount the Fan:** Carefully lift the fan assembly and attach it to the mounting bracket.
6. **Install Light Kit:** Connect and secure the LED light kit to the bottom of the fan motor housing.
7. **Restore Power:** Turn on the power at the circuit breaker and test the fan and light functions.

Ceiling Compatibility:

The VIVOHOME 42-inch ceiling fan is designed for flexible installation on both flat ceilings and sloped ceilings up to 15 degrees.



Image: Demonstrates the fan's compatibility with both flat and sloped ceilings (up to 15 degrees).

5. OPERATING INSTRUCTIONS

Your VIVOHOME ceiling fan is operated using the included remote control. Ensure batteries are installed correctly in the remote.

Remote Control Functions:



Image: Illustrates the ease of controlling the fan and light with the remote control.

- **Fan ON/OFF:** Press the fan icon button to turn the fan on or off.
- **Speed Control:** Use the '+' and '-' buttons to cycle through 6 fan speeds.
- **Natural Breeze Mode:** Activate this mode for an automatically adjusting wind speed that simulates a

gentle, natural airflow.

- **Light ON/OFF:** Press the light bulb icon button to turn the light on or off.
- **Color Temperature (CCT) Adjustment:** Press the 'CCT' button to switch between 3000K (warm white), 4000K (natural light), and 6500K (cool light).
- **Dimming:** Hold the '+' or '-' buttons on the light section of the remote to steplessly adjust brightness from 10% to 100%.
- **Timer:** Press the '1H', '2H', or '4H' buttons to set the fan to turn off automatically after 1, 2, or 4 hours, respectively.
- **Reversible Function:** Press the 'REV' button to change the direction of the fan blades (forward for summer, reverse for winter).
- **Mute Mode:** The remote includes a mute mode to eliminate operational beeps.

Wall Switch Compatibility:

The fan is compatible with traditional wall switches for basic ON/OFF control of both the fan and light. However, brightness and speed adjustments require the remote control. It is **not** compatible with rotary switches.



Image: Details on wall switch compatibility, showing it works with traditional switches but not rotary ones for full control.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To avoid damage to the finish, clean the fan with a soft, damp cloth only. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** Dust the fan blades regularly to prevent dust buildup, which can affect airflow and balance.
- **Tighten Screws:** Periodically check all screws on the fan and light kit to ensure they are tight. Loose screws can cause noise or wobble.
- **No Lubrication Needed:** The fan's motor is permanently lubricated and does not require oiling.

7. TROUBLESHOOTING

If you encounter issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker; Verify all wire connections are secure; Replace remote battery or re-pair remote.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) to balance blades; Ensure mounting bracket is securely fastened.
Light does not work	Loose wire connection to light kit; LED light kit failure.	Check light kit wiring; Contact customer support for replacement if LED is faulty.
Remote control not working	Low or dead battery; Remote not paired with fan; Obstruction between remote and receiver.	Replace battery; Follow pairing instructions (if applicable); Ensure clear line of sight to fan.

8. SPECIFICATIONS

Detailed technical specifications for the VIVOHOME 42-inch Ceiling Fan.


Feature	Specification
Brand	VIVOHOME
Model Name	Ceiling Fan (VH1717-BK)
Size	42 inch
Color	Black
Material	Acrylonitrile Butadiene Styrene, Aluminum
Product Dimensions	42"L x 42"W x 9.8"H
Power Source	DC
Voltage	220 Volts
Wattage	30 watts
Light Source Type	LED (18W)
Light Color Temperature	3000K, 4000K, 6500K
Control Method	Remote Control

Feature	Specification
Sound Level	35 dB
Installation Type	Flush Mount
Item Weight	8.1 Pounds

Specification

Package size: 17.1" x 13.2" x 7.5"

Package weight: 11.0 lb



Room Size

10ft x 10ft to
15ft x 15ft



Image: Detailed dimensions of the VIVOHOME 42-inch ceiling fan and recommended room sizes (10ft x 10ft to 15ft x 15ft).

9. WARRANTY AND SUPPORT

VIVOHOME products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official VIVOHOME website.

If you require technical assistance, troubleshooting, or have questions regarding your product, please contact VIVOHOME customer support through their official channels. Keep your purchase receipt and model number

(VH1717-BK) handy for faster service.

For more information about VIVOHOME and their product range, you can visit their Amazon store:[VIVOHOME Amazon Store](#).