Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Ashland /
- > Ashland Gold Star 10-Light Christmas Tree Topper Instruction Manual

Ashland Gold Star 10-Light Christmas Tree Topper

Ashland Gold Star 10-Light Christmas Tree Topper Instruction Manual

Model: Gold Star 10-Light Christmas Tree Topper

INTRODUCTION

This manual provides instructions for the safe assembly, operation, and maintenance of your Ashland Gold Star 10-Light Christmas Tree Topper. Please read all instructions carefully before use and retain this manual for future reference.

SAFETY INFORMATION

WARNING: To reduce the risk of fire and electric shock:

- Do not install on trees having needles, leaves, or branch coverings of metal or materials that look like metal.
- Do not mount or support strings in a manner that can cut or damage wire insulation.
- This product is for indoor use only.
- Unplug the topper from the power outlet when not in use or when changing bulbs.
- Do not overload electrical outlets.
- · Keep away from children and pets.
- Inspect the product carefully before each use. Discard if any wires are frayed or insulation is damaged.

PACKAGE CONTENTS

Verify that all components are present before proceeding with setup.

• 1 x Ashland Gold Star 10-Light Christmas Tree Topper (with 10 clear lights and white cord)



Image Description: The image displays the Ashland Gold Star 10-Light Christmas Tree Topper packaged in its retail box. The star-shaped topper, featuring a gold glitter finish and intricate wire design, is visible through a clear plastic window. White electrical cords and small clear bulbs are intertwined within the star's structure. The base of the topper, a coiled spring, is also visible. The packaging is white with red accents at the bottom, indicating "10 clear lights", "White cord", and "1 pc". The brand "Ashland" and "LIGHTED TREE TOPPER" are printed on the box.

SETUP INSTRUCTIONS

- 1. **Unpack:** Carefully remove the tree topper from its packaging. Retain packaging for off-season storage.
- 2. **Inspect:** Before plugging in, inspect the topper, cord, and bulbs for any damage. Do not use if damaged.
- 3. **Placement:** Position the coiled spring base of the topper securely over the top-most branch of your Christmas tree. Ensure the topper is stable and upright.
- 4. **Cord Management:** Route the white electrical cord down the back of the tree, ensuring it is not pinched or tangled.

5. **Connect Power:** Plug the electrical cord into a standard 120V AC indoor electrical outlet.

OPERATING INSTRUCTIONS

The Ashland Gold Star 10-Light Christmas Tree Topper is designed for simple operation.

- To Turn On: Plug the topper's electrical cord into a live 120V AC indoor outlet. The 10 clear lights will illuminate.
- To Turn Off: Unplug the topper's electrical cord from the outlet.

For convenience, consider using a timer (sold separately) to automate the on/off cycle.

MAINTENANCE

- **Cleaning:** Disconnect from power before cleaning. Gently wipe the topper with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Bulb Replacement:** If a bulb burns out, unplug the topper. Carefully pull the faulty bulb straight out from its socket. Replace with a new 2.5-volt, 0.17-watt miniature push-in type bulb (not included). Ensure the replacement bulb matches the original specifications.
- **Storage:** When not in use, unplug the topper and allow it to cool completely. Store in its original packaging or a protective container in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------------------------|--|---|
| Lights do not illuminate. | Not plugged in. Power outlet is not active. One or more bulbs are loose or burnt out. Damaged cord or wiring. | Ensure the plug is fully inserted into a working outlet. Test the outlet with another device. Check all bulbs for tightness and replace any burntout bulbs. If the cord or wiring is damaged, discontinue use and discard the product. |

SPECIFICATIONS

• Product Name: Ashland Gold Star 10-Light Christmas Tree Topper

• Brand: Ashland

• Model: Gold Star 10-Light Christmas Tree Topper

ASIN: B0DQJ2P2QLUPC: 195158572667

• Lights: 10 Clear Incandescent Lights

· Cord Color: White

• Theme: Star

• Item Weight: 1 pound (454 Grams)

• Power Source: Corded Electric (120V AC, for indoor use)

WARRANTY AND SUPPORT

Specific warranty information for the Ashland Gold Star 10-Light Christmas Tree Topper is not provided within this manual. For warranty details, product support, or to inquire about replacement parts, please refer to the original product packaging or visit the official Ashland brand website.


You may also contact the retailer where the product was purchased for further assistance.

Related Documents - Gold Star 10-Light Christmas Tree Topper



Ashland 7.5' Melody Spruce Artificial Christmas Tree Assembly and Care Guide

This guide provides instructions for assembling, setting up, storing, and troubleshooting the Ashland 7.5' Melody Spruce artificial Christmas tree. It includes details on the WRGB remote and speaker functions, safety warnings, and limited warranty information.



Ashland TG76P5479C03/TG76P5479C04 Christmas Tree Assembly Instructions

Detailed assembly, setup, and storage instructions for the Ashland TG76P5479C03/TG76P5479C04 pre-lit Christmas tree. Includes troubleshooting tips and customer service contact information.



Ashland Christmas Tree Assembly and Setup Guide (Model TG76P5458D00)

Detailed assembly instructions, storage tips, troubleshooting guide, and customer service information for the Ashland TG76P5458D00 Christmas tree with Quick Set® technology.



Ashland PolyTraps Grease Trap & Interceptor Installation & Maintenance Guide

This guide provides essential installation and maintenance instructions for Ashland PolyTraps Grease Traps and Grease Interceptors, including Series 4800 and APGI models. Learn about the product's function, proper installation procedures, and recommended maintenance practices to ensure optimal performance and longevity.



Ashland Full Synthetic SAE 0W-20 Motor Oil Safety Data Sheet

Safety Data Sheet for Ashland Full Synthetic SAE 0W-20 Motor Oil, providing detailed information on hazards, first aid, handling, storage, and regulatory information.



Ashland Zerex G-93 - 94 Antifreeze Coolant Safety Data Sheet

Safety Data Sheet for Ashland Zerex G-93 - 94 Antifreeze Coolant (ZXG935), providing comprehensive information on hazards, composition, first aid, firefighting, handling, storage, exposure controls, physical and chemical properties, stability, toxicology, ecological information, disposal, transport, and regulatory compliance.