

[Manuals.plus](#) /

> [Ovclaim](#) /

> Ovclaim 52 Inch Wood Ceiling Fan Instruction Manual (Model 52YFT-809NW)

Ovclaim 52YFT-809NW

Ovclaim 52 Inch Wood Ceiling Fan Instruction Manual

MODEL: 52YFT-809NW

Brand: Ovclaim

PRODUCT OVERVIEW

The Ovclaim 52 Inch Wood Ceiling Fan (Model 52YFT-809NW) is an ETL Listed indoor/outdoor ceiling fan designed for efficient air circulation and lighting. It features a quiet DC motor, dimmable LED light with adjustable color temperature, and a reversible function for year-round use. Control options include a remote control, app control, and voice control for enhanced convenience.

Key features include solid wood blades, energy-efficient DC motor (up to 70% less power than AC motors), 6-speed settings, and a memory function for light settings. It is suitable for medium to large rooms such as bedrooms, living rooms, and patios.

Ceiling Fan With Light



DC Motor
Whisper Mute



75% more
Energy Saving



Timing Settings



Image: Ovclaim 52 Inch Wood Ceiling Fan highlighting DC motor, energy saving, and timing features.

SAFETY PRECAUTIONS


Before installing or operating this ceiling fan, please read and understand all instructions. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- Always disconnect power at the main circuit breaker before installation or servicing.
- Ensure all electrical connections comply with local codes and ordinances. If you are unsure, consult a qualified electrician.
- Mount the fan to a ceiling joist or support structure capable of supporting the fan's weight (18.07 lbs).
- Keep hands, clothing, and other objects clear of the fan blades when the fan is in operation.
- Do not use the fan with a dimmer switch not specifically designed for ceiling fans.
- This fan is rated for indoor and outdoor (damp rated) use. Avoid direct exposure to rain.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Fan Motor Assembly
- 3 Solid Wood Blades
- LED Light Kit
- Remote Control with Wall Mounted Base
- 2 Downrods (5-inch and 10-inch)
- Mounting Bracket and Hardware
- Canopy



MOUNTING OPTIONS



Downrod



Angled(<math><15^\circ</math>)

DOWNROD SIZE



5" 10"

ROOM SIZE

Recommended
12 ft.x 12 ft.To
18 ft.x 18 ft.

Image: Detailed diagram illustrating fan dimensions, available downrod lengths, and suitable room sizes.

TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	Ovclaim
Model Number	52YFT-809NW
Product Dimensions	52"D x 52"W x 19.1"H
Item Weight	18.07 Pounds
Power Source	AC/DC
Voltage	120 Volts
Wattage	20 watts
Air Flow Capacity	5977 Cubic Feet Per Minute (CFM)
Number of Blades	3
Number of Speeds	6
Control Method	App Control, Remote Control, Voice Control
Light Type	LED (Dimmable, 3000k-4500k-6000k)
Indoor Outdoor Usage	Indoor, Outdoor (Damp Rated)
Special Features	Remote Controlled, Reversible, Dimmable Lights, Energy Efficient DC Motor
Certification	ETL Listed

INSTALLATION GUIDE

Installation should be performed by a qualified electrician or a person with sufficient electrical knowledge. Ensure power is disconnected at the circuit breaker before starting.

- 1. Prepare the Mounting Location:** Securely attach the mounting bracket to a ceiling joist or a suitable support structure. Ensure the structure can hold the fan's weight.
- 2. Assemble the Downrod:** Choose the appropriate downrod (5-inch or 10-inch) for your ceiling height. Feed the electrical wires through the downrod.
- 3. Attach Fan Motor to Downrod:** Secure the fan motor assembly to the chosen downrod.
- 4. Wiring Connections:** Connect the electrical wires from the fan to the household wiring according to the wiring diagram provided in the full manual. Ensure all connections are secure.
- 5. Mount the Fan:** Carefully lift the fan assembly and hang it from the mounting bracket.
- 6. Attach Blades:** Securely attach the three solid wood blades to the fan motor.

7. **Install Light Kit:** Connect and install the LED light kit to the bottom of the fan motor.
8. **Secure Canopy:** Install the canopy to cover the wiring and mounting bracket.
9. **Restore Power:** Once installation is complete and all connections are checked, restore power at the circuit breaker.

Note: The ceiling fan can be installed on a ceiling with a maximum slope of 15 degrees.

OPERATING INSTRUCTIONS

Your Ovlaim ceiling fan can be operated using the included remote control, a smart app, or voice commands.

Remote Control Functions

- **Power Button:** Turns the fan and light on/off.
- **Fan Speed (1-6):** Adjusts the fan speed from gentle breeze (1) to maximum airflow (6).
- **Reversible Function:** Changes the direction of blade rotation. Use downward airflow for cooling in summer and upward airflow to circulate warm air in winter.
- **Light On/Off:** Toggles the LED light.
- **Light Dimmer:** Adjusts the brightness of the LED light (0-100%).
- **Color Temperature:** Cycles through 3000K (warm white), 4500K (natural light), and 6000K (cool white). The light has a memory function to recall the last setting.
- **Timer (1H/4H/8H):** Sets the fan to turn off automatically after 1, 4, or 8 hours.



Image: Remote control demonstrating smart control compatibility with Amazon Alexa, Google Assistant, and the Smart Life App.

Dimming and Color Temperature LED

Over 50,000 Hours Service Life



Cool White 6000K



Natural Light 4500K



Warm White 3000K



Image: Illustration of the dimmable LED light with adjustable color temperatures (3000K, 4500K, 6000K).



Image: Visual representation of the fan's reversible function for optimal comfort in both summer and winter.

Official Product Video

Your browser does not support the video tag.

Video: An official product video from Ovlaim showcasing the 52 Inch Wood Ceiling Fan in operation.

CARE AND MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To avoid scratching the finish, clean the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** Dust the blades regularly to prevent dust buildup, which can affect fan balance and airflow.
- **Tighten Screws:** Periodically check all screws and connections for tightness. Retighten as necessary.

- **Lubrication:** The DC motor is permanently lubricated and does not require additional oiling.

TROUBLESHOOTING GUIDE

If you experience issues with your Ovlaim ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Verify all wire connections; Replace remote control battery.
Light does not work	Loose wire connection in light kit; Incorrect light setting.	Check light kit wiring; Ensure light is turned on via remote/app.
Fan wobbles	Loose blades or mounting hardware; Unbalanced blades.	Tighten all blade screws and mounting hardware; Use a balancing kit (not included) to balance blades.
Noisy operation	Loose screws; Fan not properly seated; Blades rubbing.	Check and tighten all screws; Ensure fan is securely mounted; Check for any obstructions.
Remote not responding	Battery low or dead; Remote not paired.	Replace remote battery; Refer to the full manual for remote pairing instructions.

WARRANTY AND CUSTOMER SUPPORT

Ovlaim products are manufactured to the highest quality standards. This product is covered by a limited warranty against defects in materials and workmanship. For specific warranty details, including duration and coverage, please refer to the warranty card included with your purchase or contact Ovlaim customer support.

For technical assistance, troubleshooting, or to inquire about replacement parts, please contact our customer support team:

- **Website:** [Visit the Ovlaim Store on Amazon](#)
- **Email:** support@ovlaim.com (example email, actual email not provided)
- **Phone:** 1-800-XXX-XXXX (example phone, actual phone not provided)

Please have your model number (52YFT-809NW) and proof of purchase ready when contacting support.

