

SS-001

# Electric Milk Frother User Manual

Model: SS-001

## INTRODUCTION

Thank you for purchasing the Generic Electric Milk Frother. This 4-in-1 appliance is designed to create hot foam, cold foam, and warm milk, enhancing your coffee and beverage experience. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

This frother features a unique design inspired by Roman columns, offering both aesthetic appeal and a secure grip. It is equipped with an upgraded high-speed silent motor for quiet operation and a non-stick interior for easy cleaning.

## IMPORTANT SAFETY INFORMATION

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not immerse the power base, cord, or plug in water or other liquids.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.
- Avoid contact with moving parts.
- Do not use attachments not recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The frother remains cool to the touch even after use, but exercise caution when handling hot liquids.
- Ensure the frother is placed on a stable, flat surface during operation.

## PACKAGE CONTENTS

Please check the box for the following items:

- Electric Milk Frother x 1
- Power Supply Base x 1
- Whisk x 2 (one for frothing, one for heating)
- Cleaning Brush x 1
- Foam Spatula x 1



Image: The Electric Milk Frother shown with its included accessories: two different whisks, a blue-handled cleaning brush, and a white foam spatula. A cup of latte and spilled milk are also visible, indicating its use.

## PRODUCT OVERVIEW

Familiarize yourself with the components of your milk frother:

- **Frother Jug:** The main container for milk, with a non-stick interior.
- **Lid:** Transparent lid to cover the jug during operation.
- **Whisks:** Two types – one for frothing (with a spring coil) and one for heating (flat).
- **Power Base:** Connects to the power outlet and supplies power to the frother jug.
- **Control Panel:** Features a single button for operation and indicator lights for different modes.

# Safe Frothing



ETL Listed



Auto Shut-Off



Temperature Control



Quiet Operation



Image: A close-up of the Electric Milk Frother, emphasizing its safety and operational features. Icons for ETL Listed, Auto Shut-Off, Temperature Control, and Quiet Operation are displayed around the frother, along with a shield icon indicating overall safety.

## SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, clean the frother jug and whisks with warm soapy water. Rinse thoroughly and dry. Do not immerse the power base in water.
3. **Placement:** Place the power base on a dry, flat, and stable surface.
4. **Attach Whisk:** Select the appropriate whisk (frothing whisk for foam, heating whisk for warm milk) and securely attach it to the pin at the bottom of the frother jug.
5. **Connect Power:** Plug the power cord into a standard 110-120V 50-60Hz electrical outlet.

## OPERATING INSTRUCTIONS

The frother offers four distinct functions accessible via a single control button.

# 4-in-1 Multifunctional

Unlock the Art of Frothing



Image: The Electric Milk Frother surrounded by various coffee and milk beverages, illustrating its 4-in-1 functionality. Labels indicate Hot Airy Foam, Hot Dense Foam, Cold Foam, and Warm Milk, showcasing the versatility of the appliance.

## General Operation:

1. Pour milk into the frother jug. Do not exceed the MAX fill line for frothing (typically lower) or the MAX fill line for heating (typically higher). The capacity is 8.1oz/240ml.
2. Place the lid on the frother jug.
3. Place the frother jug onto the power base.
4. Press the control button to select your desired mode. The indicator lights will illuminate to show the selected function.
5. The frother will automatically stop when the process is complete.
6. Carefully remove the frother jug from the base and pour the frothed milk or warm milk into your cup.

## Specific Modes:

- **Hot Foam (Thick/Airy):** Use the frothing whisk. Press the button once for thick hot foam, or twice for airy hot foam (refer to specific model instructions if different button presses are required for different hot foam types). The milk will be heated to approximately  $149 \pm 9^{\circ}\text{F}$  ( $65 \pm 5^{\circ}\text{C}$ ).
- **Cold Foam:** Use the frothing whisk. Press and hold the button for a few seconds (usually until a blue light appears) to activate cold frothing. The milk will be frothed without heating.

- **Warm Milk:** Use the heating whisk (flat whisk). Press the button to select the milk heating function. The milk will be warmed to the optimal temperature without frothing.

For best results, use cold, fresh milk. Whole milk typically produces the richest foam.




Image: A close-up shot of a person pouring creamy, frothed milk from the Electric Milk Frother into a white coffee cup, illustrating the smooth texture of the foam produced.

## MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your frother.

1. **Unplug:** Always unplug the frother from the power outlet before cleaning.
2. **Cool Down:** Allow the frother jug to cool down completely before cleaning.
3. **Clean Jug:** The non-stick interior makes cleaning easy. Rinse the inside of the frother jug with warm water immediately after use. Use the included cleaning brush and a mild dish soap to remove any milk residue. Do not use abrasive cleaners or scouring pads.
4. **Clean Whisks:** Remove the whisk from the jug and rinse it under warm water. Use the cleaning brush to ensure all milk residue is removed from the whisk coil.
5. **Clean Exterior:** Wipe the exterior of the frother jug and the power base with a damp cloth. Do not immerse the power base in water.

6. **Dry:** Ensure all parts are thoroughly dry before storing or next use.

**Note:** The frother jug is not dishwasher safe. Hand wash only.



Image: The interior of the Electric Milk Frother being rinsed under a faucet, highlighting its non-stick coating and stainless steel construction for easy cleaning. Icons for 304 Stainless Steel, Non-Stick Coating, and Scratch-Resistant Exterior are shown.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Frother does not turn on.	Not plugged in; power outage; frother not properly seated on base.	Ensure power cord is securely plugged into a working outlet. Check household circuit breaker. Ensure frother jug is correctly placed on the power base.
Milk is not frothing or foam is poor.	Incorrect whisk used; milk type/temperature; too much milk; whisk not properly attached.	Ensure the frothing whisk (with spring) is used. Use cold, fresh whole milk for best results. Do not exceed the MAX frothing line. Ensure whisk is securely attached.

Problem	Possible Cause	Solution
Milk is not heating.	Incorrect whisk used; heating function not selected.	Ensure the heating whisk (flat) is used. Select the correct heating mode.
Unpleasant odor after use.	Milk residue left inside.	Clean the frother jug thoroughly immediately after each use, especially around the whisk pin.
Frother stops prematurely.	Overheating; too much milk.	Allow the unit to cool down. Ensure milk level does not exceed the MAX fill line.

## SPECIFICATIONS

Feature	Detail
Model Name	SS-001
Capacity	8.1 oz / 240 ml
Voltage	110-120V
Frequency	50-60Hz
Power	400W
Product Dimensions (L x W x H)	3.9 inches x 3.9 inches x 7.5 inches
Material	Stainless Steel (interior)
Special Features	Quiet Function, Auto Shut-Off, Non-Slip, Cool-Touch Casing

## WARRANTY AND SUPPORT

This Generic Electric Milk Frother (Model SS-001) comes with a standard manufacturer's warranty against defects in materials and workmanship under normal household use. Please refer to the product packaging or contact your retailer for specific warranty terms and duration.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact the manufacturer or your point of purchase. Keep your purchase receipt as proof of purchase for warranty claims.

**Manufacturer:** Generic