

Manuals.plus /

› blonbar /

› blonbar Aurora Effect Wake-Up Light Alarm Clock (Model AJ350B) - User Manual

blonbar AJ350B

blonbar Aurora Effect Wake-Up Light Alarm Clock (Model AJ350B) - User Manual

Model: AJ350B

1. INTRODUCTION

Thank you for choosing the blonbar Aurora Effect Wake-Up Light Alarm Clock. This device is designed to enhance your sleep and wake-up experience with its unique aurora light effects, natural sounds, and customizable alarm settings. Please read this manual carefully to ensure proper use and maintenance of your product.

2. SAFETY INFORMATION

- Ensure the product is connected to a power source with the correct voltage as specified.
- Do not immerse the device in water or expose it to excessive moisture.
- Keep the device away from heat sources, direct sunlight, and flammable materials.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- This product is intended for indoor use only.

3. PACKAGE CONTENTS

Upon opening the package, please verify that all items are present:

- blonbar Aurora Effect Wake-Up Light Alarm Clock (Model AJ350B)
- Power Adapter
- User Manual

4. PRODUCT OVERVIEW

The blonbar Aurora Effect Wake-Up Light Alarm Clock features a sleek design with intuitive controls. Key components include:

- **Digital Time Display:** Shows current time and alarm settings.
- **Light Panel:** Emits wake-up light, aurora effects, and serves as a night lamp.
- **Control Buttons:** For setting time, alarms, sounds, and light modes.
- **Snooze Button/Joystick:** Activates snooze and adjusts screen brightness.
- **Speaker:** For natural sounds and alarm tones.



Figure 1: blonbar Aurora Effect Wake-Up Light Alarm Clock (Model AJ350B)

5. SETUP

5.1 Power Connection

1. Connect the provided power adapter to the device's power input port.
2. Plug the adapter into a standard electrical outlet. The device requires continuous power to operate.



Figure 2: Connecting the power adapter to the blonbar alarm clock.

6. OPERATING INSTRUCTIONS

6.1 Setting Time and Alarms

The clock supports 12H/24H time display. It features two independent alarms (Alarm 1 and Alarm 2) that can be customized.

1. **To Set Time:** Press and hold the 'Time' button (usually indicated by a clock icon) to enter time setting mode. Use the adjustment buttons (or rotary knob if available) to set the hour and minute. Press the 'Time' button again to confirm.
2. **To Set Alarm 1 (Wake-up Light Alarm):** Press and hold the 'Alarm 1' button (bell icon with '1'). Set the desired wake-up time. This alarm includes a gradual light increase.
3. **To Set Alarm 2 (Standard Alarm):** Press and hold the 'Alarm 2' button (bell icon with '2'). Set the desired

alarm time. This is a standard alarm without the gradual light feature.

4. **Snooze Function:** When an alarm sounds, briefly press the SNOOZE button/joystick to activate a 10-minute snooze. This can be used up to 3 times.

Your browser does not support the video tag.

Video 1: Demonstration on how to set and turn off alarms on a similar device.



Figure 3: Setting up dual alarms for personalized wake-up experiences.

Snooze e schermo digitale dimmerabile

Premere il joystick per entrare in modalità snooze dopo lo squillo della sveglia. Regolare la luminosità dello schermo digitale




Figure 4: Using the snooze function and adjusting screen brightness.

6.2 Wake-Up Light Function

Alarm 1 features a gentle wake-up light that simulates the sunrise. The light gradually changes from a soft red to orange and then to warm yellow, increasing in intensity over 15 minutes before the set alarm time. This helps you wake up more naturally.

Luce di sveglia con simulazione dell'alba

La luce di sveglia imita l'alba e inizia a brillare 15 minuti prima del suono dell'allarme.



Figure 5: The gradual transition of the wake-up light simulating sunrise.

6.3 Aurora Effect Light

The device offers a variety of RGB aurora ambient light effects to create a fantastic atmosphere in your room. Short press the light button to cycle through colors, and long press to turn off the RGB light. A long press on the touch area can also adjust the brightness of the warm light.

Your browser does not support the video tag.

Video 2: Demonstration of the ambient light with changing colors.

Un bagliore luminoso e colorato

Le vibranti luci dell'aurora adornano le vostre notti, creando un'atmosfera romantica e sognante.



Premere brevemente per accendere la luce RGB
alternare il colore
Premere a lungo per spegnere la luce RGB



Tocco breve per attivare
disattivare la luce calda
Tocco lungo per regolare la luminosità



Figure 6: Various aurora light effects for creating different room atmospheres.

6.4 Natural Sounds & Sleep Aid

The alarm clock includes 10 built-in natural sounds, such as birdsong, rain, flowing water, and bonfire, to help you relax and fall asleep. You can set a countdown timer (30/60/90 minutes) for the music to automatically turn off, accompanying you to peaceful sleep.

Suoni della natura e partner per il sonno

Scegliete un conto alla rovescia di 30/60/90 minuti e i vostri suoni della natura preferiti per accompagnarvi nel sonno



Figure 7: The natural sounds feature acting as a sleep partner.

6.5 Night Lamp & Brightness Adjustment

The light panel can function as a night lamp with stepless dimming. Simply press and hold the touch area to adjust the brightness to your ideal level, from 0% to 100%.

Lampada touch a regolazione stepless

Premi brevemente per accendere/spegnere la luce.
Premi a lungo per la regolazione stepless e scegli il tuo livello ideale di luminosità.




Figure 8: Adjusting the night lamp brightness with stepless control.

7. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place when not in use for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Power adapter not connected or faulty.	Ensure the power adapter is securely connected to both the device and the power outlet. Try a different outlet.
Alarm does not sound.	Alarm not set correctly or volume too low.	Verify alarm settings and ensure the alarm volume is not set to zero.
Wake-up light does not activate.	Alarm 1 not set or set incorrectly.	Ensure Alarm 1 is activated and set for the desired time. Remember the light starts 15 minutes before the alarm.
Screen brightness is too high/low.	Brightness setting needs adjustment.	Use the SNOOZE button/joystick to adjust the screen brightness.

9. SPECIFICATIONS

Feature	Detail
Brand	blonbar
Model Number	AJ350B
Product Dimensions	5 x 15 x 18.3 cm
Item Weight	650 grams
Material	Plastic
Color	Beige Grey
Light Type	LED
Power Source	Corded Electric
Switch Style	Touch
Special Features	Memory Function, Dimmer
Number of Alarms	2
Natural Sounds	10 types (e.g., birds, rain, water, bonfire)

10. WARRANTY AND SUPPORT

For any issues or questions regarding your blonbar Aurora Effect Wake-Up Light Alarm Clock, please contact our customer support team. We are committed to providing appropriate solutions and assistance.

