

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [RECCAZR](#) /

› [RECCAZR Wireless Keyboard and Mouse Combo User Manual](#)

## RECCAZR B0DSL6KC1

# RECCAZR Wireless Keyboard and Mouse Combo User Manual

Model: B0DSL6KC1

## 1. INTRODUCTION

---

Thank you for choosing the RECCAZR Wireless Keyboard and Mouse Combo. This product is designed to provide a comfortable and efficient typing and navigation experience with its ergonomic design and reliable 2.4Ghz wireless connection. Please read this manual carefully before use to ensure proper operation and maintenance.

### Package Contents:

- Wireless Ergonomic Keyboard
- Wireless Ergonomic Mouse
- USB Nano Receiver (stored inside the mouse battery compartment)
- User Manual



Image: The RECCAZR Wireless Ergonomic Keyboard and Mouse Combo, showing the full-size keyboard with wave keys, the ergonomic mouse, and the small USB nano receiver.

## 2. SETUP GUIDE

---

### 2.1 Battery Installation

The keyboard requires 1 AA battery and the mouse requires 1 AA battery (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the underside of the keyboard and mouse.
2. Open the battery compartment cover.
3. Insert the AA battery(s) into the compartment, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

# SILENT ERGONOMIC MOUSE



Image: Diagram illustrating the battery compartments for both the keyboard and mouse, highlighting the ON/OFF switches and the requirement for 1 AA battery each.

## 2.2 Connecting the Devices

The keyboard and mouse share a single USB nano receiver for a stable 2.4Ghz wireless connection.

1. Locate the USB nano receiver. It is typically stored in the battery compartment of the mouse for safekeeping.
2. Remove the USB nano receiver from the mouse.
3. Plug the USB nano receiver into an available USB port on your computer (desktop, laptop, PC).
4. Turn on the keyboard and mouse using their respective ON/OFF switches, usually located on the underside of each device.
5. The devices are plug-and-play and should connect automatically within a few seconds. No additional drivers or software are required.



Image: Visual representation of the 2.4Ghz wireless connection, showing the USB receiver, wireless signal, and effective range of up to 33 feet (10 meters).

## 3. OPERATING INSTRUCTIONS

### 3.1 Keyboard Functions

The keyboard features a full-size 104-key layout with a numeric keypad and multimedia function keys.

- **Ergonomic Wave Keys:** The scientific wave keys design and curved surface layout are engineered for natural typing posture, reducing strain during prolonged use.
- **Integrated Wrist Rest:** The built-in wrist rest provides support and comfort, promoting a better ergonomic position for your hands and wrists.
- **Adjustable Kickstands:** Located on the underside, these kickstands allow you to adjust the keyboard's tilt for personalized comfort.




Image: Diagram showing proper hand and arm posture with the ergonomic keyboard, emphasizing the natural curve and wrist support.

### 3.1.1 Multimedia Keys

The keyboard includes 12 multimedia function keys (F1-F12) that can be accessed by pressing the **Fn** key simultaneously with the desired function key.

Key Combination	Function
Fn + F1	Music Player
Fn + F2	Volume Down
Fn + F3	Volume Up
Fn + F4	Mute
Fn + F5	Previous Track
Fn + F6	Next Track
Fn + F7	Play/Pause
Fn + F8	Stop
Fn + F9	Browser/Home Page
Fn + F10	Email
Fn + F11	My Computer
Fn + F12	Calculator

Image: Diagram highlighting the multimedia keys (F1-F12) and the numeric keypad on the keyboard, with a legend for each multimedia function.

### 3.1.2 Operating System Layout Switching

The keyboard supports both Windows and Mac OS layouts. Use the following key combinations to switch between modes:

- **Fn + Q:** Switches to Windows layout. The Win/Lac light will turn red.
- **Fn + W:** Switches to Mac OS layout. The Win/Lac light will turn green.



Image: Visual guide for switching between Windows and Mac OS layouts using Fn+Q and Fn+W key combinations, showing the corresponding indicator lights.

### 3.2 Mouse Functions

The ergonomic mouse is designed for comfortable and silent operation.

- **Silent Clicks:** The mouse features quiet click technology, reducing noise by 90% compared to standard mice, ideal for quiet environments.
- **Adjustable DPI:** Cycle through 3 DPI levels (800-1200-1600) to adjust cursor sensitivity for different tasks. Press the DPI button located behind the scroll wheel to change settings.
- **Navigation Buttons:** Includes dedicated "Next" and "Previous" buttons on the side for convenient web page browsing.



Image: Detailed diagram of the ergonomic mouse, labeling the scroll wheel, left/right buttons, back/forward buttons, and the DPI adjustment button, along with an indication of silent clicks.

## 4. MAINTENANCE

---

### 4.1 Cleaning

To maintain the performance and appearance of your keyboard and mouse:

- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Avoid using harsh chemicals, abrasive cleaners, or solvents.
- Do not immerse the devices in water.

### 4.2 Spill-Resistant Design

The keyboard features a spill-resistant design with drainage holes at the bottom to help mitigate damage from minor spills. In case of a spill:

1. Immediately disconnect the USB receiver from your computer.
2. Turn off the keyboard using the ON/OFF switch.
3. Invert the keyboard to allow any liquid to drain out through the drainage holes.
4. Wipe the surface dry with a clean cloth.
5. Allow the keyboard to air dry completely before reconnecting and resuming use. Ensure no moisture remains inside.

## 2 IN 1 MAC OS & WINDOWS



Image: Close-up view of the keyboard keys with water droplets, illustrating the spill-resistant feature and drainage capability.

### 4.3 Smart Power Management

To conserve battery life, both the keyboard and mouse feature an auto-sleep function. They will enter sleep mode after a period of inactivity. To wake them up, simply press any key on the keyboard or move/click the mouse.

## 5. TROUBLESHOOTING

Problem	Possible Solution
Keyboard/Mouse not responding.	<ul style="list-style-type: none"><li>◦ Ensure batteries are correctly installed and not depleted. Replace if necessary.</li><li>◦ Check if the ON/OFF switch on both devices is in the "ON" position.</li><li>◦ Ensure the USB nano receiver is securely plugged into a working USB port on your computer. Try a different USB port.</li><li>◦ Move the keyboard/mouse closer to the USB receiver to ensure it's within the 10m (33ft) wireless range.</li><li>◦ Restart your computer.</li></ul>
Lag or intermittent connection.	<ul style="list-style-type: none"><li>◦ Reduce interference by moving other wireless devices (e.g., Wi-Fi routers, cordless phones) away from the receiver.</li><li>◦ Ensure there are no large metal objects between the devices and the receiver.</li><li>◦ Try plugging the USB receiver into a different USB port, preferably a direct port on the computer rather than a USB hub.</li></ul>
Mouse cursor erratic or not moving smoothly.	<ul style="list-style-type: none"><li>◦ Clean the optical sensor on the underside of the mouse.</li><li>◦ Use the mouse on a clean, non-reflective surface or a mouse pad.</li><li>◦ Adjust the DPI setting using the DPI button on the mouse.</li></ul>

Problem	Possible Solution
Keyboard keys not typing correctly (e.g., wrong characters).	<ul style="list-style-type: none"> <li>◦ Ensure the correct operating system layout is selected (Fn+Q for Windows, Fn+W for Mac).</li> <li>◦ Check for any stuck keys.</li> </ul>

## 6. SPECIFICATIONS

---

Feature	Detail
Connectivity	2.4Ghz Wireless
Wireless Range	Up to 10 meters (33 feet)
Keyboard Layout	Full-size 104 keys, Wave Ergonomic
Mouse DPI Levels	800 / 1200 / 1600 DPI (Adjustable)
Mouse Buttons	5 buttons (Left, Right, Scroll Wheel, Forward, Back, DPI)
Compatibility	Windows XP/Vista/7/8/10/11, Mac OS, Linux
Power Source (Keyboard)	1 x AA Battery (not included)
Power Source (Mouse)	1 x AA Battery (not included)
Special Features	Ergonomic Design, Wrist Rest, Silent Clicks (Mouse), Spill-Resistant (Keyboard), Smart Power Management
Color	Black
Keyboard Dimensions	Approx. 446mm x 222mm x 40mm
Mouse Dimensions	Approx. 112mm x 69mm x 41mm
Item Weight	2.57 pounds (combined)




Image: Technical drawing showing the dimensions of both the ergonomic keyboard and mouse in millimeters.

## 7. WARRANTY AND SUPPORT

RECCAZR products are designed for reliability and performance. If you encounter any issues or have questions regarding

