

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Aorus](#) /
- › [Aorus T156A 15.6-inch Business Laptop User Manual](#)

Aorus T156A

Aorus T156A 15.6-inch Business Laptop User Manual

Model: T156A

[Overview](#) [Setup](#) [Introduction](#) [Package Contents](#) [Product](#)
[Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Aorus T156A 15.6-inch Business Laptop. This manual provides essential information for setting up, operating, and maintaining your new laptop. Please read this manual thoroughly before using the device to ensure proper function and longevity. This laptop is designed for productivity and portability, featuring a 4-core processor, 8GB DDR4 RAM, and a 512GB M.2 PCIe NVMe SSD, all running on Windows 11 Pro.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- Aorus T156A Laptop
- Power Adapter and Cable
- Transparent Keyboard Cover
- Spanish Keyboard Cover
- Instruction Manual (this document)

Backlit Full Keyboard with Fingerprint ID




Image: The laptop, power adapter, and keyboard covers as included in the package.

3. PRODUCT OVERVIEW

3.1 Key Features

- **Powerful Performance:** Equipped with a 4-core N95 processor (1.7-3.4 GHz) and 8GB DDR4 RAM for efficient multitasking.
- **Ample Storage:** Features a 512GB M.2 PCIe NVMe SSD for fast data access and sufficient storage.
- **Vibrant Full HD Display:** A 15.6" Full HD IPS LCD screen offers clear visuals with wide viewing angles.
- **Convenient Features:** Includes a backlit keyboard for low-light use and a fingerprint reader for secure access.
- **Connectivity & Versatility:** Offers Bluetooth, an SD card reader, and essential ports for various devices.



4-Core

Up to 3.40 GHz Processor



Upgradeable

32GB RAM & 10TB Storage



4K Ready

Up to 3 Displays



15.6 " Display

1920x1080



8GB Memory

3200MHz Speed



512GB SSD

Fast NVMe



Climate Friendly



Backlit Keyboard



Fingerprint ID



2-Year Warranty

Image: An overview of the Ausunda T156A laptop with its main features labeled.

3.2 Processor and Memory

The laptop is powered by an Intel N95 4-core processor, capable of speeds up to 3.4 GHz, ensuring smooth operation for business and academic tasks. It comes with 8GB of DDR4 RAM and a 512GB M.2 PCIe NVMe Solid State Drive (SSD) for quick boot times and application loading.

8GB RAM
512GB SSD



Memory & Storage to Match

*Chassis logo varies by batch. Specs unchanged.

Image: A visual representation of the 4-core N95 processor chip.




Image: The laptop highlighting its 8GB RAM and 512GB SSD configuration.

3.3 Display

Experience clear and vibrant visuals on the 15.6-inch Full HD (1920x1080) IPS LCD display. The screen features a narrow bezel and supports 16 million colors, providing an immersive viewing experience. A privacy shutter is integrated for the webcam.

Powerful 4-Core Processor Chip



4 Threads



Up to
3.4GHz Turbo



16EU
Graphics

Image: The laptop's 15.6-inch Full HD IPS LCD display and its features.

3.4 Keyboard and Touchpad

The laptop features a full-size backlit keyboard, allowing comfortable typing in various lighting conditions. The integrated touchpad includes a fingerprint sensor for secure and quick login.

8GB RAM

512GB SSD



Memory & Storage to Match

Image: The backlit keyboard and the fingerprint ID sensor on the touchpad.

3.5 Ports and Connectivity

The Aulusda T156A offers a range of connectivity options:

- DC Power Input
- USB-A Ports (multiple)
- HDMI Output
- microSD Card Reader
- Headphone Jack
- Bluetooth and Wi-Fi (802.11ac, 802.11ax)

15.6-inch Full HD IPS LCD Display

Crystal clear visuals with a 180-degree full hinge and support for 16 million colors



0.2-inch
narrow bezel



Stereo
speakers



Built-in
webcam



Clear
microphone

Image: The various ports available on the sides of the laptop.

4. SETUP

4.1 Initial Power On and Charging

1. Unpack the laptop and power adapter from the box.
2. Connect the power adapter to the DC power input port on the laptop and then to a power outlet.
3. Allow the laptop to charge for at least 30 minutes before initial use, or until the charging indicator light shows a full charge.
4. Press the power button to turn on the laptop.

4.2 Windows 11 Pro Setup

Follow the on-screen instructions to complete the initial Windows 11 Pro setup. This will include:

- Selecting your region and keyboard layout.
- Connecting to a Wi-Fi network.
- Accepting the license agreement.

- Creating a user account or signing in with a Microsoft account.

4.3 Fingerprint Sensor Setup

For enhanced security, set up the fingerprint sensor:

1. Once Windows is set up, navigate to **Settings > Accounts > Sign-in options**.
2. Under 'Windows Hello Fingerprint', click **Set up**.
3. Follow the on-screen prompts to register your fingerprint. You will be asked to lift and place your finger multiple times on the sensor until it is fully registered.

5. OPERATING THE LAPTOP

5.1 Basic Usage

- **Power On/Off:** Press the power button located on the top right of the keyboard to turn the laptop on or off.
- **Sleep Mode:** Close the lid or press the power button briefly to put the laptop into sleep mode.
- **Restart/Shut Down:** Access these options from the Start Menu in Windows.

5.2 Backlit Keyboard Control

The keyboard backlight can be adjusted or turned off using the function keys. Look for the key with a keyboard icon (often F5 or F6) to cycle through brightness levels or toggle the backlight on/off.

5.3 Webcam Privacy Shutter

The integrated webcam includes a physical privacy shutter. Slide the small cover located directly above the webcam lens to open or close it, ensuring your privacy when the camera is not in use.

5.4 Connecting External Devices

Use the available ports to connect peripherals:

- **USB Devices:** Plug USB drives, mice, or keyboards into the USB-A ports.
- **External Display:** Connect an external monitor or projector using the HDMI port.
- **Audio:** Use the headphone jack for headphones or external speakers.
- **MicroSD Card:** Insert a microSD card into the dedicated slot for additional storage or data transfer.

5.5 Gaming Performance

The Aausda T156A is capable of handling light gaming and provides a smooth experience for many popular titles. For optimal performance, ensure your drivers are updated and close unnecessary background applications.

Your browser does not support the video tag.

Video: Demonstration of the Aausda T156A laptop's light gaming capabilities.

Your browser does not support the video tag.

Video: A short clip showcasing the laptop's performance during racing games.

6. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and exterior. For stubborn smudges, dampen the cloth with water or a screen-safe cleaner. Avoid harsh chemicals.

- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. It is recommended to keep the battery charged between 20% and 80% when possible. Store the laptop in a cool, dry place.
- **Software Updates:** Regularly check for and install Windows updates and driver updates to ensure optimal performance and security.
- **Ventilation:** Ensure the laptop's vents are not obstructed to prevent overheating. Use the laptop on a hard, flat surface.
- **Data Backup:** Regularly back up important data to an external drive or cloud storage to prevent data loss.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your Aausda T156A laptop.

Problem	Possible Solution
Laptop does not power on.	Ensure the power adapter is securely connected and the outlet is working. Try charging the laptop for a while before attempting to power it on again.
Screen is blank or black.	Check if the laptop is powered on. Try pressing Fn + F1 (or the display toggle key) to ensure the display is not turned off. Connect to an external monitor to check if the issue is with the laptop's screen.
Wi-Fi connection issues.	Ensure Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Check for updated Wi-Fi drivers.
Fingerprint sensor not working.	Ensure your finger is clean and dry. Re-register your fingerprint in Windows settings. Check for driver updates for the fingerprint sensor.
Keyboard backlight not working.	Press the dedicated backlight function key (e.g., Fn + F5 or F6) to toggle or adjust brightness.
Laptop is running slow.	Close unnecessary applications. Check Task Manager for resource-intensive processes. Ensure sufficient free space on the SSD. Run a malware scan.

8. SPECIFICATIONS

Detailed technical specifications for the Aausda T156A laptop:

Feature	Detail
Brand	Aausda
Model Name	T156A
Screen Size	15.6 Inches
Hard Disk Size	512 GB (SSD)
CPU Model	Intel N95 (4-Core, 1.7 GHz base, up to 3.4 GHz turbo)

Feature	Detail
RAM Memory Installed Size	8 GB DDR4
Operating System	Windows 11 Pro
Special Features	Backlit Keyboard, Fingerprint Reader
Graphics Coprocessor	UHD Graphics (Integrated)
Connectivity Technology	Bluetooth, Wi-Fi (802.11ac, 802.11ax)
Number of Ports	2 (USB-A, HDMI, microSD, Headphone Jack)
Battery Cell Type	Lithium Polymer (6000 mAh)
Item Dimensions (L x W x Thickness)	14"L x 9"W x 0.7"Th
Native Resolution	1920 x 1080 pixels
Refresh Rate	60 Hz
Webcam Capability	Yes (with privacy shutter)

9. WARRANTY & SUPPORT

9.1 Product Warranty

The Ausunda T156A laptop comes with a **2-Year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the documentation provided with your product or contact Ausunda customer support.

9.2 Customer Support

For technical assistance, troubleshooting, or service inquiries, please visit the official Ausunda Store or contact their customer support channels. You can find more information and support resources at the [Ausunda Official Store on Amazon](#).

Your browser does not support the video tag.

Video: A short promotional video from the Ausunda Official Store, showcasing the laptop's features for college students.