

GiiKER JKFXQ001

GiiKER Super Ludo Board Game Instruction Manual

Model: JKFXQ001

Brand: GiiKER

1. INTRODUCTION

Welcome to the GiiKER Super Ludo Board Game, a space-themed reimagining of the classic Ludo game. This electronic board game is designed for 2-4 players, offering dynamic gameplay with interactive features and unexpected events. This manual provides essential information for setting up, playing, and maintaining your game to ensure an enjoyable experience for all players aged 6 and up.

2. SAFETY INFORMATION

Warning: Choking Hazard - Small Parts. Not for children under 3 years.

3. WHAT'S IN THE BOX

- GiiKER Super Ludo Game Board
- Game Pieces (12 pieces total, 3 for each of the 4 colors: Red, Yellow, Green, Blue)
- User Manual

4. SETUP

1. **Unpack the Game:** Carefully remove all components from the packaging.
2. **Insert Batteries:** Locate the battery compartment (usually on the underside of the board) and insert the required batteries (not included, typically AA or AAA, refer to packaging for specifics).
3. **Place Game Pieces:** Each player selects a color (Red, Yellow, Green, or Blue). Place your three game pieces into their respective starting zones on the board. The board features built-in storage compartments for the pieces when not in use.



The GiiKER Super Ludo Board Game, showcasing its unique octagonal design with four colored player zones and a central digital dice dome.

SUPER LUDO



✓ **A PERFECT GIFT**



✓ **ENDLESS FUN**



✓ **100%
SCREEN FREE**

The GiiKER Super Ludo Board Game demonstrating its built-in storage for game pieces, ensuring all components are neatly kept within the board.

5. OPERATING INSTRUCTIONS (GAMEPLAY)

5.1. Objective

The objective of GiiKER Super Ludo is to be the first player or team to move all three of your game pieces from your starting zone, around the board, and into your home zone (the central area of your color).

5.2. Game Modes

The GiiKER Super Ludo offers two primary game modes:


- **Free-for-All (1v1):** In this mode, 2 to 4 players compete independently. Each player aims to be the sole winner by getting all their pieces home first.
- **Team Battles (2v2):** This mode is designed for 4 players, forming two teams of two. Teammates work together to get all their combined pieces home.



An illustration detailing the two primary game modes: Free-for-All (1v1) and Team (2v2), showing player piece distribution for each.

5.3. Digital Dice and Smart Crystal Ball

The game features a central "Smart Crystal Ball" which acts as the digital dice. To roll the dice, gently press down on the crystal ball. The result will be displayed digitally, and the board may light up or make sounds. This also serves as the indicator for Universe Events.



**Dynamic
Board**



**Interactive
Smart Features**




A detailed view of the central Smart Crystal Ball, which functions as the digital dice and event indicator for the GiiKER Super Ludo game.

5.4. Universe Events

During gameplay, the Smart Crystal Ball may trigger one of six dynamic Universe Events, adding unpredictable twists to the game. These events can change the flow of play significantly:

- **Teleport:** Instantly move your piece to a different location on the board.
- **Swirl:** Causes pieces to rotate or swap positions.
- **Exchange:** Swap positions with an opponent's piece.
- **One More Dice:** Grants an additional dice roll.
- **Wormhole:** Allows for a shortcut across the board.
- **Meteorite:** May send an opponent's piece back to their starting zone.



A visual representation of the six dynamic Universe Events: Teleport, Swirl, Exchange, One More Dice, Wormhole, and Meteorite, which add unpredictable twists to gameplay.

6. MAINTENANCE

To ensure the longevity of your GiiKER Super Ludo Board Game, follow these maintenance guidelines:

- **Cleaning:** Wipe the board and pieces with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the game in a cool, dry place away from direct sunlight. Utilize the built-in storage compartments for all game pieces to prevent loss.
- **Battery Care:** Remove batteries if the game will not be used for an extended period to prevent leakage.

7. TROUBLESHOOTING

- **Confusing Instructions:** If the initial instructions are unclear, refer to this comprehensive manual for detailed explanations of gameplay and features.
- **Dice Dome Sticks / Game Turns Off:** The Smart Crystal Ball (dice dome) should be pressed gently. If it sticks or the game turns off unexpectedly, ensure you are not holding it down for too long. To

change game modes, press the 'Finish' buttons located on a couple of the colored player zones, rather than holding the dice dome.

- **Universe Events Not Triggering Frequently:** The occurrence of Universe Events is random. If they seem infrequent, try turning the game off and on, or removing and reinserting the batteries to reset the system.
- **Game Not Powering On:** Check that batteries are inserted correctly and are not depleted. Replace with fresh batteries if necessary.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	10.16 x 10.16 x 0.04 inches
Item Weight	1.23 pounds
Model Number	JKFXQ001
Manufacturer Recommended Age	6 years and up
Language	English
Manufacturer	GiiKER


9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your GiiKER Super Ludo Board Game, please refer to the product packaging or visit the official GiiKER store or website. You can find more information at [GiiKER Store on Amazon](#).

© 2025 GiiKER. All rights reserved.


Related Documents - JKFXQ001

--	--



[GiiKER Super Ludo Space-Themed Board Game User Manual](#)

User manual for the GiiKER Super Ludo, a space-themed board game. Learn how to play, understand game modes, universe events, basic rules, and FAQs. Includes product specifications, warranty, and compliance information.



[GiiKER Super Ludo User Manual: Space-Themed Board Game Rules and Gameplay](#)

Comprehensive user manual for the GiiKER Super Ludo space-themed board game. Learn how to play, understand game modes, universe events, basic rules, and specifications.




[GiiKER Smart Four: AI-Powered 3D Strategy Board Game - Quick Start & Manual](#)

Get started with the GiiKER Smart Four, an AI-enhanced 3D Connect Four strategy board game. This guide covers setup, gameplay modes (Head-to-Head, Robot), app connectivity, charging, troubleshooting, and specifications for model JKSZQ001.




[GiiKER Super Decoder User Manual and Specifications](#)

Comprehensive guide to the GiiKER Super Decoder, a code-breaking game console. Includes setup, gameplay instructions for solo and duo modes, troubleshooting, specifications, warranty information, and compliance details.



Smart Four is an AI featured 3D board game. With the integrated referee, the board records your moves and determines the winner of the game. You can fire up a head to head competition or challenge against the



- Light Indication Area**
Player Indicator:
 Lighted circles indicate which party needs to take a move.
 - Triangular Indicator:**
 The indicator color corresponds with the same color circle in the top row.
 - Game Mode**
 Robot Mode - Easy
 Robot Mode - Medium
 Robot Mode - Hard
 Head to Head Mode
 - Battery Compartment**
 The battery compartment is on the back of the Smart Four. Recharge about 2 AA batteries.
 - Game Board**
 Consists of 25 circle buttons.
 - Power Button**
 Long press power button for 2 seconds to turn on/off.
 If the board is not in a game more than 30 minutes, it will shut down automatically.
 - Pieces**
 32 Black Pieces, 32 White Pieces, Total 64 Pieces.

Link four in a row in any direction

Link four in a row in any direction



- Choose piece color and move in turn.
- When you have decided where to go, place your piece on it and click on the corresponding button to confirm, and then the opposite Player Indicator will light up.
- Up to 5 pieces can be placed on one button. Otherwise, the Triangle Indicator will blink rapidly to indicate a wrong move.
- When a player wins, triangular indicator/indicators will blink to show where the four pieces connect in a row.

- Choose difficulty
 - Human move first
 - Triangular indicator lights up, you need to finish the move for the robot.
- 



Opening: either party can move first.

Long press for 2 seconds, all Triangular indicator display red to indicate setting successfully.

Long press for 2 seconds, all Triangular indicator display red to indicate setting successfully.

Name	Smart Four	Model	8320002
Material	ABS	Age	5+
Battery Type	1.5V AA Battery	Board Dimensions	280mmx203mm

Name	Smart Four	Model	8320002
Material	ABS	Age	5+
Battery Type	1.5V AA Battery	Board Dimensions	280mmx203mm

- Why doesn't the triangular indicator light up after winning?
You might forget to click the button to confirm when you place your piece on it.
- Is it possible to restart the game during play?
Yes, you can press the correspond mouse button at any time to restart the game. [Go to this mouse button](#)

- **Why doesn't the triangular indicator light up after winning?**
You might forget to click the button to confirm when you place your piece on it.
- **Is it possible to restart the game during play?**
Yes, you can press the correspond mode button at any time to restart the game or switch game modes.
- **Why does the triangular indicator blink three times?**
It means that the current move is invalid. Please check if more than 5 pieces place on one button or if the piece was not move on the button specified by the robot.

Under duress, drop, puncture, violently kick or step on it.
This product can damage the product.

The product is not water resistant. Do not drop the product into water. Do not leave the product outside in rain or on a source of moisture.

Do not place the product near a source of heat. Operate and store the product between 0° C and 40° C.

Loud noise of battery can cause personal injury as well as damage to the product. Do not touch battery leakage directly. Wipe off the affected skin and clothes. Keep battery seal away from your eyes and mouth. Batteries may make popping sounds.

Do not throw batteries away.

Do not mix different brands of batteries; do not mix different types of batteries (alkaline, standard carbon-zinc or rechargeable Ni-MH batteries). Do not leave used batteries in the Super blower. Do not reuse old batteries. Do not use damaged batteries. Do not use old cells; Do not put the batteries backwards. Handle them as disposable waste. Do not try to disassemble or force the correct direction. Do not push and pull the batteries in a fire.

Your safety terminals are not to be short-circuited.

Not suitable for children under 3 years. Small parts. Choking hazard.

GURER warrants that your GURER hardware products ("the Product") will be free from defects in materials and workmanship for a period of 90 days from the date of purchase ("the Warranty Period"). If a defect in the Product arises under normal and intended use within the Warranty Period, please contact the authorized GURER distributor or service center nearest you, or, if you are in your country, write, at its option, or call, subject to applicable laws, request to repair the Product with the new or reconditioned parts.

This warranty is only valid to the original retail purchaser, accompanied by a receipt or proof of purchase. GURER does not warrant that the operation of the Product will be uninterrupted or error-free. This Warranty does not apply for all Products nor does it cover the Product's accessories, consumables, or components on stickers or protecting coatings designed to diminish over time; or defects caused by misuse or failure to follow the product directions; misuse or unauthorized repair; all Defects caused by accidents, fire, flood, lightning, or other causes; or defects of non-manufactured parts and wear and tear otherwise due to the normal aging, other causes beyond GURER's reasonable control.

GIGER Technology Co., Ltd. declares that this product is in compliance with the relevant requirements of Directive 2004/108/EC, Directive 2014/53/EU. This declaration of conformity is published on our website www.giger.com/naoas/compliance.

The symbol above means that according to local laws or regulations your product should be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. Some collection points accept products for free. The separate collection and recycling of your product at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. See these instructions for future reference as they contain important information.

This equipment has been tested and found to comply with the limit for a Class B digital device, pursuant to Part 15 of the FCC Rules. The limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not properly installed and used, may cause interference to other equipment. It is recommended that this equipment be installed and used according to the instructions.

[illegible]

Manufacturer: FS (B2B) Technology Co., Ltd.
Website: www.gilker.com Email: support@gilker.com
Made in China
This content is subject to change without prior notice.

Comprehensive user manual for the GiiKER Super Slide, an interactive sliding puzzle game. Learn how to set up games, play in learn and challenge modes, and understand product specifications and troubleshooting.