Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- HOLMES /
- > HOLMES 18" Oscillating Stand Fan, Model 32510149 User Manual

HOLMES 32510149

HOLMES 18" Oscillating Stand Fan Instruction Manual

Model: 32510149

1. Introduction

This manual provides instructions for the assembly, operation, maintenance, and troubleshooting of your HOLMES 18" Oscillating Stand Fan. Please read all instructions carefully before use and retain this manual for future reference.



Figure 1: The HOLMES 18" Oscillating Stand Fan in a typical home environment.

2. IMPORTANT SAFETY INFORMATION

WARNING:

- · Always unplug the fan before cleaning or servicing.
- Do not operate the fan with a damaged cord or plug.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- Do not insert fingers or foreign objects into any openings on the fan.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.
- This fan is for indoor use only. Do not use outdoors.
- Ensure the fan is placed on a stable, level surface to prevent tipping.

3. PACKAGE CONTENTS

Verify that all components are present before assembly:

• Fan Head Assembly (Motor, Blades, Grills)

- · Adjustable Height Pole
- Base
- Mounting Hardware (Screws, Washers, Nuts)
- Instruction Manual



Figure 2: Product packaging illustrating the fan, ETL certification, and 3-year limited warranty.

4. ASSEMBLY INSTRUCTIONS

The HOLMES 18" Oscillating Stand Fan requires minor assembly. Follow these steps:

- 1. **Attach the Base:** Place the adjustable height pole onto the base. Secure it using the provided screws and washers from underneath the base. Ensure it is firmly tightened.
- 2. **Mount the Fan Head:** Carefully align the fan head assembly with the top of the adjustable height pole. Push down and twist gently until it locks into place. Some models may require a screw to secure the fan head to the pole.
- 3. **Secure the Grills:** Ensure the front and rear grills are properly aligned and secured around the fan blades. Fasten any clips or screws provided to hold the grills together securely.
- 4. **Check Stability:** Once assembled, ensure the fan is stable and all connections are secure before plugging it in.






Figure 3: Fully assembled HOLMES 18" Oscillating Stand Fan.

5. OPERATING INSTRUCTIONS

Your HOLMES 18" Oscillating Stand Fan offers customizable cooling options.

5.1 Power and Speed Settings

The fan features a push-button control panel located on the fan pole.

- OFF: Press the 'OFF' button to turn the fan off.
- Speed 1 (Low): Press '1' for a gentle breeze.
- Speed 2 (Medium): Press '2' for moderate airflow.
- Speed 3 (High): Press '3' for maximum airflow (up to 18 ft/sec).



Figure 4: Control panel with three-speed settings and off button.

5.2 Oscillation Function

To activate the oscillation feature, press the oscillation button (usually located on the top or rear of the motor housing). The fan head will sweep from side to side, providing wide-area cooling (approximately 75° oscillation).



Figure 5: Illustration of the fan's oscillation range, showing movement from side to side.

5.3 Adjustable Height and Tilt

- **Height Adjustment:** Loosen the height adjustment collar on the pole, adjust the pole to your desired height (between 39" and 49"), and then securely tighten the collar.
- **Head Tilt:** The fan head can be tilted up or down by approximately 25°. Gently push or pull the fan head to adjust the angle of airflow.



Figure 6: Fan head tilt adjustment, showing the ability to angle the fan head up or down.



Figure 7: Fan dimensions and adjustable height range, illustrating the fan's physical size and height adjustment capability.

6. MAINTENANCE

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- 1. Disconnect Power: Always unplug the fan from the electrical outlet before cleaning.
- 2. **Clean Exterior Surfaces:** Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- 3. **Clean Fan Blades and Grills:** The front grill can typically be removed for easier access to the blades. Use a soft cloth or a vacuum cleaner with a brush attachment to remove dust and debris from the blades and grills. Ensure all parts are dry before reassembling and operating the fan.
- 4. **Storage:** If storing the fan for an extended period, cover it to protect it from dust and store it in a cool, dry place.

7. TROUBLESHOOTING

If your fan is not operating correctly, consult the following common issues and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; power outlet not working; fan switch is off.	Ensure the fan is securely plugged into a working electrical outlet. Check if the power button is pressed to an ON setting.
Weak airflow.	Fan speed set too low; dust accumulation on blades/grills.	Increase the fan speed setting. Clean the fan blades and grills as described in the Maintenance section.
Fan makes unusual noise.	Loose parts; obstruction in blades; fan not on a level surface.	Unplug the fan and check for any loose parts or obstructions. Ensure the fan is on a stable, level surface.
Oscillation not working.	Oscillation button not engaged; internal mechanism issue.	Press the oscillation button to activate. If the issue persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	HOLMES
Model Name	Holmes Manual Stand Fan
Model Number	32510149
Color	Black
Fan Design	Pedestal Fan
Power Source	Standard 120V Outlet
Product Dimensions (D x W x H)	16.9"D x 15.35"W x 50.39"H
Adjustable Height Range	39"–49"
Oscillation Angle	75°
Head Tilt Angle	25°
Number of Speed Settings	3
Noise Level (Highest Setting)	58 Decibels
Wattage	60 watts
Air Flow Capacity	1860 Cubic Feet Per Minute (CFM)
Item Weight	12.9 Pounds
Indoor/Outdoor Usage	Indoor
Certification	ETL Certified
Assembly Required	Yes

Feature	Detail
Batteries Required	No

9. WARRANTY AND SUPPORT

This HOLMES 18" Oscillating Stand Fan is backed by a **3-year limited warranty**. For warranty claims or technical support, please refer to the contact information provided with your purchase documentation or visit the official HOLMES website.

For further assistance, please contact HOLMES customer service.

© 2024 HOLMES. All rights reserved.

Related Documents - 32510149



Holmes 16-inch Oscillating Stand Fan Owner's Guide - HASF1515/HASF1516

Owner's guide for the Holmes 16-inch (40cm) Oscillating Stand Fan (Models HASF1515, HASF1516). Provides detailed instructions on safety, assembly, operation, cleaning, storage, and warranty information.



Holmes 18 Inch Stand Fan Instruction Manual

Comprehensive instruction manual for the Holmes 18 Inch Stand Fan (Model 32510149), covering cleaning, maintenance, assembly, operation, safety instructions, and warranty information.



Holmes HSF1610A 16-Inch Oscillating Stand Fan - Cleaning and Maintenance Guide

This guide provides essential cleaning, maintenance, and safety instructions for the Holmes HSF1610A 16-inch oscillating stand fan. Learn how to properly care for your fan, including cleaning procedures, fuse replacement, and storage tips.



Holmes 16-Inch Oscillating Stand Fan (HSF1610A) - User Manual and Safety Instructions

User manual and safety guide for the Holmes 16-Inch Oscillating Stand Fan (Model HSF1610A). Covers assembly, operation, cleaning, maintenance, troubleshooting, and warranty information.



Holmes HASF2120 20-inch Power Stand Fan Owner's Guide and Safety Instructions

Comprehensive owner's guide for the Holmes HASF2120 20-inch (50cm) Power Stand Fan, including safety instructions, assembly, operation, cleaning, maintenance, and warranty information.



Holmes HAPF624R Blizzard Oscillating Grill Power Fan: Owner's Guide & Instructions

Comprehensive owner's guide for the Holmes HAPF624R Blizzard Oscillating Grill Power Fan. Includes safety instructions, operating procedures, cleaning and maintenance tips, and warranty information.