

OHOVIV N10

OHOVIV N10 Portable Charger 50000mAh Power Bank

USER MANUAL

1. INTRODUCTION

Thank you for choosing the OHOVIV N10 Portable Charger 50000mAh Power Bank. This high-capacity power bank is designed to provide reliable and efficient charging for your mobile devices on the go. Please read this manual carefully to ensure proper use, optimal performance, and longevity of your device.

2. PRODUCT OVERVIEW



Image: OHOVIV N10 Portable Charger 50000mAh Power Bank

The OHOVIV N10 Portable Charger features a sleek black design with integrated charging cables (USB-A, USB-C, Micro-USB, and Lightning) for universal compatibility. It includes a clear digital LED display that shows the remaining battery percentage, ensuring you are always aware of its charge status. Multiple output ports (OUT1, IN/OUT3, OUT2) provide versatile charging options for various devices simultaneously.

3. FEATURES

- **Ultra-High Capacity:** 50000mAh battery for extended power on the go.
- **Integrated Charging Cables:** Built-in USB-A, USB-C, Micro-USB, and Lightning cables for convenient

charging without extra wires.

- **Digital LED Display:** Clear percentage display for accurate battery level indication.
- **Multiple Output Ports:** Charge multiple devices simultaneously with various output options.
- **LED Indicator Lights:** Additional lights to indicate charging status or power.
- **Compact Design:** Portable and easy to carry despite its high capacity.
- **Wireless Charging Capability:** Supports wireless charging for compatible devices.

4. SPECIFICATIONS

Attribute	Value
Model Number	N10
Battery Capacity	50000 Milliamp Hours
Battery Type	Lithium Polymer
Product Dimensions	5.9 x 2.9 x 0.75 inches
Color	Black
Connector Type (Input/Output)	USB Type C (and built-in cables)
Special Features	LED Indicator Lights, Digital Display, Wireless Charging

5. SETUP

5.1 Initial Charging of the Power Bank

1. Locate the USB Type-C input port on the power bank (labeled IN/OUT3).
2. Connect the power bank to a suitable USB wall charger (not included) using a USB-C cable or the built-in USB-A cable connected to a USB wall adapter.
3. The digital display will show the charging percentage increasing. For first use, fully charge the power bank to 100%. This may take several hours due to its high capacity.
4. Once fully charged, the display will show "100%". Disconnect the power bank from the charger.

6. OPERATING INSTRUCTIONS

6.1 Charging Your Devices

The OHOVIV N10 Power Bank offers multiple ways to charge your devices:

Using Built-in Cables:

- Identify the correct built-in cable for your device (USB-C, Micro-USB, or Lightning).
- Pull out the desired cable from its slot on the power bank.
- Connect the cable to your device's charging port.
- The power bank will automatically begin charging your device. The digital display will illuminate to show the power bank's remaining charge.

Using USB Output Ports:

- Connect your device's charging cable (e.g., USB-A to Lightning, USB-C to USB-C) to one of the available output ports (OUT1, IN/OUT3, OUT2) on the power bank.
- Connect the other end of the cable to your device.
- The power bank will automatically begin charging your device.

Using Wireless Charging:

- Ensure your device supports wireless charging (Qi standard).
- Place your device centrally on the designated wireless charging area of the power bank.
- The power bank will automatically detect your device and begin wireless charging.

Note: The power bank can charge multiple devices simultaneously using a combination of built-in cables, USB ports, and wireless charging, depending on the total power draw.

7. MAINTENANCE

- **Cleaning:** Wipe the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Battery Health:** For optimal battery life, fully charge and discharge the power bank at least once every three months if not in regular use.
- **Avoid Drops:** Do not drop or subject the power bank to strong impacts.

8. TROUBLESHOOTING

8.1 Power Bank Not Charging

- Ensure the charging cable is securely connected to both the power bank's input port and the wall charger.
- Verify that the wall charger is functioning correctly and plugged into a live power outlet.
- Try using a different charging cable or wall charger.

8.2 Device Not Charging from Power Bank

- Check if the power bank has sufficient charge (refer to the digital display).
- Ensure the charging cable (built-in or external) is securely connected to both the power bank and your device.
- Try a different output port or built-in cable.
- Verify that your device's charging port is clean and free of debris.
- If using wireless charging, ensure your device is properly aligned on the charging pad and supports wireless charging.

8.3 Slow Charging

- Ensure you are using a high-quality cable and a compatible wall charger for the power bank's input.
- For device charging, ensure your device's cable is not damaged.
- Charging multiple devices simultaneously may reduce the charging speed for each individual device.

9. SAFETY INFORMATION

- Do not expose the power bank to water, moisture, or extreme temperatures.
- Do not disassemble, puncture, or modify the power bank.
- Keep out of reach of children.
- Avoid dropping or subjecting the power bank to severe impacts.
- Do not use the power bank if it is damaged, swollen, or leaking.
- Dispose of the power bank responsibly according to local regulations.

10. WARRANTY AND SUPPORT

For any product inquiries, technical support, or warranty claims, please contact OHOVIV customer service through the retailer where the product was purchased or refer to the contact information provided on the product packaging or the official OHOVIV website.