

AIYAPLAY 342-081V04LB

AIYAPLAY Kids Trampoline Ø140 cm - Instruction Manual

Model: 342-081V04LB | Brand: AIYAPLAY

1. SAFETY INFORMATION

Read all instructions carefully before assembly and use. Failure to follow these warnings and instructions can result in serious injury.

- **Adult Supervision Required:** Always ensure an adult supervises children using the trampoline.
- **One User at a Time:** Only one child should use the trampoline at any given time to prevent collisions.
- **Age and Weight Limits:** This trampoline is designed for children aged 3 to 6 years, with a maximum weight capacity of 45 kg (99 lbs). Do not exceed these limits.
- **Clearance Area:** Ensure adequate overhead clearance and a clear perimeter around the trampoline. Keep away from walls, furniture, and other obstacles.
- **Secure Structure:** The trampoline features six steel tubes wrapped in foam padding for a solid and safe base.
- **Safety Net:** The 360° safety net must be properly installed and secured before use to prevent falls.
- **Zippered Door:** Ensure the zippered door is fully closed during use.
- **Bottom Protection Net:** The integrated bottom net prevents children from crawling under the jumping mat, enhancing safety.
- **No Somersaults or Flips:** Avoid somersaults or flips, as these can lead to serious head and neck injuries.
- **Check Before Each Use:** Inspect the trampoline for damaged, worn, or missing parts before each use. Do not use if any components are compromised.

ZONE ENCLOSÉE



Filet de sécurité
360°



Image: The 360-degree safety net provides a secure enclosed play area for children.



CONCEPTION DE SÉCURITÉ

Le filet latéral empêche les enfants de ramper sous le tapis

Image: The bottom protection net prevents access underneath the jumping mat, and the frame is padded for safety.

2. SETUP INSTRUCTIONS

Assembly is required. It is recommended that two adults assemble this trampoline. Please ensure all parts are present before beginning assembly.

2.1 Unpacking and Component Check

1. Carefully unpack all components from the box.
2. Refer to the parts list in your physical manual to identify and count all pieces.
3. If your physical manual's diagrams are unclear, refer to the product images provided online for visual guidance on component appearance.

2.2 Frame Assembly

1. Connect the steel frame sections to form the circular base. Ensure all connections are secure.
2. Attach the trampoline legs to the assembled frame. Tighten all bolts firmly.

2.3 Jumping Mat and Elastic Cords Installation

1. Lay the jumping mat evenly over the frame.
2. Attach the 30 elastic cords to the jumping mat and the frame, following a symmetrical pattern (e.g., opposite sides) to ensure even tension.
3. Ensure all elastic cords are securely fastened.



Image: The jumping mat features a decorative pattern and is secured by 30 elastic cords.

2.4 Safety Net and Pole Installation

1. Insert the six padded poles into the designated slots around the trampoline frame.
2. Slide the safety net over the top of the padded poles.
3. Secure the bottom of the safety net to the trampoline frame.
4. Install the bottom protection net around the base of the trampoline.
5. Ensure the zippered entry is functional and can be securely closed.



Image: The trampoline's stable structure includes six steel tubes with protective foam padding.

3. OPERATING INSTRUCTIONS

3.1 Before Each Use

- Ensure the trampoline is placed on a flat, stable surface.
- Verify that the safety net is fully zipped and secured.
- Check for any loose or damaged parts.
- Confirm that the area around and above the trampoline is clear of obstructions.

3.2 Using the Trampoline

1. Children should enter the trampoline through the zippered door.
2. Encourage children to jump in the center of the mat.
3. Remind children to avoid touching the safety net or poles while jumping.
4. Always maintain adult supervision.



AIYAPLAY
by AOSOM

Image: A child enjoying the trampoline, highlighting its use for physical activity and balance development.

4. MAINTENANCE

- **Regular Inspection:** Periodically check all bolts, elastic cords, frame connections, and the safety net for tightness, wear, or damage.
- **Cleaning:** Clean the jumping mat and safety net with a damp cloth and mild soap. Avoid harsh chemicals.
- **Storage:** If storing outdoors, consider covering the trampoline to protect it from harsh weather conditions. For long-term storage, disassemble and store in a dry place.
- **Replacement Parts:** If any part becomes worn or damaged, contact AIYAPLAY customer service for replacement parts. Do not use the trampoline with damaged components.

5. TROUBLESHOOTING

5.1 Trampoline Feels Unstable

- **Check Surface:** Ensure the trampoline is on a completely flat and level surface.
- **Tighten Connections:** Re-check all frame connections and leg bolts to ensure they are securely

tightened.

5.2 Jumping Mat Lacks Bounce

- **Inspect Elastic Cords:** Verify that all 30 elastic cords are properly attached and not stretched or broken. Replace any damaged cords.
- **Weight Limit:** Ensure the user's weight does not exceed the maximum capacity of 45 kg.

5.3 Safety Net Not Staying Upright

- **Pole Connections:** Ensure the padded poles are fully inserted and secured into the frame.
- **Net Attachment:** Confirm that the safety net is correctly attached to both the top of the poles and the bottom frame.

6. SPECIFICATIONS

Model Number	342-081V04LB
Overall Dimensions (Diameter x Height)	Ø 140 cm x 190 cm
Recommended Age Range	3 to 6 years
Maximum Weight Capacity	45 kg (99 lbs)
Frame Material	Alloy Steel
Jumping Mat Material	Polyethylene (PE)
Number of Elastic Cords	30
Included Components	Safety Net, Legs, Padded Poles, Jumping Mat, Bottom Protection Net
Product Weight	11 kg (24.25 lbs)



Image: Detailed dimensions of the trampoline, including overall height, diameter, and jumping mat size.