

[manuals.plus](#) /› [EMKE](#) /› [EMKE Electric Towel Warmer 1000x500mm 320W - User Manual](#)

EMKE 1000x500mm 320W White Right Side

EMKE Electric Towel Warmer User Manual

Model: 1000x500mm, 320W, White, Right Side

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your EMKE Electric Towel Warmer. Please read it thoroughly before installation and use, and retain it for future reference. The EMKE Electric Towel Warmer, measuring 1000x500mm with a 320W heating element, is designed to efficiently dry towels and provide warmth. It features a sleek white finish, a touch screen display, Wi-Fi control, and a timer function for enhanced convenience.

2. SAFETY INFORMATION

Important Safety Instructions:

- Ensure the power supply matches the specifications of the towel warmer.
- Do not immerse the appliance in water or other liquids.
- Keep children and pets away from the towel warmer during operation.
- Do not cover the towel warmer with excessive items, as this may lead to overheating.
- The appliance is equipped with overload protection for safety.
- This product is rated IPX5 for water resistance, making it suitable for bathroom environments. However, avoid direct water spray onto the control panel.
- Installation must be performed by a qualified professional if electrical circuit modification is required.

Pratico ed elegante

Valorizza il tuo bagno ed esprimi la tua personalità. Porta colore nella tua vita!



EMKE

Image: Power plug and wall socket, highlighting electrical safety features.



I nostri radiatori sono analizzati, studiati e progettati con la massima precisione per garantire la massima efficienza energetica e un comfort ottimale. Ogni modello unisce tecnologia innovativa e design senza tempo – per un perfetto equilibrio tra funzionalità ed estetica.


Realizzati con estrema cura, i nostri radiatori si integrano armoniosamente nella tua casa, donando carattere ad ogni ambiente. Scopri un calore sostenibile, efficiente e raffinato.

Image: Towel warmer surface with water droplets, illustrating IPX5 water resistance.

3. SPECIFICATIONS

Feature	Specification
Brand	EMKE
Model	Electric Towel Warmer
Dimensions	1000x500mm
Power	320W

Color	White
Side Orientation	Right Side
Control Type	Touch Screen, Wi-Fi Control
Temperature Range	30°C to 70°C
Timer Function	1 to 9 hours (default auto-off after 8 hours)
Special Features	Memory for power interruption, Overload protection, IPX5 Water Resistance



Funzione timer da 1 a 9 ore

Asciugamani caldi immediatamente al vostro arrivo,
utilizzo efficiente dell'energia senza funzionamento continuo

Image: Technical drawing with dimensions (1000x500mm) and power (320W).

4. SETUP AND INSTALLATION

The EMKE Electric Towel Warmer is designed for straightforward wall mounting. Follow these steps for installation:

- 1. Choose Location:** Select a suitable wall location in your bathroom, ensuring it is within reach of a power outlet and away from direct water spray.
- 2. Mark Drilling Points:** Use the provided template or measure carefully to mark the four drilling points on the wall

for the mounting brackets.

3. **Drill Holes:** Drill holes at the marked points using an appropriate drill bit for your wall type. Insert wall plugs if necessary.
4. **Attach Brackets:** Secure the mounting brackets to the wall using the screws provided.
5. **Mount Towel Warmer:** Carefully align the towel warmer with the brackets and secure it in place.
6. **Connect Power:** Plug the towel warmer into a grounded electrical outlet. Ensure the power cord is not stretched or pinched.

Note: No modification to the electrical circuit is typically required for installation. If you are unsure, consult a qualified electrician.

5. OPERATING INSTRUCTIONS

5.1 Touch Screen Control

The towel warmer features an intuitive touch screen display for direct control.



Image: Digital touch screen control panel.

- **Power On/Off:** Press the power button on the touch screen to turn the unit on or off.
- **Temperature Adjustment:** Use the temperature control buttons to set the desired temperature between 30°C and 70°C.
- **Timer Setting:** Press the timer button to set the operating duration from 1 to 9 hours.

5.2 Wi-Fi Control

Control your towel warmer remotely using your smartphone via Wi-Fi.

1. **Download App:** Download the EMKE smart home application from your device's app store.
2. **Pair Device:** Follow the in-app instructions to pair your towel warmer with your smartphone. This typically involves putting the device into pairing mode and connecting to your home Wi-Fi network.
3. **Remote Operation:** Once paired, you can control power, adjust temperature, and set timers from your smartphone.



Image: Wi-Fi control via smartphone app and voice assistant compatibility.

5.3 Timer Function and Automatic Shut-off

The timer allows you to program the heating duration:

- Set the timer from 1 to 9 hours.
- By default, the unit will automatically turn off after 8 hours if no timer is set.
- To enable continuous operation, set the timer to '0H'.



Image: Timer function display.

5.4 Power Interruption Memory

In the event of a power outage, the towel warmer will retain its last settings (temperature and timer) once power is restored. This eliminates the need to reconfigure settings after a power interruption.

5.5 Temperature Guidelines

The adjustable temperature range (30°C to 70°C) allows for optimal drying and warming of various items:

- **30-40°C:** Suitable for delicate items like silk.
- **40-50°C:** Ideal for drying towels.
- **50-60°C:** Recommended for children's clothing.

- **60-70°C:** Appropriate for workwear or heavier garments.



Controllabile tramite assistenti vocali o App,
connessione Wi-Fi necessaria.

Image: Recommended temperature settings for various fabric types and bacterial growth prevention.

6. MAINTENANCE

To ensure the longevity and optimal performance of your EMKE Electric Towel Warmer, follow these maintenance guidelines:

- **Cleaning:** Disconnect the power before cleaning. Wipe the surface with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically inspect the power cord and plug for any signs of damage. If damage is found, discontinue use and contact customer support.
- **Storage:** If storing the unit for an extended period, ensure it is clean, dry, and stored in a safe place away from extreme temperatures and moisture.

7. TROUBLESHOOTING

If you encounter issues with your towel warmer, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Towel warmer does not turn on.	No power supply.	Check if the power plug is securely inserted and the outlet is functional. Check your home's circuit breaker.
Unit is not heating.	Temperature set too low or timer expired.	Increase the temperature setting. Check the timer setting; if it's '0H', it's set for continuous operation.
Wi-Fi connection issues.	Incorrect Wi-Fi password, weak signal, or device not in pairing mode.	Ensure correct Wi-Fi password. Move the unit closer to the router. Re-enter pairing mode as per app instructions.
Overheating or strange smell.	Blocked ventilation or internal fault.	Immediately unplug the unit. Ensure no items are blocking the heat dissipation. If the problem persists, contact customer support.

If the problem persists after attempting these solutions, please contact EMKE customer support.

8. WARRANTY AND SUPPORT

EMKE products are manufactured to high-quality standards. For warranty information and customer support, please refer to the documentation included with your purchase or visit the official EMKE website. Keep your purchase receipt as proof of purchase for warranty claims.

For assistance, you can also visit the [EMKE Store on Amazon](#).