

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [CyberpowerPC](#) /
- › [CyberPowerPC Gamer Supreme Gaming PC User Manual](#)

CyberpowerPC GXiVR8720A17

CyberPowerPC Gamer Supreme Gaming PC User Manual

Model: GXiVR8720A17

Brand: CyberpowerPC

INTRODUCTION

Welcome to your new CyberPowerPC Gamer Supreme Gaming PC. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your system. The Gamer Xtreme VR series is designed for high-performance computing, featuring an Intel Core Ultra 9 processor and NVIDIA GeForce RTX 5060 Ti graphics, ideal for gaming and system-intensive tasks.

WHAT'S IN THE BOX

- Desktop PC
- Keyboard
- Mouse
- Power Cord

SETUP GUIDE

Unpacking and Placement

Carefully remove the PC and accessories from the packaging. Place the PC on a stable, flat surface with adequate ventilation. Ensure there is clear space around the air intakes and exhausts.



This image shows the complete system, including the desktop tower, keyboard, and mouse, ready for setup.

Connecting Peripherals

Connect your monitor(s) to the graphics card ports (HDMI or DisplayPort). Connect the keyboard and mouse to the available USB ports.



This image illustrates the rear panel of the PC, highlighting the various connectivity options for peripherals such as USB ports, HDMI, and DisplayPort.

Power Connection

Connect the power cord to the PC's power supply unit and then to a grounded electrical outlet.

Initial Boot-up

Press the power button located on the top of the PC. The system will boot into Windows 11 Home. Follow the on-screen instructions for initial Windows setup.





This image provides a top-down perspective of the PC, clearly showing the power button and accessible USB ports on the top panel for easy access.

OPERATING INSTRUCTIONS

System Overview

Your CyberPowerPC Gamer Supreme is equipped with an Intel Core Ultra 9 processor, NVIDIA GeForce RTX 5060 Ti graphics, 32GB DDR5 RAM, and a 2TB PCIe 4.0 NVMe SSD, providing exceptional performance for demanding applications and games.




This image displays the internal components of the PC, including the liquid cooling system for the CPU, the DDR5 RAM modules, and the NVIDIA GeForce RTX 5060 Ti graphics card, all contributing to its high performance.


Connectivity

The system offers extensive connectivity options including USB-C 3.2, USB-A 3.2, USB-A 2.0, LAN, WiFi 6, and Bluetooth 5.3.

Custom RGB Lighting

The PC features custom RGB lighting. Refer to the pre-installed software (if any) for customization options.







This image shows a side profile of the PC, emphasizing the tempered glass side panel which allows a clear view of the internal components and their vibrant RGB lighting.

TECHNICAL SPECIFICATIONS

Component	Detail
Processor	Intel Core Ultra 9 285 2.5GHz (24 Cores)
Chipset	Intel Z890
RAM	32GB DDR5 6400MHz
Storage	2TB PCIe 4.0 NVMe SSD
Graphics	NVIDIA GeForce RTX 5060 Ti 16GB
Video Outputs	1x HDMI, 2x DisplayPort
USB Ports	2x USB-C 3.2, 4x USB-A 3.2, 4x USB-A 2.0
Network	1x LAN, WiFi 6, Bluetooth 5.3
Audio	7.1 Channel Audio
Operating System	Windows 11 Home
Cooling	Liquid Cool CPU
Case Features	Tempered Side Case Panel, Custom RGB Lighting
Dimensions (Package)	23.98 x 23.86 x 13.46 inches
Weight	44.9 pounds

MAINTENANCE

Cleaning

Regularly clean the exterior of the PC with a soft, dry cloth. Use compressed air to clear dust from vents and fans to ensure optimal airflow and cooling.

Software Updates

Keep your operating system, drivers, and applications updated to ensure system stability and performance.

Cable Management

Ensure cables are neatly organized to prevent obstruction of airflow and to maintain a tidy setup.

TROUBLESHOOTING

No Power

Check if the power cord is securely connected to both the PC and the electrical outlet. Ensure the power supply switch on the back of the PC is in the 'ON' position.

No Display

Verify that your monitor is properly connected to the graphics card outputs (not the motherboard outputs, unless using integrated graphics). Ensure the monitor is powered on and set to the correct input source.

System Slowdown

Check for background applications consuming high resources. Ensure sufficient free space on your SSD. Run a system scan for malware.

Overheating

Ensure the PC has adequate ventilation. Clean dust from fans and vents. Monitor temperatures using system monitoring software.

WARRANTY AND SUPPORT

Warranty Information

Your CyberPowerPC Gamer Supreme Gaming PC comes with a 1 Year Parts & Labor Warranty. This warranty covers defects in materials and workmanship under normal use.

Technical Support

Free Lifetime Technical Support is provided for your CyberPowerPC product. For assistance, please visit the official CyberpowerPC support website or contact their customer service.

For more information, visit: [CyberpowerPC Support](#)