

Genérico VS001

User Manual

VIBE SOUND V12 POWER AF 12-INCH AMPLIFIED SPEAKER

Model: VS001

1. Introduction

Thank you for purchasing the Vibe Sound V12 Power AF 12-inch Amplified Speaker. This powerful and versatile speaker is designed to deliver high-quality audio for various occasions, from personal entertainment to public events. Please read this manual carefully before operating the device to ensure proper use and to maximize its performance and longevity.

2. Safety Information

- Power Source:** Use only the specified power adapter. Ensure the voltage matches the requirements of the speaker.
- Water and Moisture:** Do not expose the speaker to rain, moisture, or any liquids. Keep it away from water sources.
- Ventilation:** Ensure adequate ventilation around the speaker. Do not block any ventilation openings.
- Heat:** Keep the speaker away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Cleaning:** Unplug the speaker from the power outlet before cleaning. Use a dry, soft cloth for cleaning. Do not use liquid cleaners or aerosol cleaners.
- Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- Placement:** Place the speaker on a stable, flat surface to prevent it from falling.
- Hearing Protection:** Avoid prolonged listening at high volume levels to prevent hearing damage.

3. Package Contents

Please check the package for the following items:

- Vibe Sound V12 Power AF 12-inch Amplified Speaker (Model: VS001)
- Wired Microphone
- Power Adapter/Cable
- User Manual (this document)

4. Product Overview

Familiarize yourself with the main components of your Vibe Sound V12 Power AF speaker.



Figure 4.1: Front view of the Vibe Sound V12 Power AF 12-inch Amplified Speaker. This image shows the speaker's main grille, the 12-inch woofer, and the control panel located at the top. Red LED lights illuminate the speaker's design.



Figure 4.2: Side view of the Vibe Sound V12 Power AF speaker, highlighting its portability features. The retractable handle is extended, and the wheels at the base are visible, designed for easy transport.



Figure 4.3: Front view of the Vibe Sound V12 Power AF speaker showcasing its dynamic multi-color LED lighting. The lights are visible around the speaker grille and along the top and bottom sections, indicating various light modes.

Control Panel (Top View)

- **Power Button:** Turns the speaker On/Off.
- **Mode Button:** Switches between Bluetooth, USB, SD, and FM Radio modes.
- **Play/Pause Button:** Controls media playback.
- **Previous/Next Track Buttons:** Navigates through tracks or FM stations.
- **Volume Knobs:** Adjusts master volume, microphone volume, and echo.
- **USB Port:** For USB flash drives.
- **SD Card Slot:** For SD memory cards.
- **Microphone Input:** For connecting the wired microphone.
- **Auxiliary Input:** For connecting external audio devices via a 3.5mm cable.
- **LED Display:** Shows current mode, track number, or FM frequency.

5. Setup

5.1 Charging the Speaker

1. Locate the DC input port on the back or side of the speaker.

2. Connect the provided power adapter to the speaker's DC input port.
3. Plug the other end of the power adapter into a suitable wall outlet.
4. The LED indicator will show the charging status (e.g., red for charging, blue/green for fully charged).
5. Allow the speaker to fully charge before first use for optimal battery life.

5.2 Powering On/Off

- To turn on the speaker, press and hold the **Power Button** on the control panel until the LED display illuminates.
- To turn off the speaker, press and hold the **Power Button** again until the LED display turns off.

6. Operating Instructions

6.1 Bluetooth Connection

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, or you can press the **Mode Button** until "BLUE" or "BT" appears on the LED display.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for available Bluetooth devices. You should see "VIBE SOUND" or a similar name in the list.
4. Select "VIBE SOUND" to pair. Once connected, you will hear a confirmation sound, and the LED display may show "CONNECTED".
5. You can now play audio from your device through the speaker.

6.2 USB/SD Playback

1. Insert a USB flash drive into the **USB Port** or an SD card into the **SD Card Slot**.
2. The speaker will automatically switch to USB or SD mode and begin playing audio files (MP3, WAV, etc.). If not, press the **Mode Button** to select the correct mode.
3. Use the **Play/Pause** and **Previous/Next Track Buttons** to control playback.

6.3 FM Radio

1. Press the **Mode Button** until "FM" appears on the LED display.
2. To auto-scan and save available stations, press and hold the **Play/Pause Button**. The speaker will scan and store stations automatically.
3. Use the **Previous/Next Track Buttons** to navigate between saved FM stations.

6.4 Microphone Usage

1. Connect the wired microphone to the **Microphone Input** port.
2. Adjust the **Microphone Volume Knob** to control the microphone's output level.
3. Use the **Echo Knob** to add an echo effect to your voice (if available).

6.5 Volume Control and Light Modes

- **Master Volume:** Use the main **Volume Knob** to adjust the overall sound output of the speaker.
- **Light Modes:** The speaker features integrated LED lights. There may be a dedicated button or a combination of buttons to cycle through different light patterns or turn them off. Refer to the specific button labels on your unit.

7. Maintenance

- Cleaning:** Wipe the speaker's exterior with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents.
- Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use, to maintain battery health.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is depleted; Power cable not connected properly.	Charge the speaker; Ensure power cable is securely connected to both speaker and outlet.
No sound	Volume is too low; Incorrect mode selected; Device not paired (Bluetooth).	Increase volume; Press Mode button to select correct input; Re-pair Bluetooth device.
Bluetooth not connecting	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in Bluetooth mode; Move device closer; Turn off other Bluetooth devices.
USB/SD not playing	Unsupported file format; Corrupted files; Drive/card not inserted correctly.	Ensure files are MP3/WAV; Check drive/card for errors; Re-insert drive/card.
Microphone not working	Microphone not connected; Microphone volume too low.	Ensure microphone is securely plugged in; Increase microphone volume knob.

9. Specifications

Feature	Detail
Model Name	V12 Power AF 12" (VS001)
Brand	Generic (Vibe Sound)
Speaker Type	Portable, Amplified
Woofer Size	12 inches
Output Power (RMS)	800W (as per description)
Max Output Power	1800 Watts (as per specifications)
Connectivity Technology	Bluetooth, USB, SD Card, FM Radio, Microphone Input, Auxiliary Input
Bluetooth Version	Bluetooth (specific version not provided)
Frequency Response	50 Hz
Impedance	3.6 Ohm

Feature	Detail
Audio Output Mode	Mono
Power Source	AC/DC
Product Dimensions (D x W x H)	33 cm x 33 cm x 70 cm
Product Weight	11 Kilograms
Included Components	Speaker, Microphone
Color	Black

10. Warranty and Support

This Vibe Sound V12 Power AF speaker comes with a manufacturer's warranty of **3 Months** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

The warranty does not cover damages caused by:

- Improper installation or operation.
- Accidents, misuse, abuse, neglect, or unauthorized modification.
- Power surges or lightning damage.
- Normal wear and tear.

For warranty claims or technical support, please contact your retailer or the manufacturer's customer service. Please have your proof of purchase and the product's model number (VS001) ready when contacting support.