

## Mojikoo S01

# Mojikoo S01 White Noise Machine Alarm Clock User Manual

Model: S01 | Brand: Mojikoo

## INTRODUCTION

Thank you for choosing the Mojikoo S01 White Noise Machine Alarm Clock. This versatile device combines a white noise machine, dimmable alarm clock, Bluetooth speaker, and nightlight into one compact unit, designed to enhance your sleep, relaxation, and wake-up routines. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and a seamless user experience.

## PRODUCT OVERVIEW

The Mojikoo S01 is an all-in-one bedside companion with the following key features:

- **4-in-1 Functionality:** White Noise Machine, Dimmable Alarm Clock, Bluetooth Speaker, and Nightlight.
- **Auto-Dimming Display:** Automatically adjusts screen brightness based on ambient light, with manual fine-tuning from 0-100%.
- **5W Stereo Bluetooth Speaker:** For streaming music, audiobooks, or meditation tracks.
- **24 Soothing Sounds:** Includes white noise, rain, ocean, and fan sounds, with 32 adjustable volume levels.
- **8 Gentle Alarms:** Features soothing wake-up sounds like birds, piano, and waves, with gradual volume increase and a 9-minute snooze.
- **9-Color Dimmable Nightlight:** Creates a calming ambiance with adjustable colors and brightness.
- **Chic Fabric Design:** Modern aesthetic that blends with various bedroom decors.

# All-IN-ONE Sleep-Wake Solution





-  Sound Machine
-  Alarm Clock
-  Bluetooth Speaker
-  Night Light



Image: The Mojikoo S01 device highlighting its four main functions: Sound Machine, Alarm Clock, Bluetooth Speaker, and Night Light.

## SETUP

### 1. Power Connection

- Unpack the Mojikoo S01 and its power adapter.
- Connect the power adapter to the DC 5V port on the back of the device.
- Plug the power adapter into a standard wall outlet. The display will light up, indicating the device is powered on.

### 2. Initial Setup

- Upon first power-on, the device may display a default time. Refer to the 'Time Setting' section to adjust it.
- Ensure the auto-dimming switch on the bottom of the device is set to 'AUTO' or 'ON' as desired.

## OPERATING INSTRUCTIONS

### 1. Time Setting

- Press the **Clock** button (usually indicated by a clock icon) once to enter hour setting mode. The hour digits will flash.
- Use the + and - buttons to adjust the hour.
- Press the **Clock** button again to enter minute setting mode. The minute digits will flash.
- Use the + and - buttons to adjust the minutes.
- Press the **Clock** button a third time to select 12-hour or 24-hour format. Use + and - to toggle.
- Press the **Clock** button once more to confirm and exit time setting.

### 2. Alarm Setting

- Press the **Alarm** button (usually indicated by an alarm clock icon) once to enter alarm hour setting mode. The hour digits will flash.
- Use the + and - buttons to set the desired alarm hour.
- Press the **Alarm** button again to enter alarm minute setting mode. The minute digits will flash.
- Use the + and - buttons to set the desired alarm minutes.
- Press the **Alarm** button a third time to select an alarm sound (A01-A08). Use + and - to cycle through the 8 gentle alarm sounds.

- Press the **Alarm** button a fourth time to adjust the alarm volume. Use **+** and **-** to set the volume.
- Press the **Alarm** button once more to confirm and activate the alarm. An alarm icon will appear on the display.
- To turn off a sounding alarm, press any button. To disable the alarm completely, press and hold the **Alarm** button until the alarm icon disappears.
- To activate the 9-minute snooze function, press the top surface of the device when the alarm sounds.

### 3. Sound Machine Operation

- Press the **Music Note** button to turn on the sound machine.
- Press the **Music Note** button repeatedly to cycle through the 24 soothing sleep sounds (e.g., white noise, fan, rain, ocean, thunder, brook, forest, wind).
- Use the **+** and **-** buttons to adjust the volume (32 levels).
- To turn off the sound machine, press and hold the **Music Note** button.




Image: The Mojikoo S01 offers 24 soothing sleep sounds for night and 8 gentle wake-up sounds for morning.

### 4. Bluetooth Speaker Pairing

- Press the **BT** button (Bluetooth icon) to activate Bluetooth pairing mode. The Bluetooth indicator light will flash.
- On your mobile device, enable Bluetooth and search for 'Mojikoo S01'.
- Select 'Mojikoo S01' to pair. Once connected, the Bluetooth indicator light will become solid.
- You can now stream audio from your device through the Mojikoo S01 speaker.
- To disconnect Bluetooth, press and hold the **BT** button.



Image: The Mojikoo S01 connected via Bluetooth to a smartphone, providing an immersive audio experience.

## 5. Nightlight Control

- Press the **Lightbulb** button to turn on the nightlight.
- Press the **Lightbulb** button repeatedly to cycle through the 9 available colors.
- Use the **Sun** icon button (brightness control) to adjust the nightlight's brightness.
- To turn off the nightlight, press and hold the **Lightbulb** button.




Image: The Mojikoo S01 features a dimmable bedside nightlight with 9 color options.

## 6. Timer Function

- Press the **Hourglass** button to activate the sleep timer.
- Press the **Hourglass** button repeatedly to cycle through available timer durations (e.g., 30, 60, 90, 120, 240 minutes, or OFF).
- The selected timer duration will be displayed. The device will automatically turn off sounds and lights after the set time.



Image: The sleep timer function allows the device to automatically turn off after a set duration.

## 7. Display Brightness Control

- The device features an auto-dimming display that adjusts to ambient light. This can be enabled/disabled via a switch on the bottom of the unit (OFF/AUTO/ON).
- To manually adjust display brightness, press the **Sun** icon button (brightness control).
- Press the **Sun** icon button repeatedly to cycle through different brightness levels (0-100%).

Image: The display offers both auto-dimming and manual brightness adjustment for optimal comfort.

## MAINTENANCE

- To clean the device, wipe it with a soft, dry cloth.
- Do not use liquid cleaners or abrasive materials.
- Keep the device away from water and excessive moisture.

## TROUBLESHOOTING

---

Problem	Solution
Device does not power on.	Ensure the power adapter is securely connected to both the device and a working power outlet.
Alarm does not sound.	Verify the alarm is set and activated (alarm icon visible). Check alarm volume settings.
Bluetooth not connecting.	Ensure the device is in Bluetooth pairing mode (flashing BT indicator). Check your mobile device's Bluetooth settings and try reconnecting.
Display is too bright/dim.	Adjust manual brightness using the Sun icon button or check the auto-dimming switch on the bottom of the device.
Sound machine not playing.	Ensure the sound machine is turned on and volume is adjusted.

## SPECIFICATIONS

---

- **Model Name:** S01
- **Brand:** Mojikoo
- **Color:** Cloud Blue
- **Power Source:** Corded Electric
- **Speaker Output:** 5W Stereo
- **Dimensions:** 6.42 x 4.88 x 3.31 inches
- **Weight:** 1.12 Pounds
- **ASIN:** B0DZ2VYPFW
- **Manufacturer:** Mojikoo

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Mojikoo website. Keep your purchase receipt for warranty claims.