

[manuals.plus](#) /› [Electactic](#) /› [Electactic Countertop Ice Maker User Manual](#)

Electactic ice maker

Electactic Countertop Ice Maker User Manual

Model: ice maker

INTRODUCTION

Thank you for choosing the Electactic Countertop Ice Maker. This compact and portable ice machine is designed to provide fresh bullet-shaped ice cubes quickly and efficiently, making it ideal for home, office, camping, and parties. Please read this manual thoroughly before operation to ensure safe and optimal performance of your ice maker.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not touch the evaporator or ice cubes when the ice maker is operating.
- Do not immerse cord, plug, or any part of the unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Avoid using attachments not recommended by the manufacturer.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Ensure the appliance is placed on a stable, level surface to prevent tipping.
- Do not block any ventilation openings. Ensure adequate air circulation around the unit.
- Use only potable water in the ice maker.
- Unplug the appliance from the outlet when not in use and before cleaning.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Electactic Ice Maker:



Figure 1: The Electactic Countertop Ice Maker, showing its compact design, handle, and included ice basket and scoop.

- **Transparent Lid:** Allows you to view the ice-making process and ice level without opening the unit.
- **Control Panel:** Features indicator lights for "ADD WATER", "ICE FULL", and "POWER", along with an ON/OFF button.
- **Ice Basket:** Removable basket for collecting and storing newly made ice cubes.
- **Ice Scoop:** Included for convenient and hygienic ice retrieval.
- **Water Reservoir:** Internal tank for holding water for ice production.
- **Drain Plug:** Located at the bottom for easy water drainage during cleaning.

Simple Operation Panel



Figure 2: Detailed view of the ice maker's simple operation panel, showing the "ADD WATER", "ICE FULL", and "POWER" indicator lights, and the ON/OFF button.

SETUP

- Unpack:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective film.
- Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is at least 4 inches of space around the unit for proper ventilation.
- Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Cleaning and Maintenance" section for detailed instructions.
- Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Operating your Electactic Ice Maker is a simple two-step process:

- 1. Add Water:** Open the lid and pour potable water into the water reservoir up to the MAX fill line. Do not overfill.
- 2. Start Ice Production:** Close the lid and press the "ON/OFF" button on the control panel. The "POWER" indicator light will illuminate, and the ice maker will begin the ice-making cycle.

Ice Production Cycle:

- The ice maker will produce 9 bullet-shaped ice cubes in approximately 6-8 minutes per cycle.
- The "ICE FULL" indicator light will illuminate when the ice basket is full, and the machine will automatically pause ice production. Remove ice to resume operation.
- The "ADD WATER" indicator light will illuminate when the water reservoir is low. Add more water and press the "ON/OFF" button to restart the cycle.



Figure 3: Illustration of the rapid ice production, showing ice cubes being dispensed into the basket.

Bullet Shaped Ice Make



6Mins/9Pcs

Figure 4: Close-up view of the bullet-shaped ice cubes produced by the machine.

The ice maker operates quietly, with noise levels below 45dB, making it suitable for various environments.

Low Noise



Figure 5: The ice maker's low noise operation, suitable for quiet environments.

CLEANING AND MAINTENANCE

Regular cleaning ensures hygienic ice production and extends the lifespan of your ice maker. This unit features a convenient self-cleaning function.

Self-Cleaning Function:

1. Ensure the ice maker is empty of ice and water.
2. Add clean water to the reservoir up to the MAX fill line.
3. Press and hold the "ON/OFF" button for 5 seconds. The machine will enter self-cleaning mode.
4. The cleaning cycle will run for approximately 20 minutes. Once complete, the machine will stop.
5. Drain the water by removing the drain plug at the bottom of the unit.
6. Rinse the interior with fresh water and drain again.

Convenient Self-Cleaning



Figure 6: Internal view illustrating the self-cleaning water circulation system.

Manual Cleaning:

- Unplug the ice maker before cleaning.
- Remove the ice basket.
- Clean the interior with a soft cloth dampened with a mild detergent solution. Rinse thoroughly with clean water.
- Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are completely dry before storing or reusing.

TROUBLESHOOTING

If you encounter issues with your ice maker, refer to the following table:

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|------------------------------------|----------------------------------------------------------------|------------------------------------------------------------------------------------|
| "ADD WATER" indicator light is on. | Water reservoir is empty or low. | Add potable water to the MAX fill line and restart the machine. |
| "ICE FULL" indicator light is on. | Ice basket is full. | Remove ice from the basket. The machine will resume operation automatically. |
| Ice maker is not making ice. | No power, insufficient water, or ambient temperature too high. | Check power connection. Add water. Ensure unit is in a cool, well-ventilated area. |
| Ice cubes are small or cloudy. | Water quality, or ambient temperature. | Use filtered water. Ensure proper ventilation and cooler ambient temperature. |

SPECIFICATIONS

| Feature | Detail |
|--------------------------------|----------------------------|
| Brand | Electactic |
| Model Name | ice maker |
| Product Dimensions (D x W x H) | 11.57"D x 8.74"W x 11.42"H |
| Capacity (Water Reservoir) | 5.3 Liters |
| Wattage | 120 watts |
| Ice Production | 9 cubes per 6-8 minutes |
| Daily Ice Output | Up to 26 lbs in 24 hours |
| Noise Level | Below 45dB |

Compact and Space-Saving



Figure 7: Dimensions of the compact and space-saving ice maker.

WARRANTY AND SUPPORT

Electactic products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the product packaging or contact Electactic customer service. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Electactic store or contact their customer support channels.

Portable Handy Design



Figure 8: The portable design of the ice maker makes it suitable for various outdoor and indoor gatherings.