

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SOVMIKU](#) /

› [SOVMIKU Vicohome 128GB Micro SD Card Instruction Manual](#)

SOVMIKU 2128GB

SOVMIKU Vicohome 128GB Micro SD Card Instruction Manual

1. PRODUCT OVERVIEW

The SOVMIKU Vicohome 128GB Micro SD Card is designed for high-performance storage in a variety of compatible devices. Featuring UHS-I U3 speed class and A1 application performance, it is suitable for recording 4K video and loading applications quickly. This card provides reliable storage for security cameras, action cameras, drones, dash cameras, gaming consoles, and more.



Image: Two Vicohome Micro SD cards, illustrating the product's appearance and capacity options.

2. SETUP AND INSTALLATION

Follow these steps to properly install your Micro SD card into a compatible device.

1. **Power Off Device:** Before inserting the Micro SD card, ensure your device (e.g., security camera, action camera, smartphone) is completely powered off.
2. **Locate SD Card Slot:** Identify the Micro SD card slot on your device. This is often a small slot, sometimes covered by a protective flap.
3. **Insert Card:** Gently insert the Micro SD card into the slot. The gold contacts on the card should typically face downwards or as indicated by a small diagram near the slot. Apply light pressure until the card clicks into place, indicating it is securely seated.
4. **Power On Device:** Once the card is inserted, power on your device. The device should recognize the new storage.
5. **Format (Optional but Recommended):** For optimal performance and compatibility, it is often recommended to format the Micro SD card using your device's internal settings. Refer to your device's manual for specific formatting instructions. **Note: Formatting will erase all data on the card.**



Image: Proper insertion of a Micro SD card into a device.



Image: Visual guide for inserting and removing Micro SD cards.

3. OPERATING INSTRUCTIONS

The Vicohome 128GB Micro SD Card is designed for seamless operation across a range of devices.

- **Data Storage:** Use the card to store photos, videos (including 4K resolution), applications, and other digital files. The 128GB capacity allows for extended recording times and ample storage space.
- **Application Performance:** With A1-rated performance, the card optimizes app loading and execution directly from the card, enhancing the user experience on compatible smartphones and tablets.
- **Compatibility:** This Micro SD card is compatible with devices requiring Micro SD, Micro SDHC, or Micro SDXC cards, including security cameras, action cameras, drones, dash cameras, smartphones, tablets, DSLR cameras, GPS devices, laptops, and gaming consoles.
- **Data Transfer:** To transfer data to or from the card, connect your device to a computer or use a dedicated Micro SD card reader.



Image: The Micro SD card's compatibility with a wide range of electronic devices.

4. MAINTENANCE AND CARE

Proper care ensures the longevity and reliable performance of your Micro SD card.

- **Physical Protection:** Avoid bending, dropping, or applying excessive force to the card. Store it in a protective case when not in use to prevent damage to the contacts or card body.
- **Temperature and Environment:** Do not expose the card to extreme temperatures (hot or cold), high humidity, or direct sunlight for prolonged periods.
- **Cleaning:** If the gold contacts appear dirty, gently wipe them with a soft, dry, lint-free cloth. Do not use liquids or abrasive materials.
- **Safe Ejection:** Always use the