

Manuals.plus /

› eeTao /

› eeTao 42V 1.5A Charger User Manual for MAXSHOT V7 Electric Scooters

## eeTao MAXSHOT V7 42V Charger

# eeTao 42V 1.5A Charger User Manual

Model: MAXSHOT V7 42V Charger

Compatible with MAXSHOT V7 8.5"/10" Tire Electric Scooters (36V 5.2Ah Lithium-ion Battery Pack)

## 1. INTRODUCTION

Thank you for choosing the eeTao 42V 1.5A Replacement Charger. This manual provides essential information for the safe and efficient use of your charger. Please read it thoroughly before operation and retain it for future reference.

This charger is designed to provide a stable 42V DC output at 1.5A, specifically for charging 36V 5.2Ah Lithium-ion battery packs found in MAXSHOT V7 8.5" and 10" tire electric scooters.

### Package Contents:

- 1 x eeTao 42V 1.5A Charger Adapter
- 1 x 5-foot Power Cable

## 2. SAFETY PRECAUTIONS

- Use only with compatible 36V Lithium-ion battery packs. Using with incompatible batteries may cause damage or injury.
- Do not expose the charger to water, moisture, or extreme temperatures.
- Do not disassemble or modify the charger.
- Keep out of reach of children.
- Ensure proper ventilation during charging. Do not cover the charger.
- Disconnect the charger from the power outlet when not in use.
- If the charger or cable is damaged, discontinue use immediately and replace it.

## 3. SETUP

1. **Inspect the Charger:** Before first use, visually inspect the charger adapter and power cable for any signs of damage.
2. **Connect Power Cable:** Insert the 5-foot power cable into the AC input port of the charger adapter.

3. **Prepare Scooter:** Ensure your MAXSHOT V7 electric scooter is turned off before connecting the charger. Locate the charging port on your scooter.

## eeTao<sup>®</sup> AC Adapter Power Supply Compatible with:



(Machine not Included)

Image 1: The eeTao 42V 1.5A charger adapter and its accompanying 5-foot power cable. The charger features a barrel connector for output.

### 4. OPERATING INSTRUCTIONS

1. **Connect to Scooter:** Insert the barrel connector of the charger into the charging port of your MAXSHOT V7 electric scooter.
2. **Connect to Power Outlet:** Plug the power cable into a standard 100-240VAC 50/60Hz wall outlet.
3. **Monitor Charging Indicator:** The charger features an LED indicator light.
  - A **RED** light indicates that the battery is currently charging.

- A **GREEN** light indicates that charging is complete.

4. **Charging Time:** Charging time will vary depending on the battery's current charge level. Refer to your scooter's manual for typical charging durations.
5. **Disconnecting:** Once the indicator light turns green, disconnect the charger from the wall outlet first, then from the scooter's charging port.

## eeTao<sup>®</sup> AC Adapter Power Supply Compatible with:

### Charging indicator light is more convenient




Image 2: The charger's LED indicator showing red for charging and green for fully charged.

## 5. MAINTENANCE

- **Cleaning:** Use a dry, soft cloth to clean the charger. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and moisture when not in use.
- **Cable Care:** Avoid bending or kinking the power cable excessively. Do not place heavy objects on the cable.
- **Regular Inspection:** Periodically check the charger and cable for any signs of wear or damage.

# Premium Cable




Image 3: Illustration of the charger's cable construction, highlighting the inner insulator, coarsening core, and TPE protective layer for durability.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Charger light does not turn on.	No power from outlet; loose connection; damaged charger/cable.	Check wall outlet with another device. Ensure all connections are secure. Inspect charger and cable for damage; replace if necessary.
Charger light remains RED for an extended period.	Battery is deeply discharged; battery capacity is large; battery is damaged.	Allow more time for charging. If charging takes excessively long or never turns green, consult your scooter's manual or a service professional. Note: A damaged battery will not accept charge.
Charger light immediately turns GREEN.	Battery is already fully charged; battery is damaged and not accepting charge.	Verify the battery's charge level on your scooter. If the battery is not fully charged, it may be damaged and require replacement.
Charger gets warm during use.	Normal operation; poor ventilation.	It is normal for the charger to get slightly warm. Ensure it is placed in a well-ventilated area and not covered. If it becomes excessively hot, disconnect immediately.

## 7. SPECIFICATIONS

<b>Brand</b>	eeTao
<b>Model Number</b>	MAXSHOT V7 42V Charger
<b>Input Voltage</b>	100-240VAC, 50/60Hz
<b>Output Voltage</b>	42V DC
<b>Output Current</b>	1.5 Amps
<b>Connector Type</b>	Barrel Connector
<b>Compatible Devices</b>	MAXSHOT V7 8.5"/10" Electric Scooters (36V Lithium-ion Battery Packs)
<b>Protection Features</b>	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
<b>Power Plug Type</b>	Type A (2-pin), Type B (3-pin) - North American & Japanese
<b>Item Weight</b>	10 Ounces (approx. 283g)

## 8. WARRANTY AND SUPPORT

**Warranty:** This eeTao charger comes with a 30-day refund policy and a 24-month exchange warranty from the date of purchase. This warranty covers manufacturing defects and normal operational failures. It does not cover damage caused by misuse, accidents, unauthorized modifications, or improper installation.

**Customer Support:** For any questions, troubleshooting assistance, or warranty claims, please contact eeTao customer support through the retailer where the product was purchased. Please have your purchase details and product model number ready.

**Important Note on Batteries:** Rechargeable batteries have a finite lifespan, typically 1 to 3 years. If your scooter's battery is damaged or has reached the end of its life, it may not accept a charge, and this is not an indication of a faulty charger.