

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PLANTKA](#) /

› [PLANTKA Front Wheel Replacement Manual for Roborock Qrevo Curv/Saros 10R/Saros 10](#)

PLANTKA Roborock Qrevo Curv/Saros 10R/Saros 10 Compatible Front Wheel

PLANTKA Front Wheel Replacement Manual

Compatible with Roborock Qrevo Curv, Saros 10R, Saros 10 Robot Vacuum Cleaners

1. INTRODUCTION

This manual provides detailed instructions for the installation, maintenance, and troubleshooting of your new PLANTKA front wheel, designed for compatibility with Roborock Qrevo Curv, Saros 10R, and Saros 10 robot vacuum cleaners. The front wheel is a critical component for the precise navigation and smooth movement of your robot vacuum.

2. PRODUCT FEATURES

- **Durable Construction:** Made from high-strength and environmentally friendly materials for extended lifespan.
- **Smooth Operation:** Ensures efficient and stable movement across various floor surfaces.
- **Easy Replacement:** Designed for straightforward removal and installation as part of routine maintenance.
- **Optimal Performance:** Recommended replacement every 2-3 months to maintain peak cleaning efficiency.
- **High Compatibility:** Perfectly matches the specified Roborock Qrevo Curv, Saros 10R, and Saros 10 models.

3. INSTALLATION GUIDE

Follow these steps to safely and correctly replace the front wheel on your robot vacuum cleaner.

3.1 Tools Required

- Small Phillips head screwdriver (if applicable for your vacuum model)
- Cleaning brush or cloth

3.2 Step-by-Step Replacement

1. **Power Off:** Ensure your robot vacuum cleaner is powered off and disconnected from its charging base.
2. **Position Vacuum:** Gently flip the vacuum cleaner over to expose its underside.
3. **Locate Old Wheel:** Identify the front wheel assembly. It is typically located at the front center of the vacuum.
4. **Remove Old Wheel:** Depending on your specific Roborock model, the wheel may simply pull out, or require a small screwdriver to release a retaining clip or screw. Carefully remove the old wheel.
5. **Clean Housing:** Use a cleaning brush or cloth to remove any accumulated hair, dust, or debris from the wheel housing area. This ensures the new wheel operates smoothly.
6. **Install New Wheel:** Align the new PLANTKA front wheel with the housing. Push it firmly into place until it clicks or is securely seated. If screws were removed, re-fasten them.
7. **Test Operation:** Flip the vacuum back over and power it on. Observe its movement to ensure the new wheel is functioning correctly.



Figure 1: View of the front wheel assembly, showing the attachment mechanism.



Figure 2: Side view of the front wheel, highlighting its compact design.



Figure 3: Exploded view of the front wheel and its housing, illustrating components for replacement.

4. MAINTENANCE

Regular maintenance of the front wheel is crucial for the optimal performance and longevity of your robot vacuum cleaner.

- **Cleaning:** Periodically inspect the front wheel for any accumulated hair, dust, or debris. Use a small brush or cloth to clean the wheel and its axle to ensure free rotation.
- **Replacement Schedule:** For best results and to maintain efficient navigation, it is recommended to replace the front wheel every 2-3 months. Replace sooner if you notice signs of wear, damage, or reduced mobility.

5. TROUBLESHOOTING

If you encounter issues with your robot vacuum's movement, consider the following troubleshooting steps related to the front wheel:

- **Vacuum not moving straight or turning properly:** This often indicates that the front wheel is obstructed or damaged. Power off the vacuum, remove the wheel, and check for any debris (hair, lint, etc.) caught in the axle or housing. Clean thoroughly. If the wheel appears physically damaged, replace it.
- **Unusual noises from the wheel area:** Grinding or squeaking noises can suggest debris trapped within the wheel mechanism or a worn-out bearing. Follow the cleaning steps outlined in Section 4. If the noise persists after cleaning, consider replacing the wheel.
- **Wheel not spinning freely:** Ensure there are no foreign objects preventing the wheel from rotating. Remove the wheel and manually spin it to check for resistance. Clean the axle and the wheel's interior.

6. SPECIFICATIONS

Feature	Detail
Package Dimensions	1.18 x 0.79 x 0.39 inches
Item Weight	1.76 ounces
Manufacturer	PLANTKA
Compatibility	Roborock Qrevo Curv, Saros 10R, Saros 10
Number of Pieces	1

7. SUPPORT AND CONTACT INFORMATION

For further assistance, technical support, or inquiries regarding your PLANTKA front wheel, please contact your retailer or the manufacturer directly. Always refer to your original Roborock vacuum cleaner's user manual for specific model-related instructions and safety guidelines.

Manufacturer: PLANTKA

