

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [BoxWave](#) /
- › [BoxWave SlimKeys Bluetooth Keyboard User Manual](#)

BoxWave SlimKeys Bluetooth Keyboard

BoxWave SlimKeys Bluetooth Keyboard User Manual

Model: SlimKeys Bluetooth Keyboard

1. INTRODUCTION

This manual provides instructions for the BoxWave SlimKeys Bluetooth Keyboard. This ultra-thin, portable keyboard is designed for comfortable and efficient typing across various devices, including the HMD Barbie Phone. Please read this manual carefully before using the product to ensure proper operation and longevity.



Image: The BoxWave SlimKeys Bluetooth Keyboard, showcasing its compact and sleek design.

The SlimKeys Bluetooth Keyboard features responsive, chiclet-style keys for a tactile typing experience. Its lightweight and compact design makes it ideal for travel, easily fitting into bags for on-the-go productivity. The keyboard utilizes Bluetooth 3.0 for quick and reliable pairing and includes a built-in on/off switch to conserve battery life.



Image: The SlimKeys Bluetooth Keyboard being stored in a bag, highlighting its ultra-thin and portable nature.

2. SETUP INSTRUCTIONS

2.1 Powering On/Off

Locate the ON/OFF switch on the top right side of the keyboard. Slide the switch to the 'ON' position to power on the keyboard. Slide it to 'OFF' when not in use to conserve battery.

2.2 Bluetooth Pairing

1. Ensure the keyboard is powered on.
2. Press the 'Connect' button, usually located near the ON/OFF switch. The Bluetooth indicator light will begin to flash, indicating the keyboard is in pairing mode.
3. On your device (e.g., HMD Barbie Phone), navigate to the Bluetooth settings.
4. Search for available devices. The keyboard should appear as 'BoxWave SlimKeys' or a similar name.
5. Select the keyboard from the list to initiate pairing. Your device may prompt you to enter a code displayed on the screen using the keyboard. Type the code and press Enter.
6. Once paired, the Bluetooth indicator light on the keyboard will stop flashing and remain solid or turn off, depending on the model. The keyboard is now ready for use.

Slim and Lightweight

Weighing just 0.4 lbs and only 0.2 in thick, SlimKeys is ideal for travel




Image: Close-up of the keyboard's top right corner, highlighting the 'Connect' button and power/charge indicators.

3. OPERATING INSTRUCTIONS

3.1 Basic Typing

The SlimKeys Bluetooth Keyboard features a standard QWERTY layout with chiclet-style keys, providing a comfortable and familiar typing experience. Simply open any text input application on your paired device and begin typing.



Image: A user typing comfortably on the SlimKeys Bluetooth Keyboard, demonstrating its ergonomic design.

3.2 Multi-Platform Compatibility

The keyboard is compatible with Android, Windows, and iOS operating systems. Certain function keys may behave differently depending on the connected device's operating system.

3.3 Specialized Function Keys

The keyboard includes specialized function keys for quick access to common commands. These keys are typically accessed by pressing the **Fn** key in combination with the desired function key (F1-F12).

- **Esc / Home (F1)**: Returns to the home screen or acts as Escape.
- **Search (F2)**: Opens the search function.
- **Select All (F3)**: Selects all content.
- **Copy (F4)**: Copies selected content.

- **Paste (F5):** Pastes copied content.
- **Cut (F6):** Cuts selected content.
- **Skip Back (F7):** Skips to the previous track/media.
- **Play/Pause (F8):** Plays or pauses media.
- **Skip Forward (F9):** Skips to the next track/media.
- **Volume Down (F10):** Decreases audio volume.
- **Volume Up (F11):** Increases audio volume.
- **Brightness Down (F12):** Decreases screen brightness.
- **Brightness Up (Fn + F12):** Increases screen brightness.
- **Lock (Delete):** Locks the device screen.



Image: A visual guide to the specialized function keys and their corresponding actions.

4. MAINTENANCE

4.1 Charging the Keyboard

The SlimKeys Bluetooth Keyboard features a long-lasting battery. When the battery is low, the charge indicator light will illuminate. Connect the included charging cable to the keyboard's charging port and to a USB power source (e.g., computer, wall adapter). The charge indicator will show charging status and turn off when fully charged. A full charge provides up to 30 days of active use or 6 months on standby.



Image: The SlimKeys Bluetooth Keyboard being charged via its USB port, illustrating the long-lasting battery feature.

4.2 Cleaning

To clean the keyboard, gently wipe the surface with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the keyboard's finish or internal components. Ensure no liquid enters the keyboard.

5. TROUBLESHOOTING

5.1 Keyboard Not Connecting

- Ensure the keyboard is powered on and fully charged.
- Make sure Bluetooth is enabled on your device.
- Try re-pairing the keyboard by following the 'Bluetooth Pairing' steps in Section 2.2.
- Ensure the keyboard is within the effective range of your device (typically up to 10 meters or 33 feet).
- Restart both the keyboard (turn off and on) and your device.

5.2 Keys Not Responding

- Check if the keyboard is properly connected via Bluetooth.
- Ensure the battery is not critically low. Charge the keyboard if necessary.
- Restart the keyboard and your device.

5.3 Lag or Delayed Input

- Ensure there are no obstructions or strong interference sources between the keyboard and your device.
- Move closer to your device to improve the Bluetooth connection.
- Disconnect and reconnect the keyboard.

6. SPECIFICATIONS

Feature	Detail
Brand	BoxWave
Model Name	SlimKeys Bluetooth Keyboard
Color	Jet Black
Connectivity Technology	Bluetooth 3.0
Number of Keys	104
Item Weight	8.6 Ounces (approx. 244 grams)
Dimensions (L x W x H)	9.5 in x 5.75 in x 0.2 in (approx. 24.1 cm x 14.6 cm x 0.5 cm)
Battery Life	Up to 30 days (active use), 6 months (standby)
Compatibility	Android, Windows, iOS devices (e.g., HMD Barbie Phone)



Chiclet Keys

Low-Profile and Responsive.



Multi-Platform

Compatible with Android, Windows & iOS operating systems.



Bluetooth 3.0 Protocol

Reliable, Easy-to-pair, Compatible.



Ultra-Slim and Light

Sleek and modern 3/16" profile.

BoxWave SlimKeys

Image: An infographic summarizing key features such as chiclet keys, multi-platform support, Bluetooth 3.0, and ultra-slim design.

7. WARRANTY AND SUPPORT

7.1 Return Policy

This product is subject to a 30-day return policy for refund or replacement, as per the seller's terms.

7.2 Manufacturer Information

BoxWave Corporation is committed to providing high-quality accessories. For further assistance or inquiries, please refer to the contact information provided with your purchase or visit the official BoxWave website.