



Manuals.plus /

› **Rolosar** /

› Wireless Earbuds, 2025 Bluetooth 5.4 Headphones Sport, Bluetooth Earbuds with ENC Noise Canceling Mic, 50H Stereo Wireless Headphones IP7 Waterproof with Earhooks, Dual LED Display for Workout/Running Light Black User Manual

Rolosar Q76

Wireless Earbuds User Manual

Model: Q76 | Brand: Rolosar

Introduction	What's in the Box	Product Overview	Setup	Operation	Maintenance
	Troubleshooting	Specifications	Support		

1. INTRODUCTION

This manual provides detailed instructions for the use and maintenance of your Rolosar Q76 Wireless Earbuds. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its lifespan. These earbuds feature Bluetooth 5.4 technology, ENC noise-canceling microphones, IP7 waterproofing, and a comfortable earhook design, making them suitable for various activities including sports and daily use.



Image 1.1: Rolosar Q76 Wireless Earbuds and their charging case. The earbuds feature an earhook design and are displayed within the open charging case, which shows a digital battery display.

2. WHAT'S IN THE BOX

The product package includes the following items:

- Rolosar Q76 Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Ear Tips (S/M/L sizes)
- User Manual

3. PRODUCT OVERVIEW

The Rolosar Q76 earbuds are designed for comfort and performance, featuring a secure earhook design and advanced audio technology.

3.1 Earbud Components

- **Earhook:** Provides a secure fit, especially during physical activity.
- **Touch Control Area:** Located on the outer surface for managing playback, calls, and voice assistant.
- **LED Indicator:** Displays connection status and battery level.
- **Microphone:** Built-in for calls with ENC noise canceling.
- **Ear Tip:** Silicone tips available in multiple sizes for optimal comfort and sound isolation.

3.2 Charging Case Components

- **Charging Ports:** Internal contacts for charging earbuds.
- **Dual LED Display:** Shows the battery percentage of the case and charging status of each earbud.
- **USB-C Port:** External port for charging the case.
- **Transparent Lid:** Allows visibility of the LED display.

4. SETUP

4.1 Initial Charging

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case. Ensure they are correctly seated and the LED indicators on the earbuds light up.
2. Connect the USB-C charging cable to the charging port on the back of the case and plug the other end into a USB power adapter (not included).
3. The LED display on the charging case will show the battery percentage. A full charge for the case takes approximately 2 hours. Earbuds charge in about 1.5 hours.

50H LONG PLAYTIME



Image 4.1: Illustration of the earbuds and charging case, highlighting the 50-hour total playtime and individual charging times for earbuds (1.5 hours) and the case (2 hours).

4.2 Pairing with a Device

The earbuds utilize Bluetooth 5.4 for a stable and efficient connection.

1. **Step 1:** Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. **Step 2:** On your smartphone or Bluetooth-enabled device, navigate to the Bluetooth settings and ensure Bluetooth is enabled.
3. **Step 3:** Search for available devices and select "Q76" from the list to connect.
4. Once successfully paired, the earbuds will automatically connect to the last paired device when removed from the case.

2025 Bluetooth 5.4

ONE STEP AUTO PAIRING

Step1: Open the lid (Earbuds auto power on)

Step2: After open the Phone Bluetooth, Click the <Q76> to Pairing



Image 4.2: Visual guide demonstrating the one-step auto-pairing process for the Q76 earbuds, showing the earbuds and a smartphone with Bluetooth settings open, displaying "Q76" as an available device.

4.3 Fitting the Earbuds

Proper fit is crucial for comfort, sound quality, and secure placement, especially during active use.

1. **Choose the Right Ear Tips:** Select the ear tips (S/M/L) that provide the best seal and comfort for your ears.
2. **Place the Earhook:** Gently place the earhook over your ear, ensuring it rests comfortably and securely behind your ear.
3. **Adjust the Earbud:** Rotate and adjust the earbud portion into your ear canal until you achieve a snug fit and optimal sound.

Designed for sports Earhooks Design

Comfortable, firm, not easy to fall off



- ① Choose the right size ear caps.
- ② Place the earhook over your ear.
- ③ Rotate and adjust to a comfortable angle.

Image 4.3: Step-by-step visual guide on how to properly fit the earbuds, showing selection of ear tip size, placing the earhook, and adjusting the earbud for a comfortable and secure fit.

5. OPERATING INSTRUCTIONS

The Rolosar Q76 earbuds feature smart touch controls for easy management of audio and calls.

5.1 Smart Touch Controls

The touch control area is located on the upper part of the earbud surface. Refer to the table below for specific functions:

Action	Function
Single Tap (L/R)	Play/Pause Music, Answer Call
Double Tap (L)	Previous Song
Double Tap (R)	Next Song
Triple Tap (L)	Volume Down (-)
Triple Tap (R)	Volume Up (+)
Long Press (2 seconds) (L/R)	Reject Call, Activate Voice Assistant
Long Press (5 seconds) (L/R)	Power On/Off
Quickly tap L and R 5 times simultaneously	Unpair Headphones

SMART TOUCH CONTROL

High-sensitivity smart touch brings easy operation



Image 5.1: Diagram illustrating the various smart touch control functions on the earbuds, including power, play/pause, call management, volume, and track navigation.

5.2 Sound Quality

The earbuds incorporate 14.2mm double-layer diaphragm drivers, engineered to deliver a balanced audio experience with strong bass, clear mid-range frequencies, and bright treble. The ENC (Environmental Noise Cancellation) microphone technology ensures clear voice transmission during calls by reducing ambient distractions.



Image 5.2: Exploded view diagram showcasing the internal components of the earbud, emphasizing features like Call Noise Reduction, Dual Channel Transmission, ACC Audio Coding, and 13mm drivers for Hi-Fi Stereo and Deep Bass.

6. MAINTENANCE AND CARE

6.1 Waterproofing (IP7 Rating)

The Rolosar Q76 earbuds are rated IP7 waterproof, meaning they are protected against immersion in water up to 1 meter for 30 minutes. This makes them resistant to sweat, rain, and minor water splashes, suitable for workouts and outdoor activities. However, they are not designed for swimming or prolonged submersion.

IP7 WATERPROOF

ACCOMPANY THE MOVEMENT

No Worries When Using



Image 6.1: Visual representation of the IP7 waterproof feature, showing earbuds being resistant to rain, sweat, and splashes.

6.2 Cleaning

- Regularly clean the ear tips with a soft, dry cloth to remove earwax and debris.
- Wipe the earbuds and charging case with a slightly damp cloth. Avoid using harsh chemicals or abrasive materials.
- Ensure the charging contacts on both the earbuds and the case are clean and dry to prevent charging issues.

6.3 Storage

When not in use, store the earbuds in their charging case to protect them from damage and to keep them charged.

7. TROUBLESHOOTING

If you encounter any issues with your earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing/connecting	<ul style="list-style-type: none"> ◦ Ensure earbuds are charged and out of the case. ◦ Turn off and on Bluetooth on your device. ◦ Forget "Q76" from your device's Bluetooth list and re-pair. ◦ Try resetting the earbuds by quickly tapping both L and R earbuds 5 times simultaneously to unpair, then re-pair.
Only one earbud working	<ul style="list-style-type: none"> ◦ Place both earbuds back into the charging case, close the lid, then open it again and take them out. ◦ Ensure both earbuds are charged. ◦ Perform a reset/unpair as described above and re-pair.
No sound or low volume	<ul style="list-style-type: none"> ◦ Increase volume on both your device and the earbuds (triple tap R earbud). ◦ Ensure earbuds are properly seated in your ears and ear tips provide a good seal. ◦ Clean ear tips and earbud mesh for any obstructions.
Charging issues	<ul style="list-style-type: none"> ◦ Ensure the charging cable is securely connected to both the case and the power source. ◦ Check if the charging contacts on the earbuds and inside the case are clean. ◦ Try a different USB-C cable or power adapter.
Touch controls unresponsive	<ul style="list-style-type: none"> ◦ Ensure your fingers are clean and dry. ◦ Restart the earbuds by placing them in the case and taking them out.

8. SPECIFICATIONS

Feature	Detail
Model Name	Q76
Brand	Rolosar
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	15 Meters
Noise Control	Passive Noise Cancellation, Sound Isolation
Audio Driver Type	Dynamic Driver
Audio Driver Size	14.2 Millimeters
Frequency Range	20 Hz - 20,000 Hz
Impedance	32 Ohm
Earpiece Shape	Ear Hooks
Form Factor	In Ear
Control Method	Touch
Earbud Battery Life (Single Playtime)	Approx. 10 Hours
Total Playtime (with Charging Case)	Approx. 50 Hours
Charging Case Battery Capacity	430 Milliamp Hours
Earbud Charging Time	1.5 Hours
Case Charging Time	2 Hours
Water Resistance Level	IP7 Waterproof
Material	Silicone
Item Weight	81 Grams (2.86 ounces)
Product Dimensions	1.57 x 0.79 x 1.97 inches
Compatible Devices	Almost all Bluetooth-enabled devices (iOS, Android, tablets, laptops, TV)

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Rolosar customer service through their official channels. Keep your purchase receipt for warranty claims.

For further assistance, please visit the **Rolosar Store on Amazon**.

10. SAFETY INFORMATION

- Do not disassemble or modify the product.
- Keep away from extreme temperatures and direct sunlight.
- Avoid dropping or subjecting the earbuds to strong impacts.
- Do not use the product in environments where it could pose a safety hazard (e.g., driving, operating heavy machinery) if it obstructs hearing.
- Prolonged exposure to high volume levels may cause hearing damage.
- Dispose of the product and its battery responsibly according to local regulations.