

[manuals.plus](#) /

› [HOTWAV](#) /

› [HOTWAV R9 Pro Rugged Tablet 11" FHD User Manual](#)

HOTWAV R9 Pro

HOTWAV R9 Pro Rugged Tablet User Manual

Model: R9 Pro | Brand: HOTWAV

1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your HOTWAV R9 Pro Rugged Tablet. Please read it thoroughly before operating the device to ensure optimal performance and longevity.



Image: Front and back view of the HOTWAV R9 Pro Rugged Tablet, highlighting its robust design and 11-inch display.

2. WHAT'S IN THE Box

Verify that all items are present in the packaging:

- 1x HOTWAV R9 Pro Rugged Tablet
- 1x Manual (this document)
- 1x Packing Box
- 1x Explosion-proof Film
- 1x USB Type-C Cable
- 1x OTG Cable

3. PRODUCT OVERVIEW AND KEY FEATURES

3.1. Rugged Design and Durability

The HOTWAV R9 Pro is engineered for extreme environments, featuring IP68/IP69K waterproof and dustproof ratings, and MIL-STD-810H certification for shock resistance. Its construction includes a double-shot TPU+PC+glass fiber back cover for enhanced protection.

IP68&IP69K Rated MIL-STD-810H Certified+LED Camping Light



Image: Visual representation of the tablet's ruggedness, showing it submerged in water, covered in dust, and surviving a drop, alongside its LED camping light in use.

3.2. Battery and Charging

Equipped with a large 20080mAh battery, the R9 Pro offers extended usage times. It supports 20W fast charging to quickly replenish power.

Powerful 20800mAh Battery

120 days standby and OTG charge

20080mAh

Large Battery

20W

SuperVOOC

400H

Calling Time

1000H

Music play




Image: Diagram illustrating the 20080mAh battery capacity and 20W fast charging capability of the tablet.

3.3. Display

The tablet features an 11-inch FHD+ display with a resolution of 1200x1920 pixels and 450cd/m² brightness. It is protected by Corning Glass 3 and supports glove touch functionality, making it suitable for outdoor use.

11 Inch 2K Scratch Resistant Display



Image: The tablet's 11-inch display showing various applications, alongside icons indicating FHD+ resolution, 60Hz refresh rate, and dual SIM support.

3.4. Performance and Storage

Powered by an Octa-Core Unisoc T606 processor, the R9 Pro includes 20GB RAM (6GB physical + 14GB virtual) and 256GB internal storage. Storage can be expanded up to 2TB using a T-flash card.

Octa-core Unisoc T606 chipset

The HOTWAV R9 Pro Rugged Tablet features the Unisoc T606 octa-core chipset, and it's awesome! You can tackle all your heavy-duty tasks, switch between apps like a pro, and enjoy super speedy launches. It's built to be efficient and dependable, so you can stay productive in any tough situation!




Image: A visual representation of the Unisoc T606 octa-core chipset, detailing 20GB RAM and 256GB ROM with 2TB expandable memory.

3.5. Camera System

The tablet features a 64MP rear camera with PDAF and f/1.8 aperture, and a 16MP front camera for photography and video calls.

64 MP Rear Main Camera



16 MP Front Camera



Image: Examples of photos taken with the 64MP rear camera and the 16MP front camera, demonstrating their capabilities.

3.6. Integrated Camping Light

A unique 6W camping light with 350 lumens and 246 LEDs is integrated into the tablet, providing illumination for various outdoor activities or emergencies.

4. SETUP

4.1. Charging the Tablet

Before first use, fully charge the tablet using the provided USB Type-C cable and a compatible 20W power adapter (not included). Connect the cable to the tablet's USB-C port and the adapter to a power outlet. The charging indicator will show the charging status.

4.2. Installing SIM and T-flash Cards

The tablet supports dual SIM cards and a T-flash (microSD) card for expandable storage.

1. Locate the SIM/SD card tray on the side of the tablet.
2. Use the provided SIM ejector tool to open the tray.

3. Carefully place your Nano-SIM cards and/or T-flash card into the designated slots. Ensure correct orientation.
4. Gently push the tray back into the tablet until it clicks into place.

4.3. Powering On/Off

- **To Power On:** Press and hold the Power button until the HOTWAV logo appears.
- **To Power Off:** Press and hold the Power button until the power options menu appears, then select "Power Off".
- **To Restart:** Press and hold the Power button until the power options menu appears, then select "Restart".

5. OPERATING INSTRUCTIONS

5.1. Android 14 Operating System

The HOTWAV R9 Pro runs on Android 14, offering a user-friendly interface and access to a wide range of applications via the Google Play Store.

5.2. Navigation

Navigate the tablet using touch gestures:

- **Tap:** Select an item.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on images and web pages.
- **Long Press:** Access contextual menus or move icons.

5.3. Glove Touch Mode

The display supports glove touch, allowing you to operate the tablet while wearing gloves. This feature is automatically enabled.

5.4. Face Unlock

For convenient and secure unlocking, set up Face Unlock:

1. Go to **Settings > Security & privacy > Face unlock.**
2. Follow the on-screen instructions to register your face.



Image: A collage showing the tablet's GPS navigation, camping light in action, face unlock in progress, and a user operating the tablet with gloves.

5.5. Dual SIM Functionality

The tablet supports two SIM cards, allowing you to manage two different phone numbers or network providers simultaneously. You can configure preferred SIM for calls, messages, and data in **Settings > Network & internet > SIMs**.

6. CAMERA USAGE

The HOTWAV R9 Pro is equipped with a 64MP rear camera and a 16MP front camera.

- **Opening the Camera:** Tap the Camera icon on the home screen or app drawer.
- **Switching Cameras:** Tap the camera switch icon to toggle between the front and rear cameras.
- **Taking Photos:** Tap the shutter button to capture an image.
- **Recording Videos:** Switch to video mode and tap the record button to start/stop recording.
- **Camera Settings:** Access various settings like resolution, flash, and modes from within the camera app.

7. CAMPING LIGHT FUNCTIONALITY

The integrated 6W camping light provides powerful illumination.

- Activating the Light:** The camping light can typically be activated via a dedicated button (if present) or through a quick settings toggle in the notification panel.
- Adjusting Brightness/Modes:** Some models may offer adjustable brightness levels or different lighting modes. Refer to the on-screen controls once the light is activated.

8. CONNECTIVITY

- Wi-Fi:** Connect to wireless networks via **Settings > Network & internet > Internet**.
- Bluetooth:** Pair with Bluetooth devices (headphones, speakers) via **Settings > Connected devices > Connection preferences > Bluetooth**.
- GPS:** The tablet supports Beidou, Galileo, Glonass, and GPS for accurate location services. Ensure location services are enabled in **Settings > Location**.

9. MAINTENANCE

- Cleaning:** Use a soft, damp cloth to clean the tablet's surface. Avoid harsh chemicals or abrasive materials.
- Water Exposure:** While waterproof, ensure all ports are securely closed before exposing the tablet to water. After water exposure, dry the tablet thoroughly, especially the charging port, before charging.
- Temperature:** Avoid exposing the tablet to extreme temperatures (hot or cold) for prolonged periods.
- Storage:** When not in use for extended periods, store the tablet in a cool, dry place.

10. TROUBLESHOOTING

Problem	Possible Solution
Tablet does not power on.	Ensure the battery is charged. Connect to a charger for at least 30 minutes. If still unresponsive, perform a forced restart by holding the Power button for 10-15 seconds.
Slow performance.	Close unused applications. Clear cache regularly. Consider uninstalling unnecessary apps. Restart the tablet.
Wi-Fi connection issues.	Toggle Wi-Fi off and on. Restart your router. Forget the network and reconnect.
Battery drains quickly.	Reduce screen brightness. Close background apps. Disable unused features like GPS, Bluetooth, or Wi-Fi when not needed. Check battery usage in settings to identify power-hungry apps.
Camera not working.	Ensure the camera app has necessary permissions. Restart the tablet. Clear the camera app's cache and data in Settings > Apps .

11. SPECIFICATIONS

Feature	Detail
Model	R9 Pro
Operating System	Android 14
Display Size	11 Inches
Screen Resolution	1200 x 1920 pixels (FHD+)
Processor	Unisoc T606 Octa-Core (1.6 GHz)
Graphics Coprocessor	Mali G57 MP1@650MHz
RAM	20GB (6GB physical + 14GB virtual)
Internal Storage	256GB
Expandable Storage	Up to 2TB (T-flash card)
Rear Camera	64MP (PDAF, f/1.8 aperture)
Front Camera	16MP
Battery Capacity	20080mAh
Charging	20W Fast Charge
Ruggedness	IP68/IP69K Waterproof & Dustproof, MIL-STD-810H
Connectivity	Dual SIM, Wi-Fi, Bluetooth, GPS (Beidou, Galileo, Glonass)
Camping Light	6W (350 lumens, 246 LEDs)
Dimensions (LxWxH)	10.61 x 0.7 x 7.16 inches
Weight	2.35 pounds


12. WARRANTY AND SUPPORT

HOTWAV offers comprehensive after-sales service for the R9 Pro Rugged Tablet:

- **Return Policy:** 30-day no-reason return.
- **Warranty:** 2-year free warranty.
- **Technical Support:** Lifetime technical support.
- **Online Service:** 24/7 online customer service.

For support, please contact HOTWAV customer service through their official channels or visit their website.

Related Documents - R9 Pro

 USER MANUAL WWW.HOTWAV.COM	<p>HOTWAV Tablet User Manual: Setup, Features, and Safety Guide</p> <p>Comprehensive user manual for the HOTWAV tablet, covering setup instructions, feature explanations, safety guidelines, and warranty information. Learn how to use your device effectively.</p>
 USER MANUAL WWW.HOTWAV.COM	<p>HOTWAV User Manual: Your Guide to Connect Passion with Life</p> <p>Explore the HOTWAV User Manual for comprehensive instructions on using your HOTWAV device. Learn about device features, settings, safety precautions, and maintenance.</p>
 User Manual 	<p>HOTWAV H1 User Manual: Setup, Features, and Safety Guide</p> <p>Comprehensive user manual for the HOTWAV H1 mobile phone. Learn how to set up your device, use its features, understand safety guidelines, and access warranty information.</p>
 Note 13 Pro User Manual 	<p>HOTWAV Note 13 Pro User Manual</p> <p>User manual for the HOTWAV Note 13 Pro smartphone, covering device features, setup, safety guidelines, maintenance, and warranty information. Includes diagrams and accessory details.</p>
	<p>HOTWAV Note 13 Max Smartphone Product Data Sheet</p> <p>Product data sheet for the HOTWAV Note 13 Max smartphone, detailing technical specifications, energy efficiency, and repairability information according to EU regulations.</p>
	<p>NTEK FCC CFR47 PART 27 CERTIFICATION TEST REPORT for HOTWAV Cyber 7 Mobile Phone</p>
 	<p>This document is a certification test report from NTEK for the HOTWAV Cyber 7 mobile phone, FCC ID: 2AOKUCYBER7. It details the testing procedures and results for compliance with FCC CFR47 Part 27 regulations, covering aspects like output power, occupied bandwidth, band edge emissions, spurious radiation, and frequency stability.</p>

