

Kisfam B0F59WMD2H

Kisfam 4-in-1 Car Vacuum Cleaner User Manual

Model: B0F59WMD2H

1. INTRODUCTION

Thank you for choosing the Kisfam 4-in-1 Car Vacuum Cleaner. This device is designed for versatile cleaning, offering vacuuming, blowing, and inflation functions. Its compact, cordless design makes it ideal for both vehicle interiors and various household tasks. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. SAFETY INSTRUCTIONS

- Do not operate the vacuum cleaner with a damaged cord or plug.
- Keep hair, loose clothing, fingers, and all body parts away from openings and moving parts.
- Do not vacuum flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Ensure the filter is properly installed before use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Store the device in a dry place when not in use.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Kisfam 4-in-1 Car Vacuum Cleaner
- Various Nozzles/Attachments for Vacuuming, Blowing, and Inflation
- USB-C Charging Cable

- Storage Case
- User Manual

4. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Kisfam Car Vacuum Cleaner.



Figure 4.1: Mini Vacuum Cleaner for Car and Home. This image illustrates the vacuum cleaner's compact design and its application in various car interior areas such as air vents, footwells, crevices, and seats.



Figure 4.2: Compressed Air Blower Function. This image demonstrates the device's use as a compressed air blower for cleaning electronics like computers and keyboards, as well as window rails and air conditioner vents.

5. CHARGING THE DEVICE

Before first use, fully charge the vacuum cleaner. Use the provided USB-C cable for charging.

1. Connect the USB-C cable to the charging port on the vacuum cleaner.
2. Connect the other end of the USB-C cable to a compatible power source (e.g., wall adapter, computer, power bank).
3. The battery indicator light will show red during charging.
4. Once fully charged (approximately 3-4 hours), the indicator light will turn green.

Batería Recargable y Carga Rápida

Con Cable de Carga TYPE-C



Indicador de Bateria



Luz Roja: Cargando



Lorem Ipsum



6000mAh

Capacidad de la Bateria, Mayor Duración

Tiempo de Carga: 3-4 Horas

Figure 5.1: Rechargeable Battery and Fast Charging. This image highlights the Type-C charging port, battery indicator lights (red for charging, green for charged), and the 6000mAh battery capacity with a 3-4 hour charging time.

Múltiples Formas de Carga a Través del Puerto USB-C Mejorado



Figure 5.2: Multiple USB-C Charging Methods. This image illustrates the flexibility of charging the device using a wall adapter, a computer, or a power bank via its upgraded USB-C port.

6. OPERATING INSTRUCTIONS

6.1. Vacuum Mode

1. Attach the desired vacuum nozzle to the suction inlet.
2. Press the power button to turn on the vacuum cleaner.
3. Press the power button repeatedly to cycle through the three suction levels: 8000PA, 16000PA, and 22000PA.
4. Move the vacuum over the area to be cleaned.
5. Press and hold the power button to turn off the device.

6.2. Blower Mode

1. Attach the blower nozzle to the air outlet.
2. Press the power button to activate the blower function.
3. Direct the airflow to remove dust from hard-to-reach areas.

4. Press and hold the power button to turn off the device.

6.3. Inflation Mode

Use the appropriate inflation nozzle (if included) with the blower function to inflate items like floats or swimming rings.

1. Attach the inflation nozzle to the air outlet.
2. Insert the nozzle into the item to be inflated.
3. Press the power button to begin inflation.
4. Monitor the inflation process and turn off the device once the desired pressure is reached.



Figure 6.1: 22000PA Powerful Suction with 3 Modes. This image details the brushless motor design, offering more suction power and reduced noise. It also displays the three adjustable power modes: 8000PA (35 minutes runtime), 16000PA (20 minutes runtime), and 22000PA (15 minutes runtime).

7. MAINTENANCE

7.1. Emptying the Dustbin

To maintain optimal suction, empty the dustbin regularly.

1. Ensure the vacuum cleaner is turned off.
2. Twist the dustbin counter-clockwise to detach it from the main body.
3. Empty the collected debris into a waste bin.
4. Reattach the dustbin by twisting it clockwise until it clicks into place.

7.2. Cleaning the HEPA Filter

The HEPA filter is washable and reusable. Clean it periodically to ensure consistent performance.

1. Remove the dustbin as described above.
2. Carefully remove the HEPA filter from the dustbin.
3. Rinse the filter under running water until it is clean. Do not use detergents or hot water.
4. Allow the filter to air dry completely before reinserting it. Do not use the vacuum cleaner with a wet filter.
5. Once dry, place the filter back into the dustbin and reattach the dustbin to the main unit.



Figure 7.1: Reusable and Washable Filter. This image shows the HEPA filter being rinsed under water, demonstrating its washable and reusable nature for easy maintenance.

8. TROUBLESHOOTING

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Low suction power	Dustbin is full; Filter is clogged; Nozzle is blocked.	Empty the dustbin; Clean or replace the filter; Clear any blockages from the nozzle.
Device does not turn on	Battery is depleted; Device is faulty.	Charge the device fully; Contact customer support if the issue persists after charging.
Battery life is short	Operating at highest power setting; Battery degradation over time.	Use lower power settings for longer runtime; Ensure full charge before use.

9. SPECIFICATIONS

Technical specifications for the Kisfam Car Vacuum Cleaner:

Feature	Specification
Brand	Kisfam
Model	B0F59WMD2H
Form Factor	Handheld
Color	Gold and black
Product Dimensions	24L x 21W x 8H Centimeters
Item Weight	860 g
Suction Power	Up to 22000PA (3 modes)
Battery Capacity	6000mAh
Charging Time	Approx. 3-4 hours (with 5V/2A adapter)
Runtime	Up to 30 minutes (depending on power mode)
Filter Type	Washable HEPA Filter
Charging Port	USB-C
UPC	709084828646

Tamaño Pequeño y Portátil para Llevar Ahorro de Espacio

Bolsa de Almacenaje + Producto + Accesorios

Aproximadamente **0.8KG**



Figure 9.1: Compact and Portable Size. This image illustrates the small footprint of the vacuum cleaner, making it easy to carry and store, often accompanied by a storage bag for the product and its accessories. The approximate weight is 0.8KG.

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact Kisfam customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.