

[Manuals.plus](#) /

> [HyperMotion](#) /

> HyperMotion Outdoor Trampoline 244 cm / 8FT with Safety Net - Instruction Manual

HyperMotion TRAMPOLINE 8FT

HyperMotion Outdoor Trampoline 244 cm / 8FT with Safety Net

Model: TRAMPOLINE 8FT

INTRODUCTION

Thank you for choosing the HyperMotion Outdoor Trampoline. This manual provides essential information for the safe assembly, operation, and maintenance of your trampoline. Please read all instructions carefully before use to ensure the safety of all users and the longevity of the product.



Image: HyperMotion Outdoor Trampoline 244 cm / 8FT with Safety Net, showing its full structure including the safety enclosure and ladder.

SAFETY INFORMATION

The safety of all users is paramount. Adhere to the following guidelines:

- **Adult Supervision:** Always ensure adult supervision when children are using the trampoline.
- **One Jumper at a Time:** To prevent collisions and injuries, only one person should jump on the trampoline at any given time.
- **Weight Limit:** Do not exceed the maximum weight recommendation of 50 kg.
- **Age Recommendation:** Suitable for children aged 3 years and above.
- **Safety Net:** Always ensure the safety net is properly installed and secured before use. The internal safety net, tensioned with fiberglass rods, protects against falls.
- **Padding:** All springs and tubes are covered with thick foam padding for a safe play experience. Do not use the trampoline if padding is damaged or missing.
- **Clearance:** Ensure adequate overhead and surrounding clearance from walls, fences, trees, and other

obstacles.

- **Weather Conditions:** Do not use the trampoline in strong winds, rain, or other adverse weather conditions.
- **No Somersaults:** Avoid somersaults or other dangerous maneuvers unless professionally trained and supervised.
- **Footwear:** Jump barefoot or in trampoline-specific socks. Avoid shoes that can damage the mat.



Image: Close-up of the trampoline's safety net and padded poles, highlighting the protective features.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. The package includes:

- Trampoline Frame (Alloy Steel)
- Jumping Mat (Polypropylene)
- 42 High-Tension Springs
- Safety Net with Fiberglass Rods

- Foam Padding for Springs and Poles
- Non-slip Ladder
- Assembly Hardware
- Instruction Manual




Image: The trampoline's sturdy ladder and W-shaped legs, illustrating stability and access.

SETUP AND ASSEMBLY

Assembly is designed to be straightforward. It is recommended that two adults perform the assembly. Follow these general steps:

1. **Unpack Components:** Lay out all parts on a clean, flat surface and verify against the package contents list.
2. **Assemble Frame:** Connect the galvanized steel frame sections according to the diagrams in the detailed

manual. Ensure all connections are secure. The three double W-shaped legs provide exceptional stability.

3. **Attach Jumping Mat:** Carefully attach the polypropylene jumping mat to the frame using the 42 high-tension springs. Use the provided spring tool if available. Ensure even tension.
4. **Install Safety Net Poles:** Securely attach the poles for the safety net to the trampoline frame. These poles should be covered with foam padding.
5. **Install Safety Net:** Drape and secure the safety net to the poles and the jumping mat. Ensure the net is taut and the entrance zipper and buckle are functional.
6. **Attach Ladder:** Secure the non-slip ladder to the trampoline frame for safe entry and exit.
7. **Final Check:** Before first use, double-check all connections, bolts, springs, and the safety net for proper installation and security.



Image: Diagram showing the trampoline's key dimensions (244 cm diameter, 214 cm height) and specifications like max weight (50 kg) and number of springs (42).

OPERATING INSTRUCTIONS

Using the HyperMotion trampoline promotes motor skills, balance, and coordination. Regular physical activity improves fitness, reduces stress, and contributes to restful sleep.

- **Entry and Exit:** Always use the provided ladder to enter and exit the trampoline. Do not jump onto or off the trampoline.
- **Secure Entry:** Ensure the safety net's zipper and buckle are closed when the trampoline is in use.
- **Center Jumping:** Encourage users to jump in the center of the mat to maintain balance and avoid contact with the frame or net poles.
- **Controlled Jumping:** Promote controlled bouncing rather than wild, uncontrolled jumps.
- **No Objects:** Do not bring any sharp objects, toys, or other items onto the trampoline that could cause injury or damage.



Image: Close-up of the safety net's entrance, showing the zipper and buckle mechanism for secure closure.

MAINTENANCE

Proper maintenance ensures the safety and extends the lifespan of your trampoline.

- **Regular Inspection:** Periodically inspect the trampoline for loose bolts, damaged springs, tears in the jumping mat or safety net, and worn padding. Replace any damaged parts immediately.
- **Cleaning:** Clean the jumping mat and safety net with mild soap and water. Avoid harsh chemicals.
- **Weather Resistance:** The trampoline is made with UV-resistant and quick-drying materials, making it suitable for outdoor use. However, consider covering it during prolonged periods of non-use or extreme weather to further protect it.
- **Winter Storage:** In regions with harsh winters, it is recommended to disassemble and store the trampoline indoors to prevent damage from snow and ice.




Image: Illustrates the trampoline's UV resistance and quick-drying, water-repellent surface, suitable for outdoor conditions.

TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

- **Squeaking Noises:** Check all frame connections and ensure they are tightened. A small amount of lubricant can be applied to joints if necessary.
- **Uneven Bounce:** Inspect all springs to ensure they are correctly attached and not stretched or damaged. Replace any faulty springs.
- **Net Sagging:** Ensure the safety net poles are securely fastened and the net is properly tensioned and attached to the frame.
- **Difficulty Assembling:** Refer to the detailed assembly diagrams in the full manual. Ensure all parts are correctly oriented before tightening.

SPECIFICATIONS

Brand	HyperMotion
Model Name	Trampoline 8ft
Model Number	TRAMPOLINE 8FT
Color	Black
Frame Size	244 cm / 8FT
Shape	Round
Product Dimensions (L x W x H)	2.44L x 2.44W x 2.14H meters
Item Weight	35 Kilograms
Maximum Weight Recommendation	50 Kilograms
Number of Springs	42
Frame Material	Alloy Steel
Jumping Mat Material	Polypropylene (PP)
Components Included	Safety Net, Ladder
Country of Origin	China

WARRANTY AND SUPPORT

The HyperMotion Outdoor Trampoline comes with a **2-year warranty**. For any questions, assistance with assembly, or warranty claims, please contact HyperMotion customer support. You can find contact information through your purchase platform or by visiting the official HyperMotion brand store.

Manufacturer: HyperMotion