

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VEVOR](#) /

› [VEVOR 2-in-1 Baby Stroller and Bassinet User Manual Model 6800H](#)

VEVOR 6800H

VEVOR 2-in-1 Baby Stroller and Bassinet User Manual

Model: 6800H

1. INTRODUCTION

Thank you for choosing the VEVOR 2-in-1 Baby Stroller and Bassinet. This product is designed to provide a safe, comfortable, and versatile travel system for your child, functioning as both a stroller and an infant bassinet. Please read this manual thoroughly before assembly and use to ensure proper operation and safety.

2. SAFETY INSTRUCTIONS

WARNING: Failure to follow these instructions could result in serious injury or death.

- Always secure your child with the 5-point harness.
- Never leave your child unattended in the stroller or bassinet.
- Do not exceed the maximum weight capacity of 50 lbs (22.7 kg).
- Ensure the stroller is fully locked in place before placing a child in it.
- Engage the brakes when parking the stroller.
- Avoid placing heavy bags on the handle, as this can cause the stroller to tip over.
- Keep fingers clear of moving parts during folding and unfolding.
- Do not use accessories or replacement parts other than those approved by VEVOR.
- Regularly inspect the stroller for loose parts, damaged components, or worn fabric.

3. PACKAGE CONTENTS

Verify that all components are present before assembly:

- Stroller Frame Body (1)
- Infant Bassinet / Seat Body (1)
- Child Tray (1)
- Brake Frame (1)
- Car Seat Base (1) - *Note: This product primarily functions as a stroller and bassinet. The "Car Seat Base" component may refer to the main seat unit or an optional accessory.*

- Adapters (2)
- Cup Holder (1)
- Front Wheels (2)
- Rear Wheels (2)



Figure 3.1: Overview of included accessories and product dimensions.

4. PRODUCT DIAGRAM AND FEATURES

Familiarize yourself with the main parts and features of your VEVOR 2-in-1 Baby Stroller.

PREMIUM ALUMINUM ALLOY SUPPORTS UP TO 50LBS



Carbon Steel Frame



Suspension System



300D Oxford Fabric



EVA Tires

Figure 4.1: Stroller modes and reversible seat functionality.

- **Reversible Seat:** The seat can face forward or backward.
- **Adjustable Backrest:** Two reclining positions (105° and 135°).
- **Adjustable Footrest:** Switches between 70° and 80°.
- **Adjustable Armrests:** Can be adjusted up to 180°.
- **360° Rotating Seat:** Allows for easy adjustment of child's view.
- **One-Hand Fold:** Convenient folding mechanism.
- **EVA Tires:** 7-inch front wheels with directional fixers, 9-inch rear wheels with linked brakes.
- **4-Fold Visible Canopy:** Provides sunshade, windproof, and rainproof protection with breathable mesh.



Figure 4.2: Detailed view of the adjustable canopy.

5. SETUP AND ASSEMBLY

5.1 Unfolding the Frame

1. Place the folded stroller frame on a flat surface.
2. Locate the folding latch and release it.
3. Lift the handle and pull upwards until the frame clicks into its fully open position. Ensure all locking mechanisms are engaged.

5.2 Attaching the Wheels

1. **Front Wheels:** Insert the front wheel axles into the designated slots on the front legs of the stroller frame until they click securely into place. Pull on the wheels to ensure they are firmly attached.

2. **Rear Wheels:** Slide the rear wheel units onto the rear axles until they lock. Verify secure attachment.



Figure 5.1: Detail of front and rear wheels.

5.3 Attaching the Bassinet/Seat Unit

1. Align the connectors on the bottom of the bassinet or seat unit with the mounting points on the stroller frame.
2. Press down firmly until you hear a click, indicating it is securely attached.
3. To reverse the direction, release the unit using the side buttons (if applicable), lift, rotate, and reattach.

4-IN-1 MULTIFUNCTIONAL BABY CAR SEAT

Solve Your Travel
Challenges with One Solution

Seat Mode
Adjustable Backrest and Leg Rest



Cradle Mode
World-Facing and Parent-Facing



Reversible Direction
Comfortable Reclining



Figure 5.2: Stroller frame and bassinet unit.

6. OPERATING INSTRUCTIONS

6.1 Using the Brakes

- To engage the brakes, press down on the brake pedal located near the rear wheels.
- To release the brakes, lift the brake pedal upwards.
- Always engage the brakes when the stroller is stationary.

6.2 Adjusting the Backrest and Footrest

- **Backrest:** Locate the adjustment lever or button on the back of the seat unit. Press and hold to recline or raise the backrest to the desired position (105° or 135°). Release to lock.
- **Footrest:** Use the buttons on either side of the footrest to adjust its angle (70° or 80°).

6.3 Adjusting the Handle and Armrests

- **Handle:** Press the buttons on the sides of the handle to adjust its height and angle for comfortable pushing.
- **Armrests:** The armrests can be adjusted up to 180° for child comfort and ease of access.

6.4 Using the 5-Point Harness

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their hips.
3. Connect the two buckle clips into the central buckle until they click.
4. Adjust the straps to ensure a snug but comfortable fit.
5. To release, press the button on the central buckle.

6.5 Folding the Stroller

1. Ensure the seat is in an upright position and the canopy is folded back.
2. Locate the one-hand fold mechanism (usually a button or lever on the handle).
3. Activate the mechanism and push the handle forward or downward to collapse the stroller.
4. Secure the folding latch to keep the stroller in its compact, folded state.

7. MAINTENANCE

7.1 Cleaning

- **Fabric Parts:** The 300D Oxford fabric is detachable for easy cleaning. Hand wash with mild soap and cold water, then air dry. Do not bleach or tumble dry.
- **Frame:** Wipe the aluminum alloy frame with a damp cloth and mild soap. Dry thoroughly. Do not use abrasive cleaners.
- **Wheels:** Periodically clean dirt and debris from the EVA wheels. Lubricate axles if necessary to ensure smooth movement.

7.2 Storage

Store the stroller in a dry, cool place away from direct sunlight and extreme temperatures to prevent material degradation.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller does not fold easily.	Folding mechanism not fully disengaged; seat not in upright position.	Ensure seat is upright and canopy is folded. Re-engage and disengage the folding mechanism.
Wheels are stiff or squeaky.	Dirt/debris in axles; lack of lubrication.	Clean wheels and axles. Apply a silicone-based lubricant if needed.
Harness buckles are difficult to connect/disconnect.	Debris in buckle; misalignment.	Inspect buckles for obstructions. Ensure proper alignment before attempting to connect.

Problem	Possible Cause	Solution
Stroller feels unstable.	Frame not fully locked; wheels not securely attached.	Verify all frame locking mechanisms are engaged. Check that all wheels are clicked into place.

9. SPECIFICATIONS

Feature	Detail
Model	6800H
Maximum Weight Capacity	50 lbs / 22.7 kg
Net Weight	16.4 kg / 36.2 lbs
Product Dimensions (L x W x H)	900x655x1115 mm / 35.4x25.8x43.9 inches
Folded Dimensions (L x W x H)	990x655x430 mm / 39.0x25.8x16.9 inches
Frame Material	Aluminum Alloy (6061)
Fabric Material	300D Oxford Fabric
Wheel Material	EVA
Front Wheels	7 inches with directional fixer
Rear Wheels	9 inches with linked brakes
Harness Type	5 Point
Backrest Adjustment	105°, 135°
Footrest Adjustment	70°, 80°
Handle Adjustment	Rotatable and adjustable
Folding Mechanism	One-hand fold

10. WARRANTY INFORMATION

This product comes with a manufacturer's warranty. Please refer to the warranty card included in your package or visit the official VEVOR website for detailed warranty terms and conditions. Keep your proof of purchase for warranty claims.

11. CUSTOMER SUPPORT

For technical assistance, missing parts, or any questions regarding your VEVOR 2-in-1 Baby Stroller and Bassinet, please contact VEVOR customer support. Contact information can typically be found on the VEVOR official website or on the

product packaging.

© 2024 VEVOR. All rights reserved.