

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [EOEOTWO](#) /

› [EOEOTWO GT06 Electric Scooter User Manual](#)

EOEOTWO GT06

EOEOTWO GT06 Electric Scooter User Manual

Model: GT06 (1200W-48V-13AH / 1200W-48V-23.4AH)

1. INTRODUCTION

This manual provides essential instructions for the safe operation, assembly, maintenance, and troubleshooting of your EOEOTWO GT06 Electric Scooter. Please read this manual thoroughly before your first ride to ensure proper use and to maximize your riding experience. Retain this manual for future reference.



Figure 1.1: The EOEOTWO GT06 Electric Scooter, showcasing its robust design and integrated digital display.

2. SAFETY GUIDELINES

Your safety is paramount. Always adhere to the following guidelines to prevent injury or damage.

- Always wear a helmet and appropriate protective gear (knee pads, elbow pads) when riding.
- Ensure all bolts and quick-release mechanisms are securely fastened before each ride.
- Check tire pressure and brake functionality before every use.
- Do not ride in heavy rain, on icy surfaces, or through standing water.
- Observe all local traffic laws and regulations.
- The scooter is designed for riders aged 14 to 60 years old.
- Do not exceed the maximum weight limit of 330 pounds (150 kg).
- Avoid riding on steep slopes exceeding 35% incline.
- Maintain a safe distance from other vehicles and pedestrians.
- Use caution when riding at night. The scooter is equipped with front and rear lights for visibility.



Figure 2.1: The EOEOTWO GT06 Electric Scooter is capable of climbing inclines, but always ride responsibly and within your skill level.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your EOEOTWO GT06 Electric Scooter.

3.1 Key Components

- **Handlebar:** For steering and control.
- **Digital Display:** Shows speed, battery level, and riding mode.
- **Brake Levers:** Controls the front and rear disc brakes.
- **Throttle:** Controls acceleration.
- **Headlight & Taillight:** For visibility during low-light conditions.
- **11-inch Off-Road Tires:** Provides enhanced grip and stability.
- **Full Suspension:** Front and rear shock absorbers for a comfortable ride.
- **Folding Mechanism:** Allows for compact storage and transport.
- **Kickstand:** For parking the scooter.

Larger LED Display

3-levels of speed



15.5 MPH

Suitable for novices

21.7 MPH

Seeking efficient trip

28.6 MPH

Extreme speed for
a Challenger

Figure 3.1: The scooter features a large LED display showing current speed, battery status, and selected speed level (1, 2, or 3).

11-INCH OFF-ROAD TIRES

Grip Every Surface Like a Beast!



Figure 3.2: The 11-inch off-road tires are designed to provide superior grip across various terrains.

Safe riding, No Bumps

Equipped with high-quality front and rear disc brakes & dual shock absorbers



Figure 3.3: The scooter is equipped with high-quality front and rear disc brakes and dual shock absorbers for safe and comfortable riding.

4. SETUP

4.1 Unpacking and Initial Assembly

1. Carefully remove all components from the packaging.
2. Unfold the scooter frame until it locks into place. Ensure the folding mechanism is secure.

3. Attach the handlebar to the stem, ensuring all cables are properly connected and not pinched. Secure with the provided fasteners.
4. Check that both tires are adequately inflated.

4.2 Initial Charging

Before your first ride, fully charge the scooter's battery.

- Locate the charging port, typically covered by a rubber flap.
- Connect the charger to the scooter, then plug it into a power outlet.
- The charging indicator on the charger will change (e.g., red to green) when fully charged.
- Charging typically takes 3-4 hours for a full charge.
- Disconnect the charger once charging is complete and secure the charging port cover.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

Press and hold the power button on the digital display to turn the scooter on or off.

5.2 Riding Modes and Speed Control

The digital display allows you to select different speed modes:

- **Mode 1:** Approximately 15.5 MPH (suitable for beginners).
- **Mode 2:** Approximately 21.7 MPH (for efficient commuting).
- **Mode 3:** Approximately 28.6 MPH (for experienced riders seeking higher speeds).

Use the throttle to accelerate. Gradually apply pressure for smooth acceleration.

5.3 Braking

The scooter is equipped with dual disc brakes. Apply both brake levers simultaneously for effective and controlled stopping. Avoid sudden, harsh braking, especially at high speeds or on slippery surfaces.

5.4 Folding and Unfolding

To fold the scooter for storage or transport, engage the folding mechanism located on the stem. Ensure it is securely latched when folded and unfolded.

SIZE



Figure 5.1: The scooter's folding mechanism allows for compact storage, reducing its height from 53 inches to 22 inches.

Riding Safely at Night

Bright headlights and integrated taillights ensure you can see and be seen



Figure 5.2: The bright headlights and integrated taillights ensure visibility and safety during nighttime riding.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your scooter.

6.1 Cleaning

Wipe the scooter with a damp cloth. Do not use high-pressure water jets or immerse the scooter in water, as this can damage electrical components.

6.2 Tire Care

Regularly check tire pressure and inflate to the recommended PSI (refer to tire sidewall for details). Inspect tires for wear and tear, and replace if necessary.

6.3 Brake Adjustment

If brakes feel loose or unresponsive, they may need adjustment. Consult a qualified technician or refer to specific brake adjustment guides.

6.4 Battery Care and Storage

- Charge the battery regularly, even if not in use, to maintain its health.
- Store the scooter in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid fully discharging the battery frequently.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

- **Scooter not turning on:** Check battery charge. Ensure all connections are secure.
- **Reduced range:** May indicate low tire pressure, riding in high-speed mode, or riding uphill frequently. Battery degradation over time is also normal.
- **Brakes feel weak:** Inspect brake pads for wear. Brakes may need adjustment or replacement.
- **Unusual noises:** Stop riding immediately and inspect the scooter for loose parts or damage.

For issues not covered here, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	EOEOTWO
Model Name	GT06
Motor Power	1200W
Max Speed	31 MPH
Max Range	20-25 Miles (depending on model and conditions)
Battery	48V 13Ah (or 23.4Ah for other variants)
Charging Time	3-4 Hours
Tires	11-inch Off-Road Pneumatic
Suspension	Dual Suspension
Brake Style	Front and Rear Disc Braking

Max Climbing Angle	Up to 35%
Weight Limit	330 Pounds (150 kg)
Product Dimensions (Expanded)	48"L x 26"W x 51"H
Product Dimensions (Folded)	48"L x 22"H
Frame Material	Aluminum Alloy Steel
Age Range	14 to 60 years old

9. WARRANTY AND SUPPORT

9.1 Warranty Information

The EOEOTWO GT06 Electric Scooter comes with a **60-day limited warranty**. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your EOEOTWO GT06 Electric Scooter, please refer to the contact information provided at the point of purchase or visit the official EOEOTWO website.

© 2025 EOEOTWO. All rights reserved.

Please ride responsibly and safely.