

Comfytemp B0F7R98SCQ

Comfytemp Cordless Heating Pad with Back Brace User Manual

Model: B0F7R98SCQ

1. INTRODUCTION

The Comfytemp Cordless Heating Pad with Back Brace is designed to provide targeted heat therapy and lumbar support for pain relief. This portable and rechargeable device offers convenience and comfort, allowing for use during various activities. It features multiple heat levels and timer settings to customize your experience.

This manual provides essential information on the safe and effective use, setup, operation, and maintenance of your Comfytemp Cordless Heating Pad with Back Brace.

2. PRODUCT COMPONENTS



Figure 2.1: Comfytemp Cordless Heating Pad with Back Brace. This image displays the main components including the heating element, control panel, and adjustable straps.

Premium Materials for Comfort

Breathable Lycra Lining

Soft, breathable and excellent heat retention



Hook-and-Loop External

Durable and adjustable

Figure 2.2: Premium Materials for Comfort. Illustrates the breathable Lycra lining and durable hook-and-loop external fabric used in the heating pad's construction.

Package Contents:

- 1 x Comfytemp Cordless Heating Pad with Back Brace
- 1 x 5000mAh Rechargeable Power Bank
- 1 x USB Charging Cable (Type C)
- 1 x Extension Strap (for waist sizes 26 to 52 inches)
- User Manual (this document)

3. SETUP

3.1 Charging the Power Bank

Before first use, fully charge the included 5000mAh power bank. Use a 5V/2A charger (not included) and the provided USB Type C charging cable. The four small white lights on the power bank will pulse while charging and indicate the

charge level.

1. Connect the USB charging cable to the power bank's input port (Micro USB or Type C).
2. Connect the other end of the cable to a compatible 5V/2A USB wall charger.
3. Charge for approximately 3 hours until all four indicator lights are solid.

3.2 Attaching the Power Bank

The heating pad features a dedicated storage pocket for the power bank.

1. Locate the storage pocket on the right side of the back brace.
2. Connect the power bank to the USB cable inside the pocket.
3. Insert the power bank into the pocket and secure it.

How to Use for Better Pain Relief?



Align the center of the belt with the lumbar spine position



Align the belt with your navel and fasten it with both sides fully overlapping



Tighten the adjustment straps on both sides until you feel firm support

NOTE:

- Use while wearing lightweight clothing.
- Start at the lowest level to avoid burns.
- Check your skin regularly to avoid overheating or burns.

Figure 3.1: Steps for connecting the power bank and wearing the heating pad.

4. OPERATING INSTRUCTIONS

4.1 Wearing the Heating Pad

1. Align the center of the belt with your lumbar spine position (lower back).
2. Wrap the main belt around your waist, aligning it with your navel, and fasten it with both sides fully overlapping.
3. Tighten the dual adjustable straps on both sides until you feel firm, comfortable support. An extension strap is included for waist sizes up to 52 inches.
4. **Important Note:** It is recommended to wear lightweight clothing when using the heat function to prevent direct skin contact and potential burns.

Dual-Strap Fit for Better Support & Warmth

Fits tightly to your body, enhancing lumbar support and heat retention



Figure 4.1: Dual-Strap Fit for Better Support and Warmth. Demonstrates how the adjustable straps provide a secure and comfortable fit.



Figure 4.2: Adjustable to Your Waist. Illustrates the standard belt and the included extension belt for a wider range of waist sizes.

4.2 Powering On and Adjusting Settings

The control panel features two buttons: one for timer settings and one for heat levels.

1. To power on, press and hold either the Timer button (clock icon) or the Heat button (waves icon) for a few seconds. The LED indicators will light up.
2. **Adjusting Heat Levels:** Press the Heat button (waves icon) to cycle through the three temperature levels:
 - **Green:** Low Heat
 - **Blue:** Medium Heat
 - **Red:** High Heat

The heat will start within a few seconds and reach full temperature in about one minute.

3. **Adjusting Timer Settings:** Press the Timer button (clock icon) to cycle through the three timer settings:
 - 15 Minutes

- 30 Minutes
- 45 Minutes

The device will automatically shut off after the selected time.

4. To power off, press and hold either button again for a few seconds.



Figure 4.3: Control Panel for Temperature and Timer Settings. Displays the intuitive buttons and their corresponding LED colors for different settings.

4.3 Usage Recommendations

- For best results, start at the lowest heat level and gradually increase if needed. Regularly check your skin to avoid overheating or burns.
- The heating pad can provide up to 4 hours of cordless warmth on low setting, or up to 2 hours on high setting, with a fully charged power bank.
- It is recommended to use the support function for up to 2 hours per day and heat therapy for about 15 minutes per session.

- This product is not suitable for strenuous physical activity or heavy lifting.

Your browser does not support the video tag.

Video 4.1: Demonstrates the features and proper usage of the Comfytemp Cordless Heating Pad with Back Brace, including how to wear it and adjust settings.

5. MAINTENANCE

5.1 Cleaning Instructions

- Always unplug the power bank from the heating pad before cleaning.
- Wipe the surface of the heating pad with a damp cloth and mild detergent.
- Do not submerge the heating pad or power bank in water.
- Allow the heating pad to air dry completely before storing or re-using.

5.2 Storage

- Store the heating pad in a cool, dry place away from direct sunlight.
- Ensure the power bank is fully charged before long-term storage to maintain battery health.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heating pad does not turn on.	Power bank is not charged or not connected properly.	Ensure the power bank is fully charged and securely connected to the heating pad. Press and hold a control button to power on.
Heat is not strong enough.	Low heat setting selected; battery level is low.	Increase the heat level using the Heat button. Ensure the power bank is fully charged.
Heating pad turns off unexpectedly.	Timer setting expired; power bank battery depleted.	Check the timer setting and reset if necessary. Recharge the power bank.
Control buttons are hard to reach/see.	Placement of the power bank pocket on the side.	While wearing, you may need to adjust the belt slightly or use a mirror to view the buttons. Familiarize yourself with button positions for tactile use.

7. SPECIFICATIONS

- **Product Dimensions:** 47.24 x 8.66 x 1.18 inches; 1.79 Pounds
- **Power Source:** 5000mAh Rechargeable Battery
- **Heat Levels:** 3 (Low, Medium, High)
- **Timer Settings:** 3 (15, 30, 45 minutes)
- **Adjustable Waist Size:** 26 to 52 inches (with extension strap)
- **Material:** Breathable Lycra Lining, Hook-and-Loop External
- **Support System:** 6 built-in support strips (4 lumbar + 2 abdomen)
- **Color:** Black

- **Manufacturer:** Shenzhen Yicai Health Technology Co. , Ltd.

Upgraded Support Strips

6x Lumbar Support

360° Compression




Figure 7.1: Upgraded Support Strips. Illustrates the internal structure providing 6x lumbar support and 360° compression.

8. WARRANTY AND SUPPORT

Comfytemp is committed to providing high-quality products and customer satisfaction.

- **Warranty:** This product comes with a 365-day warranty from the date of purchase.
- **Returns:** Enjoy 30 days of free returns.
- **Customer Support:** For any inquiries, technical assistance, or warranty claims, please contact Comfytemp customer support. We aim to provide 24-hour quick customer support.
- **Legal Disclaimer:** Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

