Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Maxim Lighting /
- Maxim Lighting Keanu 88753BK Outdoor Ceiling Fan Instruction Manual

Maxim Lighting 88753BK

Maxim Lighting Keanu 88753BK Outdoor Ceiling Fan Instruction Manual

Model: 88753BK

Safety Information

Package Contents

Setup & Installation

Operation

Maintenance

Troubleshooting

Specifications War

Warranty & Support

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Maxim Lighting Keanu 88753BK Outdoor Ceiling Fan. Please read this manual thoroughly before beginning installation and retain it for future reference. Proper installation and operation are essential for optimal performance and safety.

IMPORTANT SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these instructions:

- Ensure the power is turned off at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. Consult a qualified electrician if you are unsure about wiring procedures.
- The fan must be mounted to a structurally sound outlet box or support system capable of supporting a minimum of 35 lbs (15.9 kg).
- Do not bend the blade holders during installation, balancing, or cleaning.
- Keep hands, tools, and other objects clear of the fan blades when the fan is operating.
- This fan is suitable for outdoor, wet location use. Ensure all connections are properly sealed to prevent water ingress.
- Do not operate the fan with a damaged power cord or plug.
- Do not use this fan with any solid-state speed control device unless specifically designed for this fan.

PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact Maxim Lighting customer service.

- · Ceiling Fan Motor Assembly
- Fan Blades (ABS material)
- Mounting Bracket
- Downrod (if applicable for your model) or Hugger Mount components
- Canopy
- Hardware Pack (screws, washers, wire nuts)
- DC Wall Control
- Instruction Manual (this document)
- Integrated LED Light Kit

SETUP AND INSTALLATION

This ceiling fan requires assembly and semi-flush mount installation. Professional installation is recommended.

1. Pre-Installation Checks

- Ensure the installation location is suitable for an outdoor, wet-rated ceiling fan.
- Verify the electrical supply is turned off at the main circuit breaker.
- Confirm the ceiling joist or support structure can hold the fan's weight (approximately 13.8 lbs).

2. Mounting the Bracket

Attach the mounting bracket securely to the ceiling outlet box. Use hardware appropriate for your ceiling type. Ensure the bracket is level and firmly attached.

3. Wiring Connections

Connect the fan's electrical wires to the household wiring according to the provided wiring diagram (refer to the diagram in the physical manual). Ensure all connections are secure and insulated with wire nuts. This fan operates on 120 Volts, Corded Electric power.

4. Assembling the Fan

Carefully attach the fan motor assembly to the mounting bracket. Then, secure the ABS fan blades to the motor housing. Ensure all screws are tightened to prevent wobbling.



Figure 1: Maxim Lighting Keanu 88753BK Outdoor Ceiling Fan in Black finish. This image shows the fan's overall design, featuring its sleek black housing and uniquely curved ABS blades, designed for durability in wet locations.

5. Canopy Installation

Slide the canopy up to the ceiling and secure it to cover the wiring connections and mounting bracket. Ensure a

snug fit to protect internal components from outdoor elements.

6. Dimensions Overview

The fan measures 56 inches in width and 12.75 inches in height from the ceiling to the lowest point of the fan. Refer to the diagram below for detailed measurements.




Figure 2: Detailed dimension diagram for the Maxim Lighting Keanu 88753BK Outdoor Ceiling Fan. This illustration provides key measurements including the 56-inch blade span, 12.75-inch overall height, and specific dimensions for the motor housing and canopy, aiding in proper installation planning.

OPERATING INSTRUCTIONS

Your Keanu ceiling fan is designed for efficient air circulation and features an integrated LED light.

Fan Speed Control

The fan speed is controlled via the included DC wall control. Refer to the wall control's specific instructions for detailed operation. The energy-efficient DC motor provides quiet and powerful performance across multiple speed settings.

Light Operation

The integrated LED light kit is CCT-tunable, allowing adjustment from a warm 2700K to a bright 5000K. Use the DC wall control to turn the light on/off and to cycle through the color temperature settings. The light source type is LED, with a wattage of 15 watts.

Seasonal Operation (Reverse Function)

Most ceiling fans include a reverse switch to change the direction of blade rotation. This allows for downdraft cooling in summer and updraft heat circulation in winter. Consult your physical manual or the DC wall control instructions for the location and operation of the reverse switch.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically clean the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or plastic components.
- Tightening Screws: Check all screws on the fan blades and mounting hardware annually. Tighten any

loose screws to prevent wobbling and ensure safe operation.

- **Blade Balance:** If the fan wobbles, ensure all blades are securely attached and balanced. A balancing kit (often sold separately) can be used if necessary.
- Electrical Connections: Ensure all electrical connections remain secure, especially in outdoor environments.

Important: Always turn off the power at the circuit breaker before performing any cleaning or maintenance.

TROUBLESHOOTING

Before contacting customer support, review these common issues and solutions.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Faulty wall control.	Check circuit breaker; Verify all wire connections are secure; Test or replace wall control.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit; Ensure mounting bracket is secure.
Light does not work	Loose wire connection to light kit; Faulty LED driver; Incorrect light setting.	Check light kit wiring; Contact customer support for LED driver replacement; Cycle through light settings on wall control.
Noisy operation	Loose screws; Motor hum; Blades hitting an obstruction.	Tighten all screws; Ensure no obstructions are near blades; Motor hum is normal for some DC motors.

PRODUCT SPECIFICATIONS

Brand	Maxim Lighting
Model Name	Keanu 88753BK
Finish Color	Black
Material	ABS Plastic
Style	Modern
Product Dimensions (L x W x H)	56" x 56" x 12.75"
Item Weight	13.78 pounds
Indoor/Outdoor Usage	Outdoor (Wet Location Rated)
Power Source	Corded Electric
Voltage	120 Volts
Light Source Type	Integrated LED
Light Color	Warm White to Cool White (2700K-5000K)
Wattage	15 watts (for LED light)

Switch Type	DC Wall Control
Installation Type	Semi Flush Mount
Special Feature	Heavy Duty, Energy Star Certified
UPC	783209336544

WARRANTY INFORMATION

This Maxim Lighting Keanu 88753BK Outdoor Ceiling Fan comes with a **Limited Warranty**. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or visit the official Maxim Lighting website. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report missing/damaged parts, please contact Maxim Lighting customer support:

- Website: Visit the official Maxim Lighting website for FAQs and support resources.
- **Phone:** Refer to your product packaging or the Maxim Lighting website for customer service contact numbers.
- Email: Contact support via the email address provided on the official website.

Please have your model number (88753BK) and proof of purchase ready when contacting support.

© 2025 Maxim Lighting. All rights reserved.

Related Documents - 88753BK




Maxim Lighting Paloma 5-Light Chandelier (2885AR) - Installation and Care Guide

Detailed installation, care, and maintenance guide for the Maxim Lighting Paloma 5-Light Chandelier, model 2885AR. Includes parts list, safety warnings, and assembly steps for this elegant lighting fixture.



Maxim Lighting Falcon DC 52" Indoor/Outdoor Fan with LED Light Kit - Model 88717 Installation Guide

Comprehensive installation guide for the Maxim Lighting Falcon DC 52-inch Indoor/Outdoor Ceiling Fan (Model 88717) with LED Light Kit. Includes safety instructions, tools, parts, diagrams, wiring, and troubleshooting.



MAXIM LIGHTING 63002DWBK Ceiling Fan Installation and Safety Instructions

This document provides comprehensive installation, safety, technical specifications, and maintenance instructions for the MAXIM LIGHTING 63002DWBK ceiling fan, including details on its remote transmitter functions.



Maxim Lighting 61012 Ceiling Fan Installation and Safety Guide

Comprehensive installation and safety instructions for the Maxim Lighting 61012 ceiling fan, covering safety precautions, parts list, step-by-step installation, smart control setup, transmitter functions, technical specifications, and maintenance.



Maxim Lighting Finch 1-Light Wall Sconce (Model 21721) - Installation and Care Guide

Detailed installation, parts list, and maintenance instructions for the Maxim Lighting Finch 1-Light Wall Sconce (Model 21721). Learn how to safely assemble and care for your lighting fixture.



Maxim Lighting 60013SM Ceiling Fan Installation Guide and Safety Instructions

Comprehensive installation guide, safety precautions, parts list, and maintenance instructions for the Maxim Lighting 60013SM ceiling fan. Includes technical specifications and transmitter functions.