



[Manuals.plus](#) /

> [LUMISOL](#) /

> LUMISOL King Size Wood Platform Bed Frame User Manual

LUMISOL B0F8BV13P2

LUMISOL King Size Wood Platform Bed Frame

USER MANUAL

INTRODUCTION

Thank you for choosing the LUMISOL King Size Wood Platform Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always assemble the bed frame on a soft, clean surface to prevent damage to the product or your floor.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- Do not exceed the maximum weight capacity of 650 LBS.
- Keep small parts and packaging materials away from children during assembly.
- Use only the tools and hardware provided or recommended by the manufacturer.
- This bed frame is designed for use with a mattress of 6 inches or greater in thickness. A box spring is not required.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Headboard components
- Side rails (wood)

- Footboard components (wood)
- Metal base supports
- Wood slats
- Center support legs
- All necessary hardware (bolts, screws, washers, Allen wrench)

ASSEMBLY INSTRUCTIONS

Assembly is required. It is recommended that two adults assemble this bed frame. Follow the detailed illustrated instructions included in your package. A general overview of the steps is provided below.



Figure 1: Product Dimensions and Weight Capacity. Max weight capacity: 650 LBS. Recommended mattress thickness: 6 inches.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface and compare them against the parts list in your instruction manual to ensure everything is present.
2. **Assemble Headboard:** Attach the headboard slats to the headboard posts using the provided hardware. Ensure all connections are firm.

3. **Attach Side Rails:** Connect the wooden side rails to the headboard and footboard sections. Secure with bolts and an Allen wrench. Do not fully tighten until all major frame components are connected.
4. **Install Metal Base Supports:** Attach the black metal base supports to the wooden frame as indicated in the detailed instructions. These provide additional stability and elevation.
5. **Insert Center Support Legs:** Screw in the adjustable center support legs to the designated crossbeams or slats. Adjust their height to ensure even support across the frame.
6. **Place Wood Slats:** Lay the wood slats across the bed frame, ensuring they are evenly spaced and secured according to the instructions. Some slats may have pre-drilled holes for screws.
7. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and screws. Do not overtighten.



Figure 2: Detail of slat support and frame connection.

USAGE GUIDELINES

- Place your mattress directly onto the wood slats. A box spring is not required for this platform bed frame.
- Ensure the mattress is properly centered on the frame to distribute weight evenly.

- Avoid jumping on the bed frame, as this can compromise its structural integrity and void any warranty.




Figure 3: Assembled bed frame with mattress in a bedroom environment.

CARE AND MAINTENANCE

- **Cleaning:** Spot clean the wooden and metal surfaces with a mild detergent and a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Dusting:** Regularly dust the frame with a dry, soft cloth to prevent buildup.
- **Fastener Check:** Periodically (e.g., every 3-6 months) check all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Moisture:** Protect the bed frame from excessive moisture and direct sunlight to prevent warping or fading of the wood.

TROUBLESHOOTING

Squeaking Noises

- **Check Fasteners:** Ensure all bolts and screws are securely tightened. Loose connections are a common cause of squeaking.
- **Inspect Slats:** Verify that all wood slats are properly seated and not rubbing against the frame. Adjust if needed.
- **Lubricate Joints:** A small amount of wax or silicone spray on metal-to-metal or wood-to-wood contact points can reduce friction and noise.

Instability or Wobbling

- **Re-tighten All Hardware:** Systematically go through all connections and ensure they are firm.

- **Level the Frame:** Ensure the bed frame is on a level surface. Adjust center support legs if they are uneven.
- **Verify Assembly:** Double-check the assembly steps against the provided manual to ensure no steps were missed or parts incorrectly installed.

PRODUCT SPECIFICATIONS

Attribute	Detail
Product Name	Platform Bed Frame
Model Number	B0F8BV13P2
Size	King
Overall Product Dimensions (L x W x H)	85.5" x 81.5" x 27.2"
Weight Capacity	650 LBS
Main Material	Iron, Pine Wood, Plywood
Box Spring Required	No
Assembly Required	Yes
Included Components	All Tools

WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please refer to the documentation included with your purchase or contact LUMISOL customer service directly. Keep your purchase receipt for warranty claims.