

[Manuals.plus](#) /

› [GODOX](#) /

› [GODOX iT30 Pro C mini TTL Wireless Camera Flash User Manual](#)

GODOX GD-iT30Pro C-MIC

GODOX iT30 Pro C mini TTL Wireless Camera Flash User Manual

Model: GD-iT30Pro C-MIC

INTRODUCTION

The GODOX iT30 Pro C mini TTL Wireless Camera Flash is a compact and powerful lighting solution designed for Canon cameras. Featuring a 2.4G wireless system, a responsive touchscreen, and a built-in lithium battery, it offers advanced functionality for professional and enthusiast photographers. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.



Image: The GODOX iT30 Pro C flash unit along with its USB-C charging cable and storage bag.

SAFETY INFORMATION

- Do not disassemble or modify the flash unit. High voltage components are present.
- Keep the device dry. Do not expose to rain or moisture.
- Do not touch the flash tube after firing, as it may be hot.
- Avoid direct eye exposure to the flash, especially at close range, as it can cause temporary vision impairment.
- Use only the specified charging cable and power adapter.
- Store in a cool, dry place away from direct sunlight and extreme temperatures.

WHAT'S IN THE BOX

Verify that all components are present upon unboxing:

- Light Body x1

- USB-C Charging Cable x1
- Storage Bag x1

WHAT'S IN THE BOX

iT30Pro(Black)



Light Body	x1
USB-C Charging Cable	x1
Storage Bag	x1

Image: A visual representation of the items included in the product packaging: the flash unit, a USB-C cable, and a storage bag.

PRODUCT OVERVIEW

The GODOX iT30 Pro C is designed for portability and ease of use. Its compact size makes it ideal for on-location work.



TRAVEL LIGHT, SHOOT BIG

weighing only **120g**, the iT30 Pro slips into any bag—ideal for on-location work

Image: The iT30 Pro C flash unit shown fitting easily into a jacket pocket, highlighting its compact and portable design.

Key features include a full-color touchscreen for intuitive control and a built-in diffuser for soft, even lighting.

SETUP

1. Charging the Battery

The iT30 Pro C features a built-in lithium battery. Before first use, fully charge the device.

1. Connect the supplied USB-C charging cable to the flash unit's USB-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator on the flash will show charging status. A full charge provides up to 560 full-power flashes.

WHAT'S IN THE BOX

iT30Pro(Black)



Light Body	x1
USB-C Charging Cable	x1
Storage Bag	x1

Image: A person connecting a USB-C cable to the GODOX iT30 Pro C flash unit, illustrating the charging process.

2. Mounting the Flash to a Camera

The iT30 Pro C features a quick-release foot for easy mounting and removal.

1. Slide the flash unit's hot shoe foot into your camera's hot shoe mount.
2. Press the quick-release button/lever to secure the flash in place. Ensure it clicks firmly.
3. To remove, press the quick-release button/lever and slide the flash out.



QUICK MOUNT, QUICK RELEASE

Redesigned quick-release foot lets you lock or remove the flash in a single press.



Image: The GODOX iT30 Pro C flash unit being attached to a camera's hot shoe, demonstrating the quick-release mechanism.

OPERATING INSTRUCTIONS

1. Powering On/Off

Press and hold the power button located on the side of the unit to turn the flash on or off.

2. Using the 2.8" Full-Color Touchscreen

The iT30 Pro C features a responsive touchscreen for intuitive navigation and settings adjustment. You can swipe through menus and tap to select options. For fine-tuning, a traditional rotary dial is also available.

FULL-COLOR TOUCHSCREEN

Responsive 2.8" touchscreen that lets you swipe through settings and adjust power with just a tap.



Image: A detailed view of the GODOX iT30 Pro C's 2.8-inch full-color touchscreen, showing its user interface and touch interaction.



touch screen



full color

3. TTL Auto-Exposure

In TTL (Through-The-Lens) mode, the flash meters light through your camera's lens in real-time to automatically calculate the optimal flash output for a perfectly exposed image.

TTL AUTO-EXPOSURE

TTL mode meters light through your lens in real time and instantly calculates the optimal flash output.



Image: The GODOX iT30 Pro C flash mounted on a camera, displaying its screen in TTL auto-exposure mode, with a subject in the background.

4. Advanced Flash Features

The iT30 Pro C supports various advanced flash modes:

- **High-Speed Sync (HSS):** Supports shutter speeds up to 1/8000s, allowing you to use flash with wide apertures in bright conditions.
- **Front/Rear-Curtain Sync:** Synchronizes the flash with either the beginning or end of the shutter exposure, useful for capturing motion blur effects.
- **Multi Mode:** Fires a series of rapid flashes during a single exposure, ideal for capturing multiple movements of a subject.
- **Flash Exposure Compensation (FEC):** Adjusts the flash output relative to the camera's metered exposure, allowing for creative control over flash brightness.

ADVANCED FEATURES, PRO CONTROL

Supports **1/8000s** high-speed sync, front/rear-curtain sync, multi mode, and flash exposure compensation.



✔ Multi-modal

✔ Flash exposure compensation

✔ Front/Rear Curtain Sync

✔ Supports 1/8000 second high-speed sync

Image: The GODOX iT30 Pro C flash mounted on a camera, illustrating its capability for advanced features such as 1/8000s high-speed sync and flash exposure compensation.

5. Using the Built-In Diffuser

The iT30 Pro C includes a built-in diffuser for softer, more even light distribution. Simply flick the lever to deploy or retract the diffuser.



BUILT-IN DIFFUSER

With a quick flick of the lever, the iT30 Pro's built-in diffuser drops into place to deliver wider coverage and beautifully soft, even lighting.



Image: A comparison showing the effect of the GODOX iT30 Pro C's built-in diffuser, with examples of light output when the diffuser is off and on.

6. Wireless Master & Receiver Modes

The iT30 Pro C integrates the Godox 2.4GHz X system, allowing it to function as both a master and receiver unit. This enables flexible multi-light setups.

- **Master Mode:** Control other Godox 2.4GHz X system flashes (e.g., X3 trigger, AD200Pro, V100) wirelessly from the iT30 Pro C.
- **Receiver Mode:** Be triggered by another Godox 2.4GHz X system transmitter.
- Refer to the Godox X system manual for detailed pairing and group setup instructions.

WHAT'S IN THE BOX

iT30Pro(Silver)



Light Body	x1
USB-C Charging Cable	x1
Storage Bag	x1

Image: A diagram illustrating the GODOX iT30 Pro C's capability as a wireless master and receiver, showing it controlling other Godox flashes in a multi-light setup.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the flash unit. For stubborn dirt, a slightly damp cloth can be used, followed by a dry one. Do not use solvents or abrasive cleaners.
- **Storage:** When not in use for extended periods, store the flash in its provided storage bag in a cool, dry place. Ensure the battery is partially charged (around 50%) before long-term storage to preserve battery health.
- **Battery Care:** Avoid fully discharging the battery frequently. Recharge the battery regularly, even if the flash is not used often.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flash does not fire.	Low battery; Incorrect mode; Not properly mounted; Camera settings.	Charge battery; Check flash mode (TTL/M); Ensure flash is securely mounted on hot shoe; Verify camera flash settings.
Flash recycle time is slow.	Low battery; High power output.	Recharge battery; Reduce flash power output.
Flash output is inconsistent.	Interference in wireless mode; Dirty contacts.	Change wireless channel/group; Clean hot shoe contacts on both flash and camera.
Touchscreen unresponsive.	Temporary software glitch.	Restart the flash unit. If issue persists, contact support.

SPECIFICATIONS

Feature	Detail
Model Number	GD-iT30Pro C-MIC
Dimensions (Package)	2.5 x 1.8 x 1.8 inches

Feature	Detail
Item Weight	4.2 ounces
Flash Sync Speed	Up to 1/8000s (HSS)
Wireless System	Godox 2.4GHz X System
Display	2.8" Full-Color Touchscreen
Battery	Built-in Lithium Battery
Full Power Flashes	Up to 560 per charge
Recycle Time	1.5 seconds
Included Components	Light Body, USB-C Charging Cable, Storage Bag

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official GODOX website or contact your local distributor. Keep your purchase receipt as proof of purchase for warranty claims.

GODOX Official Website: www.godox.com

